PARTS LOCATION

DIDY6–01

Turbo Pressure Sensor VSV for Turbo Pressure Sensor

EGR Valve Shift Position Switch (M/T)

Intake Air Temp. Sensor VSV for EGR Cut Neutral Start Switch

Engine ECU

Intake Heater Spill Valve Relay (Marking: SPIL/VLV)

Throttle Body

Intake Heater Relay

Check Connector

Air Flow Meter*

E–VRV for Intake Pressere Charge*

E–VRV for EGR

Accelerator Pedal Position Sensor
Accelerator Pedal Closed Position Switch

DLC3 Clutch Start Switch
EDU
EFI OR ECD Relay

PS Oil Pressure Switch

Crankshaft Position Sensor
Water Temp. Sensor

VSV for Swirl Control Valve*
Injection Pump

Engine Speed Sensor

Spill Control Valve

Fuel Temp. Sensor

PUMP ROM (Injection Pump Correction Unit) Timing Control Valve

*: Only for Europe

N A23892