DIAW7-01

# 5. No navigation displayed, "Audio OFF" on audio screen and no audio sound.

## INSPECTION PROCEDURE

1 Service check mode.

NG

Troubleshoot for each diagnosis.

OK

2 Check the radio receiver assembly.

### PREPARATION:

Disconnect the radio receiver assembly connector.

#### **CHECK:**

Check voltage terminals +B.

<u>OK:</u>

+B: 10 - 14 V

# **CHECK:**

Check voltage terminal ACC when turn ignition switch ACC or ON position.

OK:

ACC: 10 - 14 V

#### **CHECK:**

Check continuity terminal GND.

OK:

**GND: Continuity** 

NG

Replace or repair wire harness.

OK

3

Check "AVC-LAN communication circuit" (See page DI-1215).

NG Replace the AVC -LAN circuit or radio receiver assembly.

OK

Replace the multi display.