## TROUBLESHOOTING PROBLEM SYMPTOMS TABLE

CI 001 04

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

Symptom	Suspect Area	See page
Clutch grabs/chatters	1. Engine mounting (Loosen)	-
	2. Clutch disc (Runout is excessive)	CL-19
	3. Clutch disc (Oily)	CL-19
	4. Clutch disc (Worn out)	CL-19
	5. Clutch disc torsion rubber Damaged)	CL-19
	6. Clutch disc (Glazed)	CL-19
	7. Diaphragm spring (Out of tip alignment)	CL-21
Clutch pedals-pongy	1. Glutob linee (Airin linee)	_
	2. Mastercyljndercup.(Damaged).	CL-4
	3. Release cylinder cup (Damaged)	CL-9
Clutch noisy,	1. Release bearing (Worn, dirty, or damaged)	CL-19
	2. Input shaft bearing (Worn or damaged)	MT-28
	, ,	MT-18
	3. Clutch disc torsion rubber (Damaged)	CL-19
Clutch slips	1. Clutch: pedal (Freeplay out of adjustment)	CL-2
	2. Clutch disc. (Oily)	CL-19
	3. Clutch disc. (Worn out.)	CL-19
	4Diaphragmspring(Damaged),	CL-19
	5. Pressure.plate (Distortion),	CL-19
	6. Flywheel (Distortion)	CL-19
Cīùtċh dòes not disengage	Clutch pedal (Freeplay out of adjustment)	CL-2
	2. Clutch linue (Air im linue	_
	3. Master cup (Damaged)	CL-4
	4. Release cylinder cup (Damaged)	CL-9
	5. nput shaft bearing (Worn or damaged)	MT-28
		MT-18
	6. Clutch disc (Out of true)	CL-19
	7. Crutch disc'(Runtou is excessive)	CL-19
	8. Cfutchdisc (Lihing broken)	CL-19
	9. Clutch disc (Dirty or burned)	CL-19
	10.Clutch disc (Oily)	CL-19
	11. Clutch disc. (Lack o spline grease	CL-19
	12.Diaphragm spring (Qamaged).	CL-19
	13.Diaphragm spring (Out of tip alignment)	CL-19
	14.Pressure plate (Distortion)	CL-19