DIAS7-01

DTC C1516 / 16 VGRS Actuator Neutral Position Incomplete

CIRCUIT DESCRIPTION

This code is set when the VGRS system calibration procedure does not complete normally.

DTC No.	DTC Detecting Condition	Trouble Area
C1516/16		VGRS actuator VGRS ECU

INSPECTION PROCEDURE

1 Clear DTC (See page DI-348).

NEXT

2 Perform VGRS system calibration (See page DI-357).

NEXT

3 ls DTCC 1516/16 output?

NO

VGRS system calibration is completed.

YES

4 Is DTC C 1532/32 output?

YES

Replace VGRS ECU.

NO

Proceed to step 5.

5 Is DTCC 1516/16 output after 3 or more attempts?

YES Replace VGRS actuator.

NO

Goto step 1