AUTOMATIC TRANSMISSION (A750F for 2UZ -FE) HOW TO PROCEED WITH TROUBLESHOOTING

DIAUB-0

When using hand -held tester, troubleshoot in accordance with the procedure on the following pages. Vehicle Brought to Workshop Items inside are titles of pages in this manual, with the page number indicated in the bottom portion. See the indicated pages for detailed explanations. Customer Problem Analysis P. DI-3 Connect the hand -held tester to DLC3. If the display shows "UNABLE TO CONNECT TO VEHICLE" when you have connected the hand-held tester, inspect DLC3 P. DI-4 Check DTC and Freeze Frame Data (Precheck) Record or Print DTC and Freeze Frame Data P DI-4 Clear DTC and Freeze Frame Data P. DI-4 5 // Visual Inspection // Setting the Check Mode Diagnosis P. DI-4 Symptom does not occur Symptom Simulation 7 / Problem Symptom Confirmation P. IN-27 Symptom occur 11 **OK Code** DTC Check Basic Inspection/ P. DI-4 P. DI-4 OK NG DTC Chart Mechanical System Test P. DI-4 13 OK NG OK Manual Shifting Test P. DI-4 14 Problem Symptoms Table-P. DI-26 Chapter 3 NG Chapter 1 Chapter 2 OK OK (Off-Vehicle) (Electronic) (On-Vehicle) P. DI-26 P. DI-26 NG NG 16 / Parts Inspection/ 15 • Pattern Select Switch Circuit Check Circuit A/T.P. Indicator Circuit Check Inspection P. DI-89 to DI-97 Identification of Problem Repair Confirmation Test

When using hand -held tester, troubleshoot in accordance with the procedure on the following pages.

