HEADLIGHT BEAM LEVEL CONTROL SYSTEM
LOCATION

BE0XJ–01

Engine Room Junction Block
□ H–LP R LWR Fuse

Headlight Beam Level Control Actuator

LHD Models

Headlight Beam Level Control Switch

RHD Models

Headlight Beam Level Control Switch

I07260