



#### Foot Assembly:


- Build both the left and right foot assemblies as shown.
- If Nut is difficult to start, try using the screw to pull it in without the pulley to get it into the pocket.
   Tighten the screw firmly, then back it off about 1/4 turn. Pulley
- Tighten the screw firmly, then back it off about 1/4 turn. Pulley will bind if too tight. It is best to use a locking nut since it cannot be fully tightened.



### Tailblock Assembly:

- Tighten the screws firmly, then back off about 1/4 turn. Pulley will bind if too tight. It is best to use a locking nut since it cannot be fully tightened. Make sure they turn smoothly.







# Carriage Assembly:

- Press bearings into carriage block


- Screw on remaining parts.
  Be sure smooth idler pulley turn freely
  Align GT2 pulley with assmebled smooth idler pulleys





# Bearing Rod Installation:

- Test fit rods into the end pieces. Fit should be tight and not wiggle. Belt will keep all the pieces together.
- Install 2 rods into one the foot assemlies. Slide them through the bearings in the middle carriage and attach the other foot.
- Install 2 rods into the tail block assembly. Slide them through the bearings in the midle carriage and attach the head block.



#### Belt Installation

- Use a long piece of GT2 belt
- Start on one end with belt flush with the front of the headblock. Slide it into the belt retaining slot.
- Thread the belt through the pulleys as shown.
- Pull the belt tight and slide it into the other headblock slot.
- Trim the belt. Left about 12mm exposed on one side. This will allow you to reinstall the belt if required.

