srsran::srs cu cp:: common_ue_manager

- + ~common_ue_manager()
- + get ue config()
- + get_ue_index()
- + add_ue()
- + remove_ue()
- + get nof ues()

srsran::srs cu cp:: du processor ue manager

- + ~du processor ue manager()
- + find ue()
- + set ue du context()
- + find du ue()
- + get nof du ues()

srsran::srs cu cp:: ngap ue manager

- + ~ngap ue manager()
- + set ue ng context()
- + find ngap ue()
- + get_nof_ngap_ues()

srsran::srs cu cp:: ue metrics handler

- + ~ue metrics handler()
- + handle ue metrics report _request()

srsran::srs_cu_cp:: ue manager

- + ue manager()
- + stop()
- + get ue config()
- + get ue index()
- + remove ue()
- + get_nof_ues()
- + add ue()
- + find ue()
- + set ue du context()
- + find du ue()

and 9 more...