srsran::srs_cu_up:: elap_connection_client

+ ~elap connection client()

+ handle_cu_up_connection _request()

- srsran::srs_cu_up::
 elap_connection_manager
- + ~elap_connection_manager()
- + connect_to_cu_cp()
 + handle_cu_up_e1_setup
 _request()

+elap_conn_client / +elap_conn_mng

srsran::srs_cu_up:: elap_config_params