PC = 0x3013

#### What Does This Instruction Do?

#### **Starting Processor State**

NZP = 010

**Register File:** 

**R0** = 0x0007 **R4** = 0xFFFE

**R1** = 0x0010 **R5** = 0x0002


R2 = 0x0005 R6 = 0xFFFF


**R3** = 0x0001 **R7** = 0x0008


IR = 0001 0000 1000 0100

IR = 0101 0010 0011 1111

# What Is The Instruction?








### **Sign-Extension Hardware**

Design the hardware to sign-extend a 3-bit 2's-complement number (K) to 5 bits (M)



# **Programming**

Create a program to perform R4 ← R3 × 10<sub>10</sub>

Version 1 Version 2