
## **Operating Manual**

Room-Quality-Station



1




2




Plug-in power supply.

Press black button to turn it on.

3



4



Press white button to switch in

between Room-Quality

measurements.

Press black button to shut it down.