

Nordvik DW-450 Dishwasher - User Manual

Installation

Connect the inlet hose to a cold water tap. Make sure the drain hose is not kinked.

Everyday use

Load plates facing the centre. Use the Eco programme for normally soiled dishes.

Warranty

The warranty period is 24 months from the date of purchase and covers manufacturing defects. Keep your receipt. The warranty does not cover damage from limescale; descale every three months in hard water areas.

Error codes

E1 - water inlet problem. E4 - leak detected; turn off the water supply and contact service.