

Nordvik DW-450 Dishwasher - User Manual

Safety

Read this manual before using the appliance. Keep children away from the appliance while it is running. Disconnect the power before cleaning or maintenance. Do not use the appliance if the power cable is damaged; it must be replaced by Nordvik service.

Installation

Connect the inlet hose to a cold water tap. Make sure the drain hose is not kinked and that its highest point is between 40 and 90 cm above the floor.

Everyday use

Load plates facing the centre and glasses in the upper basket. Use the Eco programme for normally soiled dishes; it takes 3 hours 50 minutes but uses the least water and energy. The Quick 30 programme is for lightly soiled dishes only.

Care and maintenance

Clean the filter at the bottom of the tub once a week. Refill rinse aid when the indicator lights up. In hard water areas, set the water softener to level 5 and use dishwasher salt.

Warranty

The warranty period is 24 months from the date of purchase and covers manufacturing defects. The warranty does not cover damage from limescale; descale every three months in hard water areas. The warranty is valid in the country of purchase. Keep your receipt as proof of the purchase date. Register your appliance at nordvik-home.example/register within 60 days to get an extra year of parts cover.

Error codes

E1 - water inlet problem: check that the tap is open and the hose is not kinked. E4 - leak detected: turn off the water supply and contact service. E9 - the door is not closed properly.

Service

Nordvik customer service: +46 8 555 019 40, weekdays 08:00-17:00. Have the model and serial number ready; they are on the label inside the door.