

Nordvik WM-720 Washing Machine - User Manual

Safety

Read this manual before using the appliance. Keep children away from the appliance while it is running. Disconnect the power before cleaning or maintenance. Do not use the appliance if the power cable is damaged; it must be replaced by Nordvik service.

Installation

Remove the four transport bolts from the back before first use and keep them for moving. Level the machine with the adjustable feet; it must not rock.

Everyday use

Sort laundry by colour and fabric. The 40-60 programme washes mixed cotton at the stated temperature with the lowest energy use. Do not load more than 9 kg of dry laundry. Wool should be washed on the Wool programme at 30 degrees and 800 rpm.

Care and maintenance

Clean the drain pump filter behind the small hatch at the bottom right every two months; a cloth on the floor catches the water. Run an empty 90 degree wash once a month to keep the drum fresh.

Warranty

The warranty period is 24 months from the date of purchase for all parts, and 10 years for the inverter motor. It covers manufacturing defects. The warranty is valid in the country of purchase. Keep your receipt as proof of the purchase date. Register your appliance at nordvik-home.example/register within 60 days to get an extra year of parts cover.

Error codes

F05 - the water does not drain: clean the drain pump filter. F12 - the door lock does not engage: close the door firmly and restart. F21 - unbalanced load: spread out the laundry.

Service

Nordvik customer service: +46 8 555 019 40, weekdays 08:00-17:00. Have the model and serial number ready; they are on the label inside the door.