

Ilma HP-12 Air-to-Air Heat Pump - User Guide

Operating modes

Heat, cool, dry and fan. In heat mode the outdoor unit works down to minus 25 degrees. Below minus 15 degrees the heating capacity drops; keep a backup heater for very cold nights.

Defrosting

In cold, humid weather the outdoor unit collects ice. The pump defrosts automatically for 5 to 10 minutes; the indoor fan stops and a white cloud of steam from the outdoor unit is normal.

Filters

Vacuum the indoor filters every month during the heating season. A dirty filter can increase power use by up to 15%.

Service

Have the heat pump serviced by an authorised installer every two years to keep the warranty valid.

Error codes

A3: outdoor temperature sensor fault. A7: low refrigerant pressure; call the installer.
H1: defrosting (not a fault).

Warranty

5 years on the compressor, 3 years on other parts, from the installation date shown on the installation certificate.