



Free Shipping on Domestic Orders \$75+

Parts

Guides

Troubleshooting

Edit



Appliance > Washing Machine > Samsung Washing Machine > Samsung Washing Machine Error Codes



Samsung Washing Machine Error Codes



Matt Zieminski and 2 contributors

Last updated on August 30, 2024

Introduction

Causes

- 1 [4C, 1 4C, nF, or 4E — Water Supply Error](#)
- 2 [5C, 1 5C, nd, 5E, SE, or SC — Water Drain Error](#)
- 3 [OC, OE, 1OC, 0C, 0E, or 1 0C — Overflow Error](#)
- 4 [Ub, UE, Ur, U6, dc*, 1 Ub, or 1U6 — Unbalance Error](#)
- 5 [HC, HE, HE1, Hr, or 1 HC — Water Heater Error](#)
- 6 [1C, 1E, LE, LC, LC1, 1 1C, or 1 LC — Water Level or Leakage Error](#)
- 7 [4C2, 4E2, CE, 14C2, or nF1 — Abnormal Water Temperature Error](#)
- 8 [tC1 - Thermistor Error](#)
- 9 [3C, 3E, E3, or 1 3C - Motor Restriction Error](#)
- 10 [FC, 9C1, 9C2, PF, 3E, 2E, 9E1, 9E2, UC, 19C1, or 19C2 - Voltage Error](#)

Additional Resources

Related Problems

Introduction

Safety First! Before you begin, remember that safety is paramount. Always unplug your washing machine before attempting any repairs or diagnostics. This precaution is crucial to prevent electric shock or damage to your appliance.

Understanding Your Washing Machine: This guide covers various problems, from water inlet problems to drying challenges or unexpected leaks. We've broken down each problem into three key sections:

- **Problem:** Identifies the specific issue you're experiencing.
- **Why It Happens:** Provides a brief explanation of potential causes.
- **How to Fix:** Offers step-by-step solutions to resolve the issue.

Ready to Solve the Issue? With this guide in hand, you're well-equipped to handle washing machine issues with ease. Let's dive in and get your washing machine running smoothly!

MACHINE ISSUES WITH EASE. LET'S DIVE IN AND GET YOUR WASHING MACHINE RUNNING SMOOTHLY AGAIN!

Causes

1 4C, 1 4C, nF, or 4E — Water Supply Error

Why It Happens?

The washer isn't getting enough water or the water level isn't changing as expected.

How to Fix

- Ensure your water supply is turned on and the hose isn't kinked.
- Restart the washer by turning it off and on.

2 5C, 1 5C, nd, 5E, SE, or SC — Water Drain Error

Why It Happens?

The washer is having trouble draining water.

How to Fix

- Check for blockages in the drain hose and filter.
- Restart your washer to reset the system.

3 OC, OE, 1OC, 0C, 0E, or 1 0C — Overflow Error

Why It Happens?

Too much water in the washer.

How to Fix

- Reduce the load size and ensure the detergent amount is correct.
- Reset the washer by turning it off and on.

4 UB, UE, UR, Ub, ac~, 1 UB, or 1Ub — Unbalance Error

Why It Happens?

The laundry load is uneven or too small.

How to Fix

- Adjust the load to balance it, or add more items.
- Reset the washer to clear the error.

5 HC, HE, HE1, Hr, or 1 HC — Water Heater Error

Why It Happens?

The water temperature is changing unexpectedly.

How to Fix

- Check the water heater settings
- Reset the washer to clear the error.

6 1C, 1E, LE, LC, LC1, 1 1C, or 1 LC — Water Level or Leakage Error

Why It Happens?

An issue with the water level sensor, or there is a leakage in the washer.

7 4C2, 4E2, CE, 14C2, or nF1 — Abnormal Water Temperature Error

Why It Happens?

The water temperature is not suitable for the selected cycle.

8 tC1 - Thermistor Error



Why It Happens:

A problem with the temperature sensor.

9 3C, 3E, E3, or 1 3C - Motor Restriction Error

Why It Happens?

The motor is having difficulty moving. Check your manual to determine whether code 3E is a voltage error or motor error.

10 FC, 9C1, 9C2, PF, 3E, 2E, 9E1, 9E2, UC, 19C1, or 19C2 - Voltage Error

Why It Happens?

The voltage supply is invalid. Check your manual to determine whether code 3E is a voltage error or motor error.

You're seeing solutions for **Samsung Washing Machine**. Select your model to find parts for your device.

[Select my model](#)

Related Problems



Samsung Washing Machine

[Samsung Washer SC Code](#)



Washing Machine

[Washing Machine Shaking](#)



Washing Machine

[Washing Machine Not Spinning](#)



Washing Machine



[Washing Machine Not Draining](#)



Washing Machine

[Washing Machine Won't Turn On](#)



Washing Machine

[Washing Machine Troubleshooting](#)



Samsung Washing Machine

10 common problems

[View all](#)

Haven't found the solution to your problem?

[Browse our forum](#)

[View statistics:](#)

Past 24 Hours:

13

82

Past 30 Days:

295

4,647

Past 7 Days:

All Time:

iFixit

[About us](#)

[Customer Support](#)

[Discuss iFixit](#)

[Careers](#)

[API](#)

Resources

[Community](#)

[Pro Wholesale](#)

[Retail Locator](#)

[For Manufacturers](#)

[Press](#)

[News](#)

Legal

[Accessibility](#)

[Privacy](#)

[Terms](#)

[Cookie Consent](#)

[Download the app
Stay in the loop](#)



try month!

Enter your email

[Subscribe](#)



[Help translate](#)



Licensed under Creative Commons

© 2025 iFixit