

Samsung WA5471ABP/XAA

4. Spin Problems — Detailed Troubleshooting Manual

This document contains 6 separate troubleshooting topics. Each topic starts on a new page and is written as a sequential procedure. User-level checks are separated from service-level diagnosis.

Model basis: Samsung's WA5471ABP/XAA support page lists the model-specific User Manual (version 4, modified May 3, 2016). The technical information for the WA5471 series documents troubleshooting areas including water valves, inlet screens, hoses, water level sensing, drain/spin, motor, PCB connections, and related service diagnosis. ■cite■turn0search1■turn0search13■

4.1. Washer does not spin

What this means: Washer does not spin is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Stop the cycle and wait until the washer is safe to open.

Step 2. Open the washer and inspect the load. Separate items that have become tightly wrapped together or have collected on one side.

Step 3. Redistribute the laundry evenly around the tub. Avoid washing one very heavy item by itself when the selected cycle requires a balanced load.

Step 4. Confirm that the washer is standing level and that all feet are firmly contacting the floor.

Step 5. Close the washer and run the spin operation again. Observe whether the tub accelerates smoothly.

Step 6. If the washer repeatedly stops, remains at a very low spin speed, or leaves the clothes unusually wet, check for a drainage problem because the washer may not enter full spin until water has drained.

Step 7. If abnormal behavior continues with a balanced load and a properly leveled machine, service diagnosis may be required.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

4.2. Clothes remain excessively wet

What this means: Clothes remain excessively wet is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Stop the cycle and wait until the washer is safe to open.

Step 2. Open the washer and inspect the load. Separate items that have become tightly wrapped together or have collected on one side.

Step 3. Redistribute the laundry evenly around the tub. Avoid washing one very heavy item by itself when the selected cycle requires a balanced load.

Step 4. Confirm that the washer is standing level and that all feet are firmly contacting the floor.

Step 5. Close the washer and run the spin operation again. Observe whether the tub accelerates smoothly.

Step 6. If the washer repeatedly stops, remains at a very low spin speed, or leaves the clothes unusually wet, check for a drainage problem because the washer may not enter full spin until water has drained.

Step 7. If abnormal behavior continues with a balanced load and a properly leveled machine, service diagnosis may be required.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

4.3. Spin cycle stops

What this means: Spin cycle stops is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Stop the cycle and wait until the washer is safe to open.

Step 2. Open the washer and inspect the load. Separate items that have become tightly wrapped together or have collected on one side.

Step 3. Redistribute the laundry evenly around the tub. Avoid washing one very heavy item by itself when the selected cycle requires a balanced load.

Step 4. Confirm that the washer is standing level and that all feet are firmly contacting the floor.

Step 5. Close the washer and run the spin operation again. Observe whether the tub accelerates smoothly.

Step 6. If the washer repeatedly stops, remains at a very low spin speed, or leaves the clothes unusually wet, check for a drainage problem because the washer may not enter full spin until water has drained.

Step 7. If abnormal behavior continues with a balanced load and a properly leveled machine, service diagnosis may be required.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

4.4. Washer refuses to spin because of unbalanced load

What this means: Washer refuses to spin because of unbalanced load is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Stop the cycle and wait until the washer is safe to open.

Step 2. Open the washer and inspect the load. Separate items that have become tightly wrapped together or have collected on one side.

Step 3. Redistribute the laundry evenly around the tub. Avoid washing one very heavy item by itself when the selected cycle requires a balanced load.

Step 4. Confirm that the washer is standing level and that all feet are firmly contacting the floor.

Step 5. Close the washer and run the spin operation again. Observe whether the tub accelerates smoothly.

Step 6. If the washer repeatedly stops, remains at a very low spin speed, or leaves the clothes unusually wet, check for a drainage problem because the washer may not enter full spin until water has drained.

Step 7. If abnormal behavior continues with a balanced load and a properly leveled machine, service diagnosis may be required.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

4.5. Spin speed is unexpectedly low

What this means: Spin speed is unexpectedly low is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Stop the cycle and wait until the washer is safe to open.

Step 2. Open the washer and inspect the load. Separate items that have become tightly wrapped together or have collected on one side.

Step 3. Redistribute the laundry evenly around the tub. Avoid washing one very heavy item by itself when the selected cycle requires a balanced load.

Step 4. Confirm that the washer is standing level and that all feet are firmly contacting the floor.

Step 5. Close the washer and run the spin operation again. Observe whether the tub accelerates smoothly.

Step 6. If the washer repeatedly stops, remains at a very low spin speed, or leaves the clothes unusually wet, check for a drainage problem because the washer may not enter full spin until water has drained.

Step 7. If abnormal behavior continues with a balanced load and a properly leveled machine, service diagnosis may be required.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

4.6. Excessive movement during spin

What this means: Excessive movement during spin is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Stop the cycle and wait until the washer is safe to open.

Step 2. Open the washer and inspect the load. Separate items that have become tightly wrapped together or have collected on one side.

Step 3. Redistribute the laundry evenly around the tub. Avoid washing one very heavy item by itself when the selected cycle requires a balanced load.

Step 4. Confirm that the washer is standing level and that all feet are firmly contacting the floor.

Step 5. Close the washer and run the spin operation again. Observe whether the tub accelerates smoothly.

Step 6. If the washer repeatedly stops, remains at a very low spin speed, or leaves the clothes unusually wet, check for a drainage problem because the washer may not enter full spin until water has drained.

Step 7. If abnormal behavior continues with a balanced load and a properly leveled machine, service diagnosis may be required.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.