

Samsung WA5471ABP/XAA

10. Control / Display Problems — Detailed Troubleshooting Manual

This document contains 8 separate troubleshooting topics. Each topic starts on a new page and is written as a sequential procedure. User-level checks are separated from service-level diagnosis.

Model basis: Samsung's WA5471ABP/XAA support page lists the model-specific User Manual (version 4, modified May 3, 2016). The technical information for the WA5471 series documents troubleshooting areas including water valves, inlet screens, hoses, water level sensing, drain/spin, motor, PCB connections, and related service diagnosis. ■cite■turn0search1■turn0search13■

10.1. Buttons do not respond

What this means: Buttons do not respond is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Press the Power button and observe whether the display and control panel respond normally.

Step 2. Check whether Child Lock is active. On this model, Child Lock can prevent normal operation of the other buttons.

Step 3. Press the affected control once and observe whether the correct indicator or display response appears. Do not repeatedly force or press a button that feels physically stuck.

Step 4. If the display shows an information/error code, record the exact code and do not guess at its meaning.

Step 5. If the problem is intermittent, note when it occurs and which buttons, cycle, or operation were active at the time.

Step 6. Do not remove the control panel or attempt live electrical measurements unless you are a qualified technician.

Step 7. If the controls remain unresponsive, behave unpredictably, or show a recurring electrical/control fault, arrange service.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

10.2. Display does not work correctly

What this means: Display does not work correctly is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Press the Power button and observe whether the display and control panel respond normally.

Step 2. Check whether Child Lock is active. On this model, Child Lock can prevent normal operation of the other buttons.

Step 3. Press the affected control once and observe whether the correct indicator or display response appears. Do not repeatedly force or press a button that feels physically stuck.

Step 4. If the display shows an information/error code, record the exact code and do not guess at its meaning.

Step 5. If the problem is intermittent, note when it occurs and which buttons, cycle, or operation were active at the time.

Step 6. Do not remove the control panel or attempt live electrical measurements unless you are a qualified technician.

Step 7. If the controls remain unresponsive, behave unpredictably, or show a recurring electrical/control fault, arrange service.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

10.3. Incorrect cycle behavior

What this means: Incorrect cycle behavior is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Turn the washer off and identify exactly what the washer is doing and at which stage the problem occurs.

Step 2. Check the simplest external causes first: power, water supply, drain path, door/lid, load balance, and selected cycle.

Step 3. Inspect only accessible parts for obvious damage, obstruction, looseness, or incorrect positioning.

Step 4. Restart the washer only after the external checks are complete and it is safe to do so.

Step 5. Observe whether the problem repeats and record any information/error code exactly as displayed.

Step 6. Do not open internal components or bypass safety devices as a user-level repair.

Step 7. If the condition persists after the external checks, arrange qualified service diagnosis.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

10.4. Washer gets stuck in a cycle

What this means: Washer gets stuck in a cycle is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Turn the washer off and identify exactly what the washer is doing and at which stage the problem occurs.

Step 2. Check the simplest external causes first: power, water supply, drain path, door/lid, load balance, and selected cycle.

Step 3. Inspect only accessible parts for obvious damage, obstruction, looseness, or incorrect positioning.

Step 4. Restart the washer only after the external checks are complete and it is safe to do so.

Step 5. Observe whether the problem repeats and record any information/error code exactly as displayed.

Step 6. Do not open internal components or bypass safety devices as a user-level repair.

Step 7. If the condition persists after the external checks, arrange qualified service diagnosis.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

10.5. Unexpected cycle termination

What this means: Unexpected cycle termination is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Turn the washer off and identify exactly what the washer is doing and at which stage the problem occurs.

Step 2. Check the simplest external causes first: power, water supply, drain path, door/lid, load balance, and selected cycle.

Step 3. Inspect only accessible parts for obvious damage, obstruction, looseness, or incorrect positioning.

Step 4. Restart the washer only after the external checks are complete and it is safe to do so.

Step 5. Observe whether the problem repeats and record any information/error code exactly as displayed.

Step 6. Do not open internal components or bypass safety devices as a user-level repair.

Step 7. If the condition persists after the external checks, arrange qualified service diagnosis.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

10.6. Error/information code displayed

What this means: Error/information code displayed is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Press the Power button and observe whether the display and control panel respond normally.

Step 2. Check whether Child Lock is active. On this model, Child Lock can prevent normal operation of the other buttons.

Step 3. Press the affected control once and observe whether the correct indicator or display response appears. Do not repeatedly force or press a button that feels physically stuck.

Step 4. If the display shows an information/error code, record the exact code and do not guess at its meaning.

Step 5. If the problem is intermittent, note when it occurs and which buttons, cycle, or operation were active at the time.

Step 6. Do not remove the control panel or attempt live electrical measurements unless you are a qualified technician.

Step 7. If the controls remain unresponsive, behave unpredictably, or show a recurring electrical/control fault, arrange service.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

10.7. Control PCB problem

What this means: Control PCB problem is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Press the Power button and observe whether the display and control panel respond normally.

Step 2. Check whether Child Lock is active. On this model, Child Lock can prevent normal operation of the other buttons.

Step 3. Press the affected control once and observe whether the correct indicator or display response appears. Do not repeatedly force or press a button that feels physically stuck.

Step 4. If the display shows an information/error code, record the exact code and do not guess at its meaning.

Step 5. If the problem is intermittent, note when it occurs and which buttons, cycle, or operation were active at the time.

Step 6. Do not remove the control panel or attempt live electrical measurements unless you are a qualified technician.

Step 7. If the controls remain unresponsive, behave unpredictably, or show a recurring electrical/control fault, arrange service.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

10.8. Sensor problem

What this means: Sensor problem is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Turn the washer off and record any information code shown on the display.

Step 2. Check the external conditions associated with the symptom first: water supply, drain path, door/lid, load balance, and hose condition.

Step 3. Restart only after the external checks are complete and the washer is in a safe state.

Step 4. Observe whether the washer repeatedly overfills, underfills, stops waiting for water, or reports the same sensor-related condition.

Step 5. Do not disconnect, bypass, or electrically test internal sensors as a user-level repair.

Step 6. If the symptom repeats with normal water supply and drainage, service diagnosis may be required for the pressure sensor, hose, wiring, PCB, or related components.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.