

Samsung WA5471ABP/XAA

12. Maintenance Problems — Detailed Troubleshooting Manual

This document contains 7 separate troubleshooting topics. Each topic starts on a new page and is written as a sequential procedure. User-level checks are separated from service-level diagnosis.

Model basis: Samsung's WA5471ABP/XAA support page lists the model-specific User Manual (version 4, modified May 3, 2016). The technical information for the WA5471 series documents troubleshooting areas including water valves, inlet screens, hoses, water level sensing, drain/spin, motor, PCB connections, and related service diagnosis. ■cite■turn0search1■turn0search13■

12.1. Bad odor from washer

What this means: Bad odor from washer is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Turn the washer off and identify exactly what the washer is doing and at which stage the problem occurs.

Step 2. Check the simplest external causes first: power, water supply, drain path, door/lid, load balance, and selected cycle.

Step 3. Inspect only accessible parts for obvious damage, obstruction, looseness, or incorrect positioning.

Step 4. Restart the washer only after the external checks are complete and it is safe to do so.

Step 5. Observe whether the problem repeats and record any information/error code exactly as displayed.

Step 6. Do not open internal components or bypass safety devices as a user-level repair.

Step 7. If the condition persists after the external checks, arrange qualified service diagnosis.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

12.2. Mold/mildew buildup

What this means: Mold/mildew buildup is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Turn the washer off and identify exactly what the washer is doing and at which stage the problem occurs.

Step 2. Check the simplest external causes first: power, water supply, drain path, door/lid, load balance, and selected cycle.

Step 3. Inspect only accessible parts for obvious damage, obstruction, looseness, or incorrect positioning.

Step 4. Restart the washer only after the external checks are complete and it is safe to do so.

Step 5. Observe whether the problem repeats and record any information/error code exactly as displayed.

Step 6. Do not open internal components or bypass safety devices as a user-level repair.

Step 7. If the condition persists after the external checks, arrange qualified service diagnosis.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

12.3. Tub needs cleaning

What this means: Tub needs cleaning is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Stop the cycle and identify whether the problem is caused by detergent quantity, detergent type, dispenser buildup, or washing conditions.

Step 2. Check the detergent package instructions and use only the detergent type and quantity appropriate for the washer and load.

Step 3. Inspect the dispenser. Remove visible residue and clean the accessible dispenser components according to the manual.

Step 4. If excessive suds are present, allow the washer to complete its appropriate suds-management/rinse behavior rather than adding more detergent.

Step 5. For poor cleaning, check load size, cycle selection, water supply, and whether heavily soiled items need pretreatment.

Step 6. Run a suitable rinse or cleaning cycle after correcting the detergent issue and observe whether residue or suds remain.

Step 7. If the problem continues despite correct detergent use and a clean dispenser, investigate water supply, cycle selection, and service-level causes.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

12.4. Dispenser buildup

What this means: Dispenser buildup is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Turn the washer off and identify exactly what the washer is doing and at which stage the problem occurs.

Step 2. Check the simplest external causes first: power, water supply, drain path, door/lid, load balance, and selected cycle.

Step 3. Inspect only accessible parts for obvious damage, obstruction, looseness, or incorrect positioning.

Step 4. Restart the washer only after the external checks are complete and it is safe to do so.

Step 5. Observe whether the problem repeats and record any information/error code exactly as displayed.

Step 6. Do not open internal components or bypass safety devices as a user-level repair.

Step 7. If the condition persists after the external checks, arrange qualified service diagnosis.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

12.5. Washer interior needs cleaning

What this means: Washer interior needs cleaning is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Stop the cycle and identify whether the problem is caused by detergent quantity, detergent type, dispenser buildup, or washing conditions.

Step 2. Check the detergent package instructions and use only the detergent type and quantity appropriate for the washer and load.

Step 3. Inspect the dispenser. Remove visible residue and clean the accessible dispenser components according to the manual.

Step 4. If excessive suds are present, allow the washer to complete its appropriate suds-management/rinse behavior rather than adding more detergent.

Step 5. For poor cleaning, check load size, cycle selection, water supply, and whether heavily soiled items need pretreatment.

Step 6. Run a suitable rinse or cleaning cycle after correcting the detergent issue and observe whether residue or suds remain.

Step 7. If the problem continues despite correct detergent use and a clean dispenser, investigate water supply, cycle selection, and service-level causes.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

12.6. Water inlet screens need cleaning

What this means: Water inlet screens need cleaning is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Turn the washer off using the Power button and wait until the controls are no longer active before inspecting external water connections.

Step 2. Confirm that the household water supply is available. Open the appropriate water faucet fully and check that water can flow normally.

Step 3. Inspect the hot and cold inlet hoses along their full visible length. Make sure neither hose is sharply bent, crushed, twisted, or trapped against the washer.

Step 4. Check both hose connections at the washer and at the water supply. Each connection should be seated correctly and should not show leakage.

Step 5. If the problem involves slow or no filling, inspect the inlet screens at the hose connections for visible dirt or sediment. Clean only the accessible screens using the procedure recommended by the manual; do not damage or remove internal components.

Step 6. Reconnect the hoses securely, restore the water supply, and run a short test cycle. Observe whether water enters normally.

Step 7. If the washer still has a fill problem after the external checks, the cause may involve the water valve, pressure sensing system, wiring, or control board. These are service-level checks and should not be opened or tested as a DIY repair.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

12.7. Washer not maintained regularly

What this means: Washer not maintained regularly is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Turn the washer off and identify exactly what the washer is doing and at which stage the problem occurs.

Step 2. Check the simplest external causes first: power, water supply, drain path, door/lid, load balance, and selected cycle.

Step 3. Inspect only accessible parts for obvious damage, obstruction, looseness, or incorrect positioning.

Step 4. Restart the washer only after the external checks are complete and it is safe to do so.

Step 5. Observe whether the problem repeats and record any information/error code exactly as displayed.

Step 6. Do not open internal components or bypass safety devices as a user-level repair.

Step 7. If the condition persists after the external checks, arrange qualified service diagnosis.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.