

Samsung WA5471ABP/XAA

14. Water-Level / Pressure Sensor Problems — Detailed Troubleshooting Manual

This document contains 6 separate troubleshooting topics. Each topic starts on a new page and is written as a sequential procedure. User-level checks are separated from service-level diagnosis.

Model basis: Samsung's WA5471ABP/XAA support page lists the model-specific User Manual (version 4, modified May 3, 2016). The technical information for the WA5471 series documents troubleshooting areas including water valves, inlet screens, hoses, water level sensing, drain/spin, motor, PCB connections, and related service diagnosis. ■cite■turn0search1■turn0search13■

14.1. Incorrect water level detected

What this means: Incorrect water level detected is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Stop the washer and wait until the tub has stopped moving completely.

Step 2. Inspect the floor beneath and around the washer. The washer should stand on a solid, stable surface and should not rock when gently checked.

Step 3. Check each leveling foot and make sure the washer is stable. If leveling is required, follow the model's installation/leveling procedure rather than forcing the cabinet.

Step 4. Open the washer and redistribute the load if clothing has collected on one side.

Step 5. Run the washer again and listen carefully. Separate normal operating sounds from a new scraping, grinding, banging, or repeated metallic sound.

Step 6. If the noise appears only with a particular load, remove the load and inspect pockets, garments, and the tub area for loose objects.

Step 7. If abnormal noise or vibration continues with a balanced load and a stable, level washer, stop using the machine and arrange service.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

14.2. Washer overfills

What this means: Washer overfills is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Turn the washer off and identify exactly what the washer is doing and at which stage the problem occurs.

Step 2. Check the simplest external causes first: power, water supply, drain path, door/lid, load balance, and selected cycle.

Step 3. Inspect only accessible parts for obvious damage, obstruction, looseness, or incorrect positioning.

Step 4. Restart the washer only after the external checks are complete and it is safe to do so.

Step 5. Observe whether the problem repeats and record any information/error code exactly as displayed.

Step 6. Do not open internal components or bypass safety devices as a user-level repair.

Step 7. If the condition persists after the external checks, arrange qualified service diagnosis.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

14.3. Washer underfills

What this means: Washer underfills is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Turn the washer off and identify exactly what the washer is doing and at which stage the problem occurs.

Step 2. Check the simplest external causes first: power, water supply, drain path, door/lid, load balance, and selected cycle.

Step 3. Inspect only accessible parts for obvious damage, obstruction, looseness, or incorrect positioning.

Step 4. Restart the washer only after the external checks are complete and it is safe to do so.

Step 5. Observe whether the problem repeats and record any information/error code exactly as displayed.

Step 6. Do not open internal components or bypass safety devices as a user-level repair.

Step 7. If the condition persists after the external checks, arrange qualified service diagnosis.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

14.4. Water-level sensor failure

What this means: Water-level sensor failure is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Stop the washer and wait until the tub has stopped moving completely.

Step 2. Inspect the floor beneath and around the washer. The washer should stand on a solid, stable surface and should not rock when gently checked.

Step 3. Check each leveling foot and make sure the washer is stable. If leveling is required, follow the model's installation/leveling procedure rather than forcing the cabinet.

Step 4. Open the washer and redistribute the load if clothing has collected on one side.

Step 5. Run the washer again and listen carefully. Separate normal operating sounds from a new scraping, grinding, banging, or repeated metallic sound.

Step 6. If the noise appears only with a particular load, remove the load and inspect pockets, garments, and the tub area for loose objects.

Step 7. If abnormal noise or vibration continues with a balanced load and a stable, level washer, stop using the machine and arrange service.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

14.5. Washer keeps filling

What this means: Washer keeps filling is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Turn the washer off and identify exactly what the washer is doing and at which stage the problem occurs.

Step 2. Check the simplest external causes first: power, water supply, drain path, door/lid, load balance, and selected cycle.

Step 3. Inspect only accessible parts for obvious damage, obstruction, looseness, or incorrect positioning.

Step 4. Restart the washer only after the external checks are complete and it is safe to do so.

Step 5. Observe whether the problem repeats and record any information/error code exactly as displayed.

Step 6. Do not open internal components or bypass safety devices as a user-level repair.

Step 7. If the condition persists after the external checks, arrange qualified service diagnosis.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.

14.6. Washer stops because required water level isn't reached

What this means: Washer stops because required water level isn't reached is treated as the observed symptom or fault condition. Follow the steps in order and stop when the cause is identified.

Step-by-step procedure

Step 1. Stop the washer and wait until the tub has stopped moving completely.

Step 2. Inspect the floor beneath and around the washer. The washer should stand on a solid, stable surface and should not rock when gently checked.

Step 3. Check each leveling foot and make sure the washer is stable. If leveling is required, follow the model's installation/leveling procedure rather than forcing the cabinet.

Step 4. Open the washer and redistribute the load if clothing has collected on one side.

Step 5. Run the washer again and listen carefully. Separate normal operating sounds from a new scraping, grinding, banging, or repeated metallic sound.

Step 6. If the noise appears only with a particular load, remove the load and inspect pockets, garments, and the tub area for loose objects.

Step 7. If abnormal noise or vibration continues with a balanced load and a stable, level washer, stop using the machine and arrange service.

When to escalate: If the problem remains after the safe external checks, or if the washer shows repeated electrical, sensor, control, motor, valve, pump, or lock faults, stop user troubleshooting and arrange qualified service.