

HP Proliant DL360 Gen9										ESX01
PCI-E Intel		PCI-E Intel		Broadcom Onboard						
PCI-E Intel		1C	1D							
1A	1B	vmnic6	vmnic7	ILO					1H	
vmnic5	vmnic4				vmnic0	vmnic1	vmnic2	vmnic3		

vmnic4	10.0.123.231 + 10.9.0.010 - Mgmt & vMotion	[To Procurve - Back]
vmnic5	10.3.0.10 - iSCSI-HF20-A	[To Procurve - Back]
vmnic6	10.0.123.231 + 10.9.0.010 - Mgmt & vMotion	[To Procurve - Back]
vmnic7	10.3.0.11 - iSCSI-HF20-B	[To Procurve - Back]
vmnic0	Not connected	
vmnic1	Not connected	
vmnic2	Not connected	
vmnic3	Not connected	

HP Proliant DL360 Gen9										ESX03
PCI-E Intel		PCI-E Intel		Broadcom Onboard						
PCI-E Intel		3C	3D							
3A	3B	vmnic6	vmnic7	ILO						
vmnic5	vmnic4				vmnic0	vmnic1	vmnic2	vmnic3		

vmnic4	10.0.123.233 + 10.9.0.030 - Mgmt & vMotion	[To Procurve - Back]
vmnic5	10.3.0.30 - iSCSI-HF20-A	[To Procurve - Back]
vmnic6	10.0.123.233 + 10.9.0.030 - Mgmt & vMotion	[To Procurve - Back]
vmnic7	10.3.0.31 - iSCSI-HF20-B	[To Procurve - Back]
vmnic0	Not connected	[To Dell PowerConnect]
vmnic1	Not connected	
vmnic2	Not connected	
vmnic3	Not connected	

HP Proliant DL360 Gen9										ESX05
PCI-E Intel		PCI-E Intel		Broadcom Onboard						
PCI-E Intel		5C	5D							
5A	5B	vmnic6	vmnic7	ILO						
vmnic5	vmnic4				vmnic0	vmnic1	vmnic2	vmnic3		

vmnic4	10.0.123.235 + 10.9.0.050 - Mgmt & vMotion	[To Procurve - Back]
vmnic5	10.3.0.50 - iSCSI-HF20-A	[To Procurve - Back]
vmnic6	10.0.123.235 + 10.9.0.050 - Mgmt & vMotion	[To Procurve - Back]
vmnic7	10.3.0.51 - iSCSI-HF20-B	[To Procurve - Back]
vmnic0	Not connected	
vmnic1	Not connected	
vmnic2	Not connected	
vmnic3	Not connected	

HP Proliant DL360 Gen9										ESX07
PCI-E Intel		PCI-E Intel		Broadcom Onboard						
PCI-E Intel		7C	7D							
7A	7B	vmnic6	vmnic7	ILO			7G			
vmnic5	vmnic4				vmnic0	vmnic1	vmnic2	vmnic3		

vmnic4	10.0.123.230 + 10.9.0.070 - Mgmt & vMotion	[To Procurve - Back]
vmnic5	10.3.0.70 - iSCSI-HF20-A	[To Procurve - Back]
vmnic6	10.0.123.230 + 10.9.0.070 - Mgmt & vMotion	[To Procurve - Back]
vmnic7	10.3.0.71 - iSCSI-HF20-B	[To Procurve - Back]
vmnic0	Not connected	
vmnic1	Not connected	
vmnic2	192.168.100.0 - DMZ	
vmnic3	Not connected	

HP Proliant DL360 Gen9										ESX02
PCI-E Intel		PCI-E Intel		Broadcom Onboard						
PCI-E Intel		2C	2D							
2A	2B	vmnic6	vmnic7	ILO						
vmnic5	vmnic4				vmnic0	vmnic1	vmnic2	vmnic3		

vmnic4	10.0.123.232 + 10.9.0.020 - Mgmt & vMotion	[To Procurve - Back]
vmnic5	10.3.0.20 - iSCSI-HF20-A	[To Procurve - Back]
vmnic6	10.0.123.232 + 10.9.0.020 - Mgmt & vMotion	[To Procurve - Back]
vmnic7	10.3.0.21 - iSCSI-HF20-B	[To Procurve - Back]
vmnic0	Not connected	
vmnic1	Not connected	
vmnic2	Not connected	
vmnic3	Not connected	

HP Proliant DL360 Gen9 [HARDWARE PROBLEM IN MAINTENANCE MODE]										ESX04
PCI-E Intel		PCI-E Intel		Broadcom Onboard						
PCI-E Intel		4C	4D							
4A	4B	vmnic6	vmnic7	ILO						
vmnic5	vmnic4				vmnic0	vmnic1	vmnic2	vmnic3		

vmnic4	10.0.123.234 + 10.9.0.040 - Mgmt & vMotion	[To Procurve - Back]
vmnic5	10.3.0.40 - iSCSI-HF20-A	[To Procurve - Back]
vmnic6	10.0.123.234 + 10.9.0.040 - Mgmt & vMotion	[To Procurve - Back]
vmnic7	10.3.0.41 - iSCSI-HF20-B	[To Procurve - Back]
vmnic0	Not connected	[To Dell PowerConnect]
vmnic1	Not connected	
vmnic2	Not connected	
vmnic3	Not connected	

HP Proliant DL360 Gen9										ESX06
PCI-E Intel		PCI-E Intel		Broadcom Onboard						
PCI-E Intel		6C	6D							
6A	6B	vmnic6	vmnic7	ILO			6G			
vmnic5	vmnic4				vmnic0	vmnic1	vmnic2	vmnic3		

vmnic4	10.0.123.236 + 10.9.0.060 - Mgmt & vMotion	[To Procurve - Back]
vmnic5	10.3.0.60 - iSCSI-HF20-A	[To Procurve - Back]
vmnic6	10.0.123.236 + 10.9.0.060 - Mgmt & vMotion	[To Procurve - Back]
vmnic7	10.3.0.61 - iSCSI-HF20-B	[To Procurve - Back]
vmnic0	Not connected	
vmnic1	Not connected	
vmnic2	192.168.100.0 - DMZ	
vmnic3	Not connected	

HP Switch - Back											
[MODULE B] - HP 24-port 1Gig-T zl Module (J8702A)											
1	3	5	7	9	11	13	15	17	19	21	23
7G											
6G											
2	4	6	8	10	12	14	16	18	20	22	24

HP Procurve - Back											
[MODULE H] - HP 24-port 1Gig-T zl Module (J8702A)											
1	3	5	7	9	11	13	15	17	19	21	23
2	4	6	8	10	12	14	16	18	20	22	24

HP Switch - Back											
[MODULE I] - HP 8-port 10GBASE-T v2 zl Module (J9546A)											
	1	2	3	4	5	6	7	8			
	1B	2B	3B	4B	5B	6B	7B	l-eth3b			
[MODULE K] - HP 8-port 10GBASE-T v2 zl Module (J9546A)											
	1	2	3	4	5	6	7	8			
	1A	2A	3A	l-eth3	5A	6A	7A	l-eth3a			

Nimble physical NIC reference diagrams

NIMBLE CS215				10.3.0.2	10.3.0.3		
	CONTROLLER A				CONTROLLER B		
l-eth2		l-eth3	l-eth4		r-eth2	r-eth3	r-eth4
l-eth1		iSCSI			r-eth1	iSCSI	
Mgmt					Mgmt		

NIMBLE HF20				10.3.0.6	10.3.0.7		
	CONTROLLER A				CONTROLLER B		
l-eth3a	l-eth3b				r-eth3a	r-eth3b	
iSCSI					iSCSI		
		l-eth0a	l-eth0b			r-eth0a	r-eth0b
		Mgmt				Mgmt	

HP Switch - Back											
[MODULE J] - HP 8-port 10GBASE-T v2 zl Module (J9546A)											
	1	2	3	4	5	6	7	8			
	1C	2C	3C	4C	5C	6C	7C	r-eth3b			
[MODULE L] - HP 8-port 10GBASE-T v2 zl Module (J9546A)											
	1	2	3	4	5	6	7	8			
	1D	2D	3C	r-eth3	5D	6D	7D	r-eth3a			

Nimble web user Interface reference diagrams

NIMBLE CS215 UI

CONTROLLER A

● Active

eth3 eth4

SAS Out

eth1 eth2 P1

CONTROLLER B

● Standby

eth3 eth4

SAS Out

eth1 eth2 P1

Make Active

NIMBLE HF20 UI

CONTROLLER A

● Active

eth3a eth3b

SAS Out

eth0a eth0b P1 P2

CONTROLLER B

● Standby

eth3a eth3b

SAS Out

eth0a eth0b P1 P2

Make Active