
## Meter Reading (MR) Interface Chart

(Version 4.1.6 Release, August 31, 2012)



Method	MR-CB	MR-EA	MR-OA	MR- AM	MR- MDM	MR- PPM	MR-EDTR	NOT
AccountChangedNotification	OPT				OPT			OPT
AdjustThresholdMonitoring						REC		
CancelDisconnectedStatus	OPT				OPT	1		
CancelMeterEventMonitoring	REC				REC			
CancelPlannedOutage	OPT				OPT			
CancelThresholdMonitoring						REC		
CancelUsageMonitoring	OPT				OPT			
CustomerChangedNotification	REC				REC			OPT
CustomersAffectedByOutageNotification			OPT		OPT			OPT
DeleteMeterGroup	OPT	OPT	OPT		OPT			
DeleteReadingSchedule	OPT	OPT	OPT		OPT			
DeleteSchedule	OPT	OPT	OPT		OPT			
DisableReadingSchedule	OPT	OPT	OPT		OPT			
EnableReadingSchedules	OPT	OPT	OPT		OPT			
EndDeviceShipmentNotification					OPT		OPT	OPT
EstablishMeterGroup	OPT				OPT			
EstablishReadingSchedules	OPT	OPT	OPT		OPT			
EstablishSchedules	OPT	OPT	OPT		OPT			
GetAMRSupportedMeters	REC	REC			REC			
GetConfigurationGroupMembers	OPT				OPT			
GetConfigurationGroupNames	OPT				OPT			
GetConfigurationGroupNamesByMeterID	OPT				OPT			
GetFormattedBlockTemplates	OPT				OPT			
GetHistoryLogByMeterID	REC	OPT			REC			
GetHistoryLogsByDate	REC	OPT			REC			
GetHistoryLogsByDateAndEventCode	REC	OPT			REC			
GetHistoryLogsByMeterIDAndEventCode	REC	OPT			REC			
GetLatestMeterReadingsByMeterGroup	REC				REC			
GetLatestMeterReadingsByMeterGroupIntervalData	REC				REC			
GetLatestReadingByFieldName		OPT			OPT			
GetLatestReadingByFieldNameIntervalData		OPT			OPT			
GetLatestReadingByMeterID	REC	REC			REC			
GetLatestReadingByMeterIDAndFieldName		REC			REC			
GetLatestReadingByMeterIDAndFieldNameIntervalData		REC			REC			
GetLatestReadings		REC			REC			

GetLatesiReadingsbyMeteriDustinetworData   REC		550	5=0	1	ı	5=0	1		т 1
Gett_attestReadingsByMetericInFormatedBiock	GetLatestReadingsByMeterIDList	REC	REC			REC			
Gett_attestReadingsByMetericInFormatedBiock	GetLatestReadingsByMeterIDListIntervalData	REC	REC			REC			
Gett_Details/beter/							1	-	
Gett Pasadings Bylling Cycle   OPT							-		
Get1   Readings   Sillinia   Cycle   Image		_	OPT						
Get1 Preadings () Detail () Detail () Get1 Preadings () Detail () Detail () Detail () Get1 Preadings () Detail ()	GetLPDataByMeterID	OPT				OPT			
Get1PeadingsByBater	GetLPReadingsRyBillingCycle	OPT				OPT			1
Get.PReadingsByDateIntervalData									+
Get.PReadingsByNeterinDrantateditions									
GetPReadingsByMeterIPFormatedBlock	GetLPReadingsByDateFormattedBlock							ļ	
GetPReadingsByMeterIPFormatedBlock	GetLPReadingsBvDateIntervalData	OPT				OPT			
Gett/PReadings/Meter/Discreta/Data									+
GerReadings/Meter/Dimers/alData	<u> </u>								
Gelfeadingsykleter(Direnze)  Dept   Gelfeadingskykleter(Direnze)  Gelfeadingskykleter(Direnze)  Gelfeadingskykleter(Direnze)  Gelfeadingskykleter(Direnze)  Gelfeadingskykleter(Direnze)  Gelfeadingskykleter(Direnze)  Gelfeadingskybater(Gelf									
Gelfeadingsykleter(Direnze)  Dept   Gelfeadingskykleter(Direnze)  Gelfeadingskykleter(Direnze)  Gelfeadingskykleter(Direnze)  Gelfeadingskykleter(Direnze)  Gelfeadingskykleter(Direnze)  Gelfeadingskykleter(Direnze)  Gelfeadingskybater(Gelf	GetModifiedAMRMeters	OPT	OPT			OPT		ļ	
GetReadingsByBillingCycle									
GetReadingsByBillingCycleIntervalData							-		+
GetReadingsByDate									
GetReadingsByDateAndFieldName	GetReadingsByBillingCycle	OPT				OPT		ļ	
GetReadingsByDateAndFieldName	GetReadingsByBillingCycleIntervalData	OPT				OPT			
GetReadingsByOateAndFieldNameIntervalData			DEC				1		1
GetReadrigsByOateInderwaldData		KLC					1		
GetReadingsByOateIntervalData									
GetReadingsByOateIntervalData	GetReadingsBvDateAndFieldNameIntervalData		OPT			OPT			
GelReadingsByMeterID		REC							
GetReadingsByMeterIDAndFieldName				1	1		<del>                                     </del>		<del>                                     </del>
GetReadingsByMeterIDAndFieldNameIntervalData				1	ļ		ļ		ļl
GetReadingsByMeterIDAndFieldNameIntervalData	GetReadingsByMeterID	REC	REC		1	REC	1	ļ	
GetReadingsByMeterIDAndFieldNameIntervalData   OPT	GetReadingsBvMeterIDAndFieldName				1		1		
GetReadingsByMeteriDListAndFieldNameIntervalData GetReadingsByMeteriDListAndFieldNameIntervalData GetReadingsByMeteriDListAndFieldName GetReadingsByMeteriDListAndFieldName GetReadingsByMeteriD GetReadingsCheduleS GetScheduleSyID GetSchedu		+		1	1		<del>                                     </del>		++
GetReadingSbyUDMAndDate GetReadingScheduleByD GetReadingScheduleS GetScheduleByD		<u> </u>		ļ	<b></b>		<b> </b>		ļ
GetReadingSbyUDMAndDate		REC		<u> </u>	<u>L</u>		<u>                                       </u>		
GetReadingScheduleByID			OPT			OPT		_	
GetReadingSchedules		ODT		ODT	<del> </del>		+ +		+
GetScheduleByID				_	<b> </b>		1		<b></b>
GetSupportedFieldNames	GetReadingSchedules	OPT	OPT	OPT		OPT		ļ	
GetSupportedFieldNames	GetScheduleBvID	OPT	OPT	OPT		OPT			
GetSUpported/FieldNames         REC									
GetSupportedNeadingStatusCodes GetSupportedNeadingStatusCodes OPT InHomeDisplayAddNotification OPT InHomeDisplayAddNotification OPT InHomeDisplayAddNotification OPT InHomeDisplayAddNotification OPT InHomeDisplayAddNotification OPT InHomeDisplayAddNotification OPT InHomeDisplayReadingNotification NeEC Rec OPT MeterBaseAddNotification OPT MeterBaseReadingNotification OPT MeterBaseReadingNotification OPT MeterBaseReadingNotification OPT OPT MeterBaseReadingNotification OPT MeterBaseReadingNotification OPT OPT MeterBaseReadingNotification OPT OPT MeterBaseReadingNotification OPT OPT MeterBaseReadingNotification OPT OPT OPT MeterBaseReadingNotification OPT		OF I		OFT			+		
GetSupportedReadingStatusCodes InHomeDisplayAddNotification InHomeDisplayAddNotification OPT InHomeDisplayAddNotification OPT InHomeDisplayChangedNotification OPT InHomeDisplayExchangeNotification OPT InHomeDisplayExchangeNotification OPT OPT OPT OPT OPT OPT OPT OPT OPT InHomeDisplayRetreNotification OPT									
GetSupportedReadingStatusCodes InHomeDisplayAddNotification InHomeDisplayChangedNotification OPT InHomeDisplayChangedNotification OPT InHomeDisplayChangedNotification OPT InHomeDisplayChangedNotification OPT InHomeDisplayChangedNotification OPT OPT OPT OPT OPT OPT OPT OPT InHomeDisplayRemoveNotification OPT	GetSupportedMeterEventCodes	REC	REC	REC	REC	REC	REC	REC	
InHomeDisplayAddNotification		OPT				OPT			1
InHomeDisplayChangedNotification							+		ODT
InHomeDisplayExchangeNotification									
InHomeDisplayRemoveNotification	InHomeDisplayChangedNotification	OPT						ļ	OPT
InHomeDisplayRemoveNotification	InHomeDisplayExchangeNotification	OPT				OPT			OPT
InHomeDisplayRetireNotification									
InitiateDisconnectedStatus							1		
InitiateDisconnectedStatus	InHomeDisplayRetireNotification								OPT
InitiateDisconnectedStatus	InitiateDemandReset	OPT				OPT		ļ	
InitiateGroupMeterReadingsByMeterIDAndDate REC REC REC InitiateLPMeterReadingsByMeterID OPT OPT OPT InitiateMeterExentMonitoring REC REC REC InitiateMeterExentMonitoring REC REC REC REC InitiateMeterInstallation REC REC REC REC REC REC REC InitiateMeterInstallation REC REC REC REC InitiateMeterInstallation REC REC REC REC InitiateMeterReadingByMeterIDAndFieldName OPT OPT OPT InitiateMeterReadingByMeterIDAndFieldName OPT OPT OPT InitiateMeterReadingsByFieldName OPT OPT InitiateMeterReadingsByFieldName OPT OPT InitiateMeterReadingsByMeterID OPT OPT InitiateJusageMonitoring REC Net									
InitiateHistoricalMeterReadingsByMeterIDAndDate   REC   REC   InitiateLPMeterReadingsByMeterID   OPT   OPT   OPT   InitiateMeterEventMonitoring   REC   REC   REC   InitiateMeterExchange   REC   REC   REC   InitiateMeterExchange   REC   REC   REC   InitiateMeterInstallation   REC   REC   REC   InitiateMeterReadingByMeterIDAndFieldName   OPT   OPT   OPT   OPT   InitiateMeterReadingByObject   OPT   OPT   OPT   OPT   OPT   InitiateMeterReadingsByFieldName   OPT   OPT   OPT   OPT   OPT   InitiateMeterReadingsByMeterID   OPT   OPT   OPT   OPT   InitiateMeterReadingsByMeterID   OPT   OP							+		
InitiateLPMeterReadingsByMeterID									
InitiateLPMeterReadingsByMeterID	InitiateHistoricalMeterReadingsByMeterIDAndDate	REC				REC		ļ	
InitiateMeterEventMonitoring		OPT				OPT			1
InitiateMeterExchange							+		-
InitiateMeterInstallation									
InitiateMeterReadingByMeterIDAndFieldName	InitiateMeterExchange	REC				REC		ļ	
InitiateMeterReadingByMeterIDAndFieldName	InitiateMeterInstallation	REC				REC			
InitiateMeterReadingByObject			OPT						
InitiateMeterReadingsByFieldName							+		
InitiateMeterReadingsByMeterID									
InitiateMeterReadingsByMeterID	InitiateMeterReadingsByFieldName	1	OPT		1	OPT	1	ļ	
InitiatePlannedOutage		OPT							
InitiateThresholdMonitoring				1	<del>                                     </del>		+ +		+
InitiateUsageMonitoring		UPI		1	1	UPI	<del>   </del>		1
InsertMeterInConfigurationGroup				<u> </u>	<u> </u>		REC		<u> </u>
InsertMeterInConfigurationGroup	InitiateUsageMonitoring	OPT	-		1	OPT		<del> </del>	
InsertMeterInMeterGroup       OPT       OPT         IsAMRMeter       REC       REC         MeterAddNotification       REC       REC         MeterBaseAddNotification       OPT       OPT         MeterBaseChangedNotification       OPT       OPT         MeterBaseExchangeNotification       OPT       OPT         MeterBaseRemoveNotification       OPT       OPT         MeterBaseRetireNotification       OPT       OPT         MeterChangedNotification       REC       REC         MeterConnectivityNotification       OPT       OPT         MeterExchangeNotification       OPT       OPT         MeterRemoveNotification       REC       REC         MeterRetireNotification       REC       REC         MeterTestNotification       REC       REC         MeterTestNotification       REC       REC         MeterTestNotification       REC       REC         RemoveMetersFromConfigurationGroup       OPT       OPT	· · · · · · · · · · · · · · · · · · ·	OPT			1		† †		$\vdash$
IsAMRMeter         REC         REC           MeterAddNotification         REC         REC           MeterBaseAddNotification         OPT         OPT           MeterBaseChangedNotification         OPT         OPT           MeterBaseExchangeNotification         OPT         OPT           MeterBaseRemoveNotification         OPT         OPT           MeterBaseRetireNotification         OPT         OPT           MeterChangedNotification         OPT         OPT           MeterConnectivityNotification         REC         REC           MeterExchangeNotification         OPT         OPT           MeterRemoveNotification         REC         REC           MeterRemoveNotification         REC         REC           MeterRetireNotification         REC         REC           MeterTestNotification         REC         REC           MeterTestNotification         REC         REC           Recolor         OPT         OPT           Recolor         OPT         OPT           Recolor         OPT         OPT				1	<del> </del>		+		$\vdash$
MeterAddNotification         REC         REC         OPT           MeterBaseAddNotification         OPT         OPT         OPT           MeterBaseChangedNotification         OPT         OPT         OPT           MeterBaseExchangeNotification         OPT         OPT         OPT           MeterBaseRemoveNotification         OPT         OPT         OPT           MeterBaseRetireNotification         OPT         OPT         OPT           MeterChangedNotification         REC         REC         OPT           MeterConnectivityNotification         OPT         OPT         OPT           MeterExchangeNotification         OPT         OPT         OPT           MeterRemoveNotification         REC         REC         OPT           MeterRetireNotification         REC         REC         OPT           MeterTestNotification         REC         REC         OPT           RetChangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT									
MeterAddNotification         REC         REC         OPT           MeterBaseAddNotification         OPT         OPT         OPT           MeterBaseChangedNotification         OPT         OPT         OPT           MeterBaseExchangeNotification         OPT         OPT         OPT           MeterBaseRemoveNotification         OPT         OPT         OPT           MeterBaseRetireNotification         OPT         OPT         OPT           MeterChangedNotification         REC         REC         OPT           MeterConnectivityNotification         OPT         OPT         OPT           MeterExchangeNotification         OPT         OPT         OPT           MeterRemoveNotification         REC         REC         OPT           MeterRetireNotification         REC         REC         OPT           MeterTestNotification         REC         REC         OPT           RetChangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT	IsAMRMeter	REC				REC	1	ļ	
MeterBaseAddNotification         OPT         OPT         OPT           MeterBaseChangedNotification         OPT         OPT         OPT           MeterBaseExchangeNotification         OPT         OPT         OPT           MeterBaseRemoveNotification         OPT         OPT         OPT           MeterBaseRetireNotification         OPT         OPT         OPT           MeterChangedNotification         REC         REC         OPT           MeterConnectivityNotification         OPT         OPT         OPT           MeterExchangeNotification         OPT         OPT         OPT           MeterRemoveNotification         REC         REC         OPT           MeterRetireNotification         REC         REC         OPT           MeterTestNotification         REC         REC         OPT           RetChangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT					İ		† †	-	OPT
MeterBaseChangedNotification         OPT         OPT         OPT           MeterBaseExchangeNotification         OPT         OPT         OPT           MeterBaseRemoveNotification         OPT         OPT         OPT           MeterBaseRetireNotification         OPT         OPT         OPT           MeterChangedNotification         REC         REC         OPT           MeterConnectivityNotification         OPT         OPT         OPT           MeterExchangeNotification         OPT         OPT         OPT           MeterRemoveNotification         REC         REC         OPT           MeterRetireNotification         REC         REC         OPT           MeterTestNotification         REC         REC         OPT           RetCHangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT				+	1		+ +		
MeterBaseExchangeNotification         OPT         OPT         OPT           MeterBaseRemoveNotification         OPT         OPT         OPT           MeterBaseRetireNotification         OPT         OPT         OPT           MeterChangedNotification         REC         REC         OPT           MeterConnectivityNotification         OPT         OPT         OPT           MeterExchangeNotification         OPT         OPT         OPT           MeterRemoveNotification         REC         REC         OPT           MeterRetireNotification         REC         REC         OPT           MeterTestNotification         REC         REC         OPT           RateChangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT				ļ	<b></b>		<b> </b>		
MeterBaseExchangeNotification         OPT         OPT         OPT           MeterBaseRemoveNotification         OPT         OPT         OPT           MeterBaseRetireNotification         OPT         OPT         OPT           MeterChangedNotification         REC         REC         OPT           MeterConnectivityNotification         OPT         OPT         OPT           MeterExchangeNotification         OPT         OPT         OPT           MeterRemoveNotification         REC         REC         OPT           MeterRetireNotification         REC         REC         OPT           MeterTestNotification         REC         REC         OPT           RateChangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT	MeterBaseChangedNotification			<u> </u>	<u>L</u>		<u>                                      </u>		
MeterBaseRemoveNotification         OPT         OPT         OPT           MeterBaseRetireNotification         OPT         OPT         OPT           MeterChangedNotification         REC         REC         OPT           MeterConnectivityNotification         OPT         OPT         OPT           MeterExchangeNotification         OPT         OPT         OPT           MeterRemoveNotification         REC         REC         OPT           MeterRetireNotification         REC         REC         OPT           MeterTestNotification         REC         REC         OPT           RateChangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT		OPT				OPT		_	OPT
MeterBaseRetireNotification         OPT         OPT         OPT           MeterChangedNotification         REC         REC         OPT           MeterConnectivityNotification         OPT         OPT         OPT           MeterExchangeNotification         OPT         OPT         OPT           MeterRemoveNotification         REC         REC         OPT           MeterRetireNotification         REC         REC         OPT           MeterTestNotification         OPT         OPT         OPT           RateChangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT				+	1		<del>                                     </del>		
MeterChangedNotification         REC         REC         OPT           MeterConnectivityNotification         OPT         OPT         OPT           MeterExchangeNotification         OPT         OPT         OPT           MeterRemoveNotification         REC         REC         OPT           MeterRetireNotification         REC         REC         OPT           MeterTestNotification         OPT         OPT         OPT           RateChangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT				1	<del> </del>		<del>                                     </del>		
MeterConnectivityNotification         OPT         OPT         OPT           MeterExchangeNotification         OPT         OPT         OPT           MeterRemoveNotification         REC         REC         OPT           MeterRetireNotification         REC         REC         OPT           MeterTestNotification         OPT         OPT         OPT           RateChangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT	MeterBaseRetireNotification				<u> </u>		1		
MeterConnectivityNotification         OPT         OPT         OPT           MeterExchangeNotification         OPT         OPT         OPT           MeterRemoveNotification         REC         REC         OPT           MeterRetireNotification         REC         REC         OPT           MeterTestNotification         OPT         OPT         OPT           RateChangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT					1	REC	1 T		OPT
MeterExchangeNotification         OPT         OPT         OPT           MeterRemoveNotification         REC         REC         OPT           MeterRetireNotification         REC         REC         OPT           MeterTestNotification         OPT         OPT         OPT           RateChangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT	MeterChangedNotification	REC		OPT	i		†		
MeterRemoveNotification         REC         REC         OPT           MeterRetireNotification         REC         REC         OPT           MeterTestNotification         OPT         OPT         OPT           RateChangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT		REC			1		+		_
MeterRetireNotification         REC         REC         OPT           MeterTestNotification         OPT         OPT         OPT           RateChangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT	MeterConnectivityNotification					~~			1 (1)
MeterRetireNotification         REC         REC         OPT           MeterTestNotification         OPT         OPT         OPT           RateChangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT	MeterConnectivityNotification MeterExchangeNotification	OPT							
MeterTestNotification         OPT         OPT         OPT           RateChangedNotification         REC         REC         OPT           RemoveMetersFromConfigurationGroup         OPT         OPT         OPT	MeterConnectivityNotification MeterExchangeNotification	OPT							
RateChangedNotification     REC     REC     OPT       RemoveMetersFromConfigurationGroup     OPT     OPT	MeterConnectivityNotification MeterExchangeNotification MeterRemoveNotification	OPT REC				REC			OPT
RemoveMetersFromConfigurationGroup OPT OPT	MeterConnectivityNotification MeterExchangeNotification MeterRemoveNotification MeterRetireNotification	OPT REC				REC REC		OPT	OPT OPT
	MeterConnectivityNotification MeterExchangeNotification MeterRemoveNotification MeterRetireNotification MeterTestNotification	OPT REC REC				REC REC OPT		OPT	OPT OPT OPT
	MeterConnectivityNotification MeterExchangeNotification MeterRemoveNotification MeterRetireNotification MeterTestNotification RateChangedNotification	OPT REC REC				REC REC OPT REC		OPT	OPT OPT OPT
	MeterConnectivityNotification MeterExchangeNotification MeterRemoveNotification MeterRetireNotification MeterTestNotification RateChangedNotification	OPT REC REC				REC REC OPT REC		OPT	OPT OPT OPT

ScheduleGroupMeterReading	OPT				OPT			
ServiceLocationChangedNotification	REC				REC			OPT
ServiceOrderChangedNotification	REC				REC			OPT
ServiceOrderClosedNotification	REC				REC			OPT
ServiceOrderOpenedNotification	REC				REC			OPT
UpdateServiceLocationDisplays	OPT				OPT			
Discovery								
DomainMembersChangedNotification	OPT							
DomainNamesChangedNotification	OPT							
GetDomainMembers	OPT							
GetDomainNames	OPT							
GetMethods	REQ							
GetPublishMethods	REC							
Subscription and Network Management								
GetRegistrationInfoByID	REC							
RegisterForService	REC							
RequestRegistrationID	REC							
UnregisterForService	REC							
PingURL	REQ							

REQ - Inclusion is required for this interface.

REC - Inclusion is recommended for this interface.

OPT - Inclusion is optional for this interface.

Cooperative Energy Services (CES) reserves exclusive discretion to determine the content and definition of MultiSpeak®, a federally registered trademark of the National Rural Electric Cooperative Association (NRECA). Copyright © 2000-2012 CES.