

USER'S GUIDE

LPC2148 PROGRAMMING PROCEDURE



LPC2148 PROGRAMMING PROCEDURE

STEP: 1


Supply Input Voltage 12V AC/DC {or} Connect to USB for Power Input.



NOTE: LPC2148 Board Can Work either in 12V AC/DC or USB Power. Do not connect both.

STEP: 2


Connect LPC2148 – COM0/ISP Port to PC via RS232 Port. If RS232 Port is not available in your PC, use USB to UART Converter.



STEP: 3

In Flash Utility,

- ➤ Select Correct COM port Number, BAUD RATE(9600) and XTAL Frequency(12000). COM Port can be identified in Device Manager (My Computer → Properties) in PC.
- ➤ Do not select Device, Part Id and Bootloader Id, It Will automatically Identify.
- Disable DTR/RTS For Reset and Bootloader Selection.



STEP: 4


How to Enter into ISP mode manually

Click Read Device Id.


If **p0.14** is pulled low during **RESET**, it will enter into ISP mode In ISP only we can Flash, Read, and verify hex file.

The bootloader uses UART#0 for downloading new program images(Hex) into the processor FLASH.If the processor samples P0.14 low after reset the bootloader is entered, else the application code is executed.

➤ It will ask for "Please Reset Your Lpc2000 Board".




Sometimes if error message like "Cannot Communicate with Test Board" Comes




Click Read Device Id again It will ask for "Please Reset Your Lpc2000 Board".


Now in LPC 2148 board press ISP switch (sw2)




By holding ISP switch, press **RESET switch** (sw1)




Now release **RESET switch** (sw1)




Then release ISP switch (sw2) also.



Now click OK.




Device, Part Id and Bootloader Id is Read Successfully.



STEP: 5

Select the **HEX** File and click **Upload** to FLASH after Uploading Press **RESET** Switch (sw1) for Return the LPC2148 Board into **Application mode**.



NSK POWER OF IMAGINATION www.nskelectronics.in