

Ignition Advance Curve (Low)

Ignition Advance Curve (High)





 Measuring condition : warming-up engine
Ignition advance tolerance : +/- 2° Note:

1. Measuring condition : warming-up engine 2. Ignition advance tolerance : +/- 2° Note: