

DTC	FAULT CONDITION
B110300	LHCM internal fault
B112011	Cruise set switch circuit shorted to ground
B112012	Cruise set switch circuit shorted to voltage
B112013	Cruise set switch circuit open
B112111	Cruise resume switch circuit shorted to ground
B112112	Cruise resume switch circuit shorted to voltage
B112113	Cruise resume switch circuit open
B112211	Cruise on switch circuit shorted to ground
B112212	Cruise on switch circuit shorted to voltage
B112213	Cruise on switch circuit open
B112311	Cruise off switch circuit shorted to ground
B112312	Cruise off switch circuit shorted to voltage
B112313	Cruise off switch circuit open
B112411	Left turn switch circuit shorted to ground
B112412	Left turn switch circuit shorted to voltage
B112413	Left turn switch circuit open
B112511	Right turn switch circuit shorted to ground
B112512	Right turn switch circuit shorted to voltage
B112513	Right turn switch circuit open
B112613	Clutch switch circuit open
B112712	Clutch lever applied switch circuit shorted to voltage
B112812	Clutch lever released switch circuit shorted to voltage
B112911	Turn switch cancel circuit shorted to ground
B112912	Turn switch cancel circuit shorted to voltage
B112913	Turn switch cancel circuit open
B112E11	High beam switch circuit shorted to ground
B112E12	High beam switch circuit shorted to voltage
B112E13	High beam switch circuit open
B112F11	FTP circuit shorted to ground
B112F12	FTP circuit shorted to voltage
B112F13	FTP circuit open
B115300	RHCM internal fault
B116000	RHCM/LHCM internal fault
B116508	RHCM Off switch invalid data received
B116509	Stop switch fault
B116511	Stop switch circuit shorted to ground
B116512	Stop switch circuit shorted to voltage
B116513	Stop switch circuit open
B116608	RHCM run switch invalid data received
B116609	Run switch fault

B116611	Run switch circuit shorted to ground
B116612	Run switch circuit shorted to voltage
B116613	Run switch circuit open
B116711	Start switch circuit shorted to ground
B116712	Start switch circuit shorted to voltage
B116713	Start switch circuit open
B116811	Ride mode switch circuit shorted to ground
B116812	Ride mode switch circuit shorted to voltage
B116813	Ride mode switch circuit open

DTC	FAULT CONDITION
B116A11	Hazard switch circuit shorted to ground
B116A12	Hazard switch circuit shorted to voltage
B116A13	Hazard switch circuit open
B116B11	TC switch circuit shorted to ground
B116B12	TC switch circuit shorted to voltage
B116B13	TC switch circuit open
B116C11	Front brake applied switch circuit shorted to ground
B116C12	Front brake applied switch circuit shorted to voltage
B116C13	Front brake applied switch circuit open
B116D11	Front brake released switch circuit shorted to ground
B116D12	Front brake released switch circuit shorted to voltage
B116D13	Front brake released switch circuit open
B11A92	Clutch switch performance
B11A292	High beam switch performance
B11A392	FTP switch performance
B11A492	Cruise set switch performance
B11A592	Cruise resume switch performance
B11A692	Cruise on switch performance
B11A792	Cruise off switch performance
B11A892	Left turn switch performance
B11A992	Right turn switch performance
B11AB92	Heated grip performance
B11B192	Stop switch performance
B11B292	Run switch performance
B11B392	Start switch performance
B11B492	Ride mode switch performance
B11B592	Spare/reserved switch performance

B11B692	Hazard switch performance
B11B792	TC switch performance
B11B892	VR switch performance
B11B992	Front brake switch performance
B11C011	Heated grip temperature sensor circuit shorted to ground
B11C013	Heated grip temperature sensor circuit open
B11C016	Heated grip temperature sensor circuit voltage below threshold
B11C017	Heated grip temperature sensor circuit voltage above threshold
B11C118	Heated grip circuit overloaded
B11C119	Heated grip circuit overloaded
B11C262	Heated grip status mismatch
B11C300	Heated grip over commanded temperature
B120000	Inst internal fault
B120100	Inst internal fault
B121041	Inst internal fault
B121141	Inst internal fault
B121241	Inst internal fault
B121304	Inst internal fault
B121400	Inst internal fault
B121447	Inst internal fault
B122000	Incoming ODO high
B122200	Vehicle configuration invalid
B122411	Battery telltale output circuit shorted to ground
B122413	Battery telltale output circuit open
B122511	Low fuel telltale output circuit shorted to ground

DTC	FAULT CONDITION
B122513	Low fuel telltale output circuit open
B122611	Low fuel telltale output circuit shorted to ground
B122613	Turn signal right telltale output circuit open
B122711	Turn signal left telltale output circuit shorted to ground
B122713	Turn signal left telltale output circuit open
B122811	FIL telltale output circuit shorted to ground
B122813	FIL telltale output circuit open
B122911	ABS telltale output circuit shorted to ground
B122913	ABS telltale output circuit open
B122A11	Traction control telltale output circuit shorted to ground
B122A13	Traction control telltale output circuit open
B13149E	LHCM VR PTT button stuck

B13159E	LHCM up button stuck
B13169E	LHCM left button stuck
B13179E	LHCM center button stuck
B13189E	LHCM right button stuck
B13199E	LHCM down button stuck
B13219E	RHCM up button stuck
B13229E	RHCM left button stuck
B13239E	RHCM center button stuck
B13249E	RHCM right button stuck
B13259E	RHCM down button stuck
B13719E	RHCM ride mode button stuck
B15A992	Front brake switch performance
B210011	System power 1 circuit shorted to ground
B210015	System power 1 circuit shorted to voltage
B210019	System power 1 circuit overloaded
B211111	ACC circuit shorted to ground
B211112	ACC circuit shorted to voltage
B211119	ACC circuit overloaded
B211611	Fuel pump circuit shorted to ground
B211615	Fuel pump circuit shorted to voltage/open
B211619	Fuel pump circuit overloaded
B21164B	Fuel pump circuit over temperature
B212111	Starter circuit shorted to ground
B212115	Starter circuit shorted to voltage/open
B212119	Starter circuit overloaded
B212511	Horn output circuit shorted to ground
B212515	Horn circuit shorted to voltage/open
B212519	Horn circuit overloaded
B213111	High beam circuit shorted to ground
B213115	High beam circuit shorted to voltage/open
B213119	High beam circuit overloaded
B213611	Low beam circuit shorted to ground
B213615	Low beam circuit shorted to voltage/open
B213619	Low beam circuit overloaded
B214111	Turn signal left front circuit shorted to ground
B214115	Turn signal left front circuit shorted to voltage/open
B214119	Turn signal left front circuit overloaded
B214611	Turn signal right front circuit shorted to ground
B214615	Turn signal right front circuit shorted to voltage/open
B214619	Turn signal right front circuit overloaded

DTC	FAULT CONDITION
B215111	Turn signal left rear circuit shorted to ground
B215115	Turn signal left rear circuit shorted to voltage/open
B215119	Turn signal left rear circuit overloaded
B215611	Turn signal right rear circuit shorted to ground
B215615	Turn signal right rear circuit shorted to voltage/open
B215619	Turn signal right rear circuit overloaded
B216111	Brake lamp circuit shorted to ground
B216115	Brake lamp circuit shorted to voltage/open
B216119	Brake lamp circuit overloaded
B216611	Running lamp circuit shorted to ground
B216615	Running lamp circuit shorted to voltage/open
B216619	Running lamp circuit overloaded
B217011	System power 2 circuit shorted to ground
B217012	System power 2 circuit shorted to voltage
B217019	System power 2 circuit overloaded
B217111	Wake up power circuit shorted to ground
B217115	Wake up power circuit shorted to voltage/open
B217119	Wake up power circuit overloaded
B217211	Siren circuit shorted to ground
B217212	Siren circuit shorted to voltage
B217511	VVT power circuit shorted ground
B217519	VVT power circuit overloaded
B217613	Security antenna circuit open
B220611	Run/stop switch input circuit shorted to ground
B220615	Run/stop switch circuit shorted to voltage/open
B22509E	Clutch switch stuck on
B22519E	Horn switch stuck on
B22529E	High beam switch stuck on
B22539E	FTP switch stuck on
B225481	Left turn signal error
B22549E	Left turn switch stuck on
B22559E	Trip switch stuck on
B22609E	Start switch stuck on
B226181	Right turn signal invalid data recieved
B22619E	Right turn switch stuck on
B226281	Brake lever position RHCM invalid data received
B22629E	Front brake switch stuck on
B226381	Hazard switch error
B22639E	Hazard switch stuck on

B226881	Ride mode switch invalid data received
B22689E	Ride mode switch stuck on
B22699E	VR switch stuck on
B226A9E	Cruise set switch stuck on
B226B9E	Cruise resume switch stuck on
B226C9E	Cruise On switch stuck on
B226D9E	Cruise Off switch stuck on
B226E9E	LHCM navigation switch stuck on
B226F9E	RHCM navigation switch stuck on
B227008	BCM internal fault
B227042	BCM internal fault
B227043	BCM internal fault
B227046	BCM internal fault

DTC	FAULT CONDITION
B227049	BCM internal fault
B2271A2	System voltage low
B2271A3	System voltage high
B227400	Constant battery line error
B227711	Banking lamp output circuit shorted to ground
B227719	Banking lamp output circuit current above threshold
B227777	Banking lamp output bulb out or commanded position not reachable
B227794	Banking lamp output unexpected operation
B227856	Bank light configuration invalid
B227955	Tilt sensing configuration default
B228400	Rear brake state correlation
B228556	Rear brake configuration invalid
B228608	Rear brake rx bus signal/message failure
B228681	Rear brake rx invalid serial data received
B228700	Front brake state correlation
B228856	Front brake configuration invalid
B228908	Front brake Rx bus signal/message failure
B228981	Front brake Rx invalid data received
B229281	Traction control switch error
B22929E	RHCM traction control switch stuck on
B22939E	RHCM auxiliary switch stuck on
B22949E	LHCM auxiliary switch stuck on
B22959E	Information switch stuck on
B22969E	Heated grip switch stuck on

B229A9E	Spare/reserved switch stuck on
B231009	ABS/EHCU ride mode component failure
B231056	ABS/EHCU ride mode configuration invalid
B231062	ABS/EHCU ride mode signal compare failure
B23109A	ABS/EHCU ride mode change not allowed or system operating conditions
B231109	ABS/ECM ride mode component failure
B231156	ABS/ECM ride mode configuration invalid
B231162	ABS/ECM ride mode signal compare failure
B23119A	ABS/ECM ride mode change not allowed or system operating conditions
B231362	Ride mode signal compare failure
B231400	Traction control change timeout
B231509	Suspension ride mode component failure
B231556	Suspension ride mode configuration invalid
B231562	Suspension ride mode signal compare failure
B23159A	Suspension ride mode change not allowed or system operating conditions
B231600	Ride mode override fault
B231756	BCM ride mode configuration invalid
B233000	Charging system fault
B233300	ABS/EHCU acceleration data fault
C007700	Low tire pressure
C008300	TPMS indicator malfunction
C051CF0	Multi-axis acceleration sensor range/performance
C051CF1	Multi-axis acceleration sensor range/performance
C051CF2	Multi-axis acceleration sensor range/performance
C051CF3	Multi-axis acceleration sensor range/performance
C051CF4	Multi-axis acceleration sensor range/performance
C051CF5	Multi-axis acceleration sensor range/performance
C051CF6	Multi-axis acceleration sensor range/performance

DTC	FAULT CONDITION
C051CF7	Multi-axis acceleration sensor range/performance
C051CF8	Multi-axis acceleration sensor range/performance
C051CF9	Multi-axis acceleration sensor range/performance
C051CFA	Multi-axis acceleration sensor range/performance
C051CFB	Multi-axis acceleration sensor range/performance
C051D46	Multi-axis acceleration sensor missing calibration
C051D56	Multi-axis acceleration sensor missing calibration
C051DF0	Multi-axis acceleration sensor missing calibration
C051DF1	Multi-axis acceleration sensor missing calibration

C051DF2	Multi-axis acceleration sensor missing calibration
C051DF3	Multi-axis acceleration sensor missing calibration
C051DF4	Multi-axis acceleration sensor missing calibration
C051DF5	Multi-axis acceleration sensor missing calibration
C051DF6	Multi-axis acceleration sensor missing calibration
C051DF7	Multi-axis acceleration sensor missing calibration
C051DF8	Multi-axis acceleration sensor missing calibration
C051DF9	Multi-axis acceleration sensor missing calibration
C051DFA	Multi-axis acceleration sensor missing calibration
C051DFB	Multi-axis acceleration sensor missing calibration
C051DFC	Multi-axis acceleration sensor missing calibration
C051DFD	Multi-axis acceleration sensor missing calibration
C051E08	Multi-axis acceleration sensor intermittent/erratic
C051E42	Multi-axis acceleration sensor intermittent/erratic
C051E44	Multi-axis acceleration sensor intermittent/erratic
C051E47	Multi-axis acceleration sensor intermittent/erratic
C052004	Multi-axis acceleration sensor internal failure
C052006	Multi-axis acceleration sensor internal failure
C052044	Multi-axis acceleration sensor internal failure
C052045	Multi-axis acceleration sensor internal failure
C052048	Multi-axis acceleration sensor internal failure
C052092	Multi-axis acceleration sensor internal failure
C056200	ABS/EHCU voltage low
C056300	ABS/EHCU voltage high
C0563FF	ABS/EHCU voltage high signal above critical threshold
C101400	ABS/EHCU relay error
C102100	ABS/EHCU front WSS always zero
C102300	ABS/EHCU rear/left rear WSS always zero
C102500	ABS/EHCU front wheel speed intermittent
C102700	ABS/EHCU rear/left rear wheel speed intermittent
C102900	ABS/EHCU wheel speed difference too high
C103200	ABS/EHCU front wheel speed circuit open/shorted
C103400	ABS/EHCU rear/left rear wheel speed circuit open/shorted
C104000	ABS/EHCU pump/motor error
C104125	IMU error/signal failure
C104129	IMU error/signal invalid
C10412A	IMU error/signal stuck in range
C10412F	IMU error/signal erratic
C104200	IMU mounting error
C105500	ABS/EHCU internal error
C106100	ABS/EHCU front apply solenoid circuit open/high resistance

C106200	ABS/EHCU front release solenoid circuit open/high resistance
C106500	ABS/EHCU rear/left rear apply solenoid circuit open/high resistance

DTC	FAULT CONDITION
C106600	ABS/EHCU rear/left rear release solenoid circuit open/high resistance
C107100	Rear prime valve error
C107200	Rear isolation valve error
C107300	Front isolation valve error
C107400	Front prime valve error
C107500	Front linked inlet valve error
C107600	Front linked outlet valve error
C107700	Front circuit pressure sensor error
C107800	Rear circuit pressure sensor error
C108100	Front master pressure sensor error
C108200	Front master pressure sensor offset error
C108300	Front wheel pressure sensor error
C108400	Front wheel pressure sensor offset error
C108500	Rear master pressure sensor error
C108600	Rear master pressure sensor offset error
C108700	Rear wheel pressure sensor error
C108800	Rear wheel pressure sensor offset error
C108900	Pressure sensor external supply error
C110000	Traction control fault indicated by ECM/VSC
C115900	ABS invalid stored VIN
C117800	ABS no VIN received from ECM/VSC
C118400	ABS invalid VIN from ECM/VSC
C119500	Wake up error
C121300	Front caliper pressure system fault
C121400	Rear caliper pressure system fault
C181014	Front preload piston position circuit shorted to ground/open
C181064	Front preload piston position (+) signal plausibility failure
C181214	Rear preload piston position (+) circuit shorted to ground/open
C181264	Rear preload piston position (+) signal plausibility failure
C181414	Front stroke position circuit shorted to ground/open
C181464	Front stroke position (+) signal plausibility failure
C181614	Rear stroke position circuit shorted to ground/open
C181664	Rear stroke position (+) signal plausibility failure
C181712	All stroke position circuit shorted to voltage
C181811	Front ARH control circuit shorted to ground
C181812	Front ARH control circuit shorted to voltage
C181813	Front ARH control circuit open

C181814	Front ARH control circuit short to ground/open
C181911	ARH solenoid power circuit shorted to ground
C181915	ARH solenoid power circuit shorted to voltage/open
C182011	Rear ARH control circuit shorted to ground
C182012	Rear ARH control circuit shorted to voltage
C182014	Rear ARH control circuit shorted to ground/open
C182112	Front damping control circuit shorted to voltage
C182114	Front damping control circuit shorted to ground/open
C182164	Front damping control signal plausibility failure
C182211	Damping solenoid power circuit shorted to ground
C182215	Damping solenoid power circuit shorted to voltage/open
C182312	Rear damping control circuit shorted to voltage
C182314	Rear damping control circuit shorted to ground/open
C182364	Rear damping control signal plausibility failure
C200000	Front TPMS communication fault

DTC	FAULT CONDITION
C200100	Rear or right rear TPMS communication fault
C200316	Front TPMS fault circuit voltage below threshold
C200356	Front TPMS fault/invalid/incompatible configuration
C200398	Front TPMS fault component or system over temperature
C2003F1	Front TPMS fault/acceleration error
C2003F2	Front TPMS fault pressure error
C200416	Rear/Right rear TPMS fault circuit voltage below threshold
C200456	Rear/Right rear TPMS fault configuration invalid
C200498	Rear/Right rear TPMS fault component or system over temperature
C2004F1	Rear/Right rear TPMS fault acceleration error
C2004F2	Rear/Right rear TPMS fault pressure error
C200600	TPMS IDs not loaded
C200700	Low tire pressure thresholds not loaded
P001200	Camshaft front intake timing over-retarded
P001500	Camshaft front exhaust timing over-retarded
P001600	Camshaft front intake correlation error
P001700	Camshaft front exhaust correlation error
P001800	Camshaft rear intake correlation error
P001900	Camshaft rear exhaust correlation error
P002200	Camshaft rear intake timing over-retarded
P002500	Camshaft timing rear exhaust over-retarded
P002600	VVT control solenoid front intake circuit range/performance
P002700	VVT control solenoid front exhaust circuit range/performance

P002800	VVT control solenoid rear intake circuit range/performance
P002900	VVT control solenoid rear exhaust circuit range/performance
P003000	HO2S pre catalyst front cylinder heater control circuit open
P003100	HO2S pre catalyst front cylinder heater control circuit shorted to ground
P003200	HO2S pre catalyst front cylinder heater control circuit shorted to voltage
P003600	HO2S post catalyst front cylinder heater control circuit open
P003700	HO2S post catalyst front cylinder heater control circuit shorted to ground
P003800	HO2S post catalyst front cylinder heater control circuit shorted to voltage
P005000	HO2S pre catalyst rear cylinder heater control circuit open
P005100	HO2S pre catalyst rear cylinder heater control circuit shorted to ground
P005200	HO2S pre catalyst rear cylinder heater control circuit shorted to voltage
P005300	HO2S pre catalyst front cylinder heater resistance
P005400	HO2S post catalyst front cylinder heater resistance
P005900	HO2S pre catalyst rear cylinder heater resistance
P007100	AAT sensor circuit range/performance
P007200	AAT sensor circuit shorted to ground
P007300	AAT sensor circuit shorted to voltage/open
P00D100	HO2S pre catalyst front cylinder heater control circuit performance
P00D200	HO2S post catalyst front cylinder heater control circuit performance
P00D300	HO2S pre catalyst rear cylinder heater control circuit performance
P00D400	HO2S post catalyst rear cylinder heater control circuit performance
P010600	MAP sensor circuit range/performance
P010700	MAP sensor failed low/open
P010800	MAP sensor failed high/open
P010900	MAP sensor circuit intermittent
P011100	IAT sensor circuit range/performance
P011200	IAT sensor circuit shorted to ground
P011300	IAT sensor circuit shorted to voltage/open
P011600	ECT sensor circuit range/performance

DTC	FAULT CONDITION
P011700	ECT sensor circuit shorted to ground
P011800	ECT sensor circuit shorted to voltage/open
P011900	ECT sensor circuit intermittent
P011B00	ECT - IAT sensor correlation error
P011E00	ECT - AAT sensor correlation error
P012000	TPS 1 range error
P012800	Coolant thermostat temperature below regulating temperature
P013100	HO2 sensor circuit low voltage - bank 1 sensor 1
P013200	HO2S pre catalyst front cylinder circuit high voltage

P013300	HO2S pre catalyst front cylinder circuit slow response
P013400	HO2S pre catalyst front cylinder circuit no activity detected
P013500	HO2 sensor heater circuit - bank 1 sensor 1
P013700	HO2S pre catalyst front cylinder circuit shorted to ground
P013800	HO2S post catalyst front cylinder circuit shorted to voltage
P013A00	HO2S post catalyst front cylinder circuit slow response
P013B00	HO2S post catalyst front cylinder circuit slow response
P013C00	HO2S post catalyst rear cylinder circuit slow response
P013D00	HO2S post catalyst rear cylinder circuit slow response
P014000	HO2S post catalyst front cylinder circuit no activity detected
P014100	HO2S post catalyst front cylinder heater circuit
P015100	HO2S pre catalyst rear cylinder circuit low voltage
P015200	HO2S pre catalyst rear cylinder circuit high voltage
P015300	HO2S pre catalyst rear cylinder circuit slow response
P015400	HO2S pre catalyst rear cylinder circuit no activity detected
P015500	HO2S pre catalyst rear cylinder heater circuit
P015700	HO2S post catalyst rear cylinder circuit low voltage
P015800	HO2S post catalyst rear cylinder circuit high voltage
P016000	HO2S post catalyst rear cylinder circuit no activity detected
P016100	HO2S post catalyst rear cylinder heater circuit
P022000	TPS 2 range error
P022200	TPS 2 circuit shorted to ground/open
P022300	TPS 2 circuit shorted to voltage
P026100	Fuel injector front cylinder circuit shorted to ground/open
P026200	Fuel injector front cylinder shorted to voltage
P026400	Fuel injector rear cylinder circuit shorted to ground/open
P026500	Fuel injector rear cylinder shorted to voltage
P030000	Random/multiple cylinder misfire detected
P030100	Front cylinder misfire detected
P030200	Rear cylinder misfire detected
P032500	Knock sensor front or single circuit open
P032700	Knock sensor front or single circuit shorted to ground
P032800	Knock sensor front or single circuit shorted to voltage
P034100	Camshaft position sensor front intake circuit range/performance
P034600	Camshaft position sensor rear intake circuit range/performance
P036600	Camshaft position sensor front exhaust circuit range/performance
P037100	CKP sensor wrong number of pulses
P037400	CKP sensor no pulses
P039100	Camshaft position sensor rear exhaust circuit range/performance
P042000	Catalyst system efficiency front cylinder below threshold
P043000	Catalyst system efficiency rear cylinder below threshold

P044400	Purge solenoid circuit shorted to ground
P044500	Purge solenoid circuit shorted to voltage

DTC	FAULT CONDITION
P046200	Fuel sender circuit shorted to ground
P046300	Fuel sender shorted circuit shorted to voltage
P050500	Idle speed control unstable
P050600	Idle speed control RPM too low
P050700	Idle speed control RPM too high
P052200	Engine oil pressure sensor circuit shorted to ground
P052300	Engine oil pressure sensor circuit shorted to voltage
P056000	Powertrain voltage low
P056200	System voltage low
P056300	System voltage high
P057200	Brake switch shorted to ground
P057700	Cruise control input error
P060200	ECM programming error
P060300	ECM EEPROM memory error
P060400	ECM memory error
P060500	ECM memory error
P060600	ECM memory error
P060700	ECM performance error
P060B00	ECM performance error
P060C00	ECM performance error
P06B800	ECM memory error
P063000	VIN not programmed or incompatible ECM/PCM
P064100	5 Volt reference out of range
P065100	5 Volt reference 2 out of range
P070400	Clutch switch input circuit
P073000	Incorrect gear ratio
P091500	Gear shift position circuit "A" range/performance
P091600	Gear shift position circuit shorted to ground
P091700	Gear shift position circuit shorted to voltage
P100900	ECM internal error
P101900	ECT high temp
P110000	ABS/EHCU indicates torque control fault
P110200	ABS/EHCU indicates FWSS fault
P110300	ABS/EHCU indicates rear/right rear WSS fault
P110400	ABS/EHCU indicates RWSS fault
P110800	ABS/EHCU front WSS missing data
P110900	ABS/EHCU rear/right rear WSS missing data

P111000	ABS/EHCU left rear WSS missing data
P127000	TGS 2 A/D validation error
P135300	No combustion detected front cylinder
P135600	No combustion detected rear cylinder
P135800	Intermittent secondary detected rear cylinder
P150100	JSS circuit shorted to ground
P150200	JSS circuit shorted to voltage/open
P151000	ETC limited performance mode
P151100	ETC power management mode
P151200	ETC forced idle mode
P151400	ETC airflow error
P160000	ETC watchdog error
P160800	Loss of continuous battery
P163200	Odometer learned up
P169100	Cooling fan left circuit shorted to ground

DTC	FAULT CONDITION
P169200	Cooling fan left circuit shorted to voltage
P178500	VVT control solenoid front intake circuit open
P178600	VVT control solenoid front intake circuit shorted to voltage
P178700	VVT control solenoid front intake circuit shorted to ground
P179000	VVT control solenoid front exhaust circuit open
P179100	VVT control solenoid front exhaust circuit shorted to voltage
P179200	VVT control solenoid front exhaust circuit shorted to ground
P179500	VVT control solenoid rear intake circuit open
P179600	VVT control solenoid rear intake circuit shorted to voltage
P179700	VVT control solenoid rear intake circuit shorted to ground
P180000	VVT control solenoid rear exhaust circuit open
P180100	VVT control solenoid rear exhaust circuit shorted to voltage
P180200	VVT control solenoid rear exhaust circuit shorted to ground
P210000	ETC driver circuit open
P210100	ETC actuation error
P210200	ETC driver circuit shorted to ground
P210300	ETC driver circuit shorted to voltage
P210500	ETC forced shutdown mode
P210700	ETC driver internal error
P211900	ETC actuator return error
P212100	TPS circuit range/performance
P212200	TGS 1 circuit shorted to ground/open
P212300	TGS 1 circuit shorted to voltage
P212400	TGS 1 circuit intermittent

P212700	TGS 2 circuit shorted to ground/open
P212800	TGS 2 circuit shorted to voltage
P212900	TGS 2 circuit intermittent
P213500	TPS A/B voltage correlation
P213800	TGS correlation error
P214600	Fuel injector front supply voltage circuit/open
P214900	Fuel injector rear supply voltage circuit/open
P217600	ETC zero position learning error
P219500	O2S pre catalyst front cylinder signal lean
P219600	O2S pre catalyst front cylinder signal rich
P219700	O2S pre catalyst rear cylinder signal lean
P219800	O2S pre catalyst rear cylinder signal rich
P227000	O2S post catalyst front cylinder signal lean
P227100	O2S post catalyst front cylinder signal rich
P227200	O2S post catalyst rear cylinder signal lean
P227300	O2S post catalyst rear cylinder signal rich
P227900	Intake air leak
P230000	Ignition coil driver front circuit shorted to ground/open
P230100	Ignition coil driver front circuit shorted to voltage
P230300	Ignition coil driver rear circuit shorted to ground/open
P230400	Ignition coil driver rear circuit shorted to voltage
P230600	Aux ignition coil driver front circuit shorted to ground/open
P230700	Aux ignition coil driver front circuit shorted to voltage
P230900	Aux ignition coil driver rear circuit shorted to ground/open
P231000	Aux ignition coil driver rear circuit shorted to voltage
P2A0B00	MAP sensor rear circuit range/performance
P2A0C00	MAP sensor rear circuit shorted to ground
P2A0D00	MAP sensor rear circuit shorted to voltage

DTC	FAULT CONDITION
P2A0E00	MAP sensor rear circuit intermittent/erratic
U000100	CAN bus error
U000188	CAN bus error
U000189	CAN bus error
U000200	CAN bus error
U000300	ABS/EHCU internal fault
U002888	CAN bus error, primary
U003788	CAN bus error, secondary
U010000	Lost communication with ECM/VSC
U010001	Lost communication with ECM
U010002	Lost communication with ECM

U010003	Lost communication with ECM
U010004	Lost communication with ECM
U010005	Lost communication with ECM
U010081	Lost communication with ECM
U0100F0	Lost communication with ECM
U0100F1	Lost communication with ECM
U0100F2	Lost communication with ECM
U0100F3	Lost communication with ECM
U0100F6	Lost communication with ECM
U0100F7	Lost communication with ECM
U0100F8	Lost communication with ECM
U0100FD	Lost communication with ECM
U012100	Lost communication with ABS/EHCU
U012500	Lost communication with IMU
U012581	Lost communication with IMU
U0125F0	Lost communication with IMU
U0125F1	Lost communication with IMU
U0125F2	Lost communication with IMU
U014000	Lost communication with BCM
U014081	Lost communication with BCM
U014100	Lost communication with LHCM
U014181	Lost communication with LHCM
U014200	Lost communication with RHCM
U014262	Lost communication with RHCM
U014281	Lost communication with RHCM
U015600	Lost communication with inst 1
U015601	Lost communication with inst 1
U015602	Lost communication with inst 1
U015603	Lost communication with inst 1
U015681	Lost communication with inst 1
U018200	Lost communication with banking lamp
U030000	Module software incompatibility
U031500	Software incompatibility with ABS/EHCU
U040000	Invalid data received
U040100	Invalid data from ECM/VSC
U040164	Invalid data from ECM
U040167	Invalid data from ECM
U040181	Invalid data from ECM
U040182	Invalid data from ECM
U040183	Invalid data from ECM
U04018F	Invalid data from ECM

DTC	FAULT CONDITION
U041564	Invalid data from ABS/EHCU
U041567	Invalid data from ABS/EHCU
U041581	Invalid data from ABS/EHCU
U041582	Invalid data from ABS/EHCU
U041583	Invalid data from ABS/EHCU
U04158F	Invalid data from ABS/EHCU
U042200	Invalid data from BCM
U042264	Invalid data from BCM
U042267	Invalid data from BCM
U042281	Invalid data from BCM
U042282	Invalid data from BCM
U042283	Invalid data from BCM
U04228F	Invalid data from BCM
U043100	Invalid data from LHCM
U043164	Invalid data from IMU
U043167	Invalid data from LHCM
U043181	Invalid data from LHCM
U043182	Invalid data from LHCM
U043183	Invalid data from LHCM
U043187	Invalid data from LHCM
U04318F	Invalid data from LHCM
U043200	Invalid data from IMU
U043264	Invalid data from IMU
U043267	Invalid data from IMU
U043282	Invalid data from IMU
U043283	Invalid data from IMU
U04328F	Invalid data from IMU
U0432F0	Invalid data from IMU
U0432F1	Invalid data from IMU
U0432F2	Invalid data from IMU
U044300	Invalid data from LHCM
U044367	Invalid data from RHCM
U044381	Invalid data from RHCM
U044382	Invalid data from RHCM
U044383	Invalid data from RHCM
U044387	Invalid data from RHCM
U04438F	Invalid data from RHCM
U045767	Invalid data from BCM

U045781	Invalid data from BCM
U045782	Invalid data from BCM
U045783	Invalid data from BCM
U04578F	Invalid data from BCM
U048303	Banking lamp LIN bus invalid data received
U048356	Banking lamp LIN bus invalid data received
U048381	Banking lamp LIN bus invalid data received
U100000	IMU Vehicle learn failure
U100188	LIN bus error
U142100	Invalid TIP signal
U143181	Invalid data from lighting switch
U206400	ABS/EHCU internal fault
U206700	ABS/EHCU internal fault
U208200	ABS/EHCU internal fault
DTC	FAULT CONDITION
U208300	ABS/EHCU internal fault
U208700	ABS/EHCU internal fault
U208F00	ABS/EHCU internal fault
U216400	Invalid data from LHCM
U216700	Invalid data from LHCM
U218100	Invalid data from LHCM
U218200	Invalid data from LHCM
U218300	Invalid data from LHCM
U218700	Invalid data from LHCM
U218F00	Invalid data from LHCM
U226400	Invalid data from BCM
U226700	Invalid data from BCM
U228100	Invalid data from BCM
U228200	Invalid data from BCM
U228300	Invalid data from BCM
U228700	Invalid data from BCM
U228F00	Invalid data from BCM
U236400	Invalid data from RHCM
U236700	Invalid data from RHCM
U238100	Invalid data from RHCM
U238200	Invalid data from RHCM
U238300	Invalid data from RHCM
U238700	Invalid data from RHCM
U238F00	Invalid data from RHCM
U246400	Invalid data received from instrument

U246700	Invalid data received from instrument
U248100	Invalid data received from instrument
U248200	Invalid data received from instrument
U248300	Invalid data received from instrument
U248F00	Invalid data received from instrument
U301242	IMU internal fault
U301244	IMU internal fault
U301245	IMU internal fault
U301247	IMU internal fault
U301251	IMU internal fault
U301257	IMU internal fault
U351000	ECM calibration error