
ESP32 WROOM module

88 D 42 ESP32-WROOM-32D 35 U0_TX 24 SD_DATO 34 U0_RX 26 CAN_RX SENSOR_VP SENSOR_VN 14 CAN_STB 1012 114 CAN_STB 1013 15 1014 13 SD_CLK 1015 23 SD_CMD 1016 27 U2_RX 1017 80 U2_TX 1018 30 LED1 1019 31 1021 33 1022 36 1023 37 1025 10 1026 11 1027 12 1032 8 1033 9 1034 6 1035 7 UART at IO16/17 for AT commands


Pinout for SD card from: https://github.com/espressif/esp-idf/tree/master/examples/storage/sd_card

Data Manager - LS.one and LS.bus to WiFi gateway


USB power supply




Micro-SD card




LS.one isolated UART interface



LS.bus CAN interface



USB to UART converter for ESP programming



Data Manager -Libre Solar Website: https://libre.solar LIBRE**SOLAR** Sheet: /
File: data-manager.sch
Author: Martin Jäger

Size: A3 Date: 2019-10-17 Rev: 0.2

Reset and boot circuit
See Sparkfun / Adafruit boards