RND 320-KA3305 Calibration Procedures

Calibration instrument: benchtop multimeter with 6.5 digits display, 5A electronic load with milliampere display.
Calibration condition: Preheat for 2 minutes after switch on .

Being into calibration mode, press and hold button M4 for around 5 seconds after switch on, and all the displays will become 0. At the same time voltage displays on CH1 blink. At this time, the power supply is in the mode of zero calibration. That the voltage display of CH1 blinks means the current calibration channel is CH1, which can be switched into CH2 by pressing the button “CH2”. And the exact calibration procedures are as follows (Take CH1 as an example and procedures of CH2 is the same as that of CH1):

1. Voltage Zero Calibration: connect the positive pole and negative pole of the multimeter leads into the output terminals of CH1 respectively. Then, watch the voltmeter and adjust the knob to make the multimeter in the range 0v – 5mv. After that, the zero calibration is over. Press M1 to save the calibration value.

2. Current Zero Calibration: press the current button “PUSH (A)”, and the current display of the power supply blinks. Connect amperemeter to rotate the current button “PUSH (A)” to adjust the current value in the range 0MA – 2MA. Press the button M1 to save the calibration value.

Then the voltage and current Zero calibrations end. Press the button “M4” again to enter the calibration mode of the max value. The voltage displays 30V or so and the CH1 display blinks. The calibration procedures are as follows:

3. Connected with the multimeter and watch the display of it; rotate the voltage adjustment knob “PUSH (V)” to adjust the power supply between 30.00 – 30.02V, and press the button “M1” to save the data.
4. Press the current knob “PUSH (A)” and then the current display blinks; connected with the electronic load and set the current of it to be 5.5A. And then rotate the current knob “PUSH (A)” to adjust the current to be 5.000A+-5mA (KA3305D/P) or 3.000A+-5mA (KA3303D/P). At last, press the button “M1” to save the max current value.
5. Switch off, and then restart the power supply. The calibration ends.

RND is a trademark of Distrelec