AeroFlow Maintenance Guide

"The AeroFlow is designed with your family's comfort and safety in mind. Keeping up with regular maintenance not only extends the life of your AeroFlow but also ensures a safe and enjoyable driving experience for your whole family. This guide provides essential maintenance tips tailored specifically for your AeroFlow."

Regular Maintenance Schedule

- Every 10,000 Miles or Annually: Tire inspection and rotation, brake system check, and cabin air filter replacement.
- Every 20,000 Miles: Battery health check, suspension and alignment assessment, and full vehicle inspection.

Specific Maintenance Tips for AeroFlow

- Battery Care: Regular charging is key. Avoid letting the battery drain completely. Ideal charging is between 30% and 80%.
- Child Safety Features: Regularly check the operation of child locks, safety belts, and car seat anchors.
- Interior Maintenance: Clean and check the interior regularly, especially if you have young children. Spills should be cleaned promptly to avoid damage.

Seasonal Care

- Winter: Ensure that your heating system is functioning properly. Consider using winter tires in snowy regions.
- Summer: Check the air conditioning system and window shades to protect your family from the heat.

Battery Care and Longevity

- To maximize the life of your AeroFlow's battery, avoid frequent fast charging. Use standard charging methods when possible.
- Monitor the battery condition through the vehicle's diagnostic system, especially before long trips.

Troubleshooting Common Issues

- Reduced Range: Check tire pressure and look for any unnecessary load in the vehicle.
- Infotainment System Issues: If the system becomes unresponsive, a system reset or software update might be needed.

Warranty and Service Information

- The AeroFlow comes with a comprehensive 7-year/70,000-mile warranty.
- The battery and electric drivetrain have an extended warranty of 8 years/90,000 miles.