



HX-40用户手册及安装说明

HX-40 User Manual and Installation Instructions

Before using the HX-40, please read the User Manual and Installation Instructions carefully.

目录 Contents

I. 产品说明

Product Description

II. 附件清单

Accessories List

III. 默认键位及功能键

Default Key Layout and Function Keys

IV. 装机图解

Installation Diagrams

V. 修改键位以及更新固件

Key Remapping and Firmware Update

VI. 常见问题

FAQ

产品说明

Product Description

- 产品名称：HX-40

Product Name: HX-40

- 键入角度：7°

Typing Angle: 7°

- 内部结构：Top Mound

Internal Structure: Top Mound

- 固件：QMK

Firmware: QMK

- 支持的特殊键位：阶梯Caps、分裂空格

Special Key Features: Stepped Caps Lock, Split Spacebar

- 支持连接方式：有线、蓝牙、2.4G

Connectivity Options: Wired, Bluetooth, 2.4GHz Wireless

附件清单

Accessories List

- 铝合金外壳

Aluminum Case

- PCB*2（PCBA、分离小板）

PCB*2（PCBA、USB Daughter Board）

- FR4材质定位板

FR4 Plate

- ？ ？ mAh电池

?? mAh Battery

- 声音包

Sound Dampening Kit

- 螺丝包

Screw Kit

默认键位及功能键

Default Key Layout and Function Keys

装机图解

Installation Diagrams

装机图解

Installation Diagrams

修改键位

Key Remapping

更新固件

Firmware Update

常见问题

FAQ

按键无法使用但是灯光正常显示，或开始时正常工作但是一段时间后按键出现问题。

The keys are not functional, but the lights display normally, or they initially work fine but develop issues after a certain period.

一般是由于供电不足导致的，请检查您使用的线材。如果你使用的是一条客制化线，请更换为普通量产线后再进行测试；

Normally its due to the lack of power. If you are using a customized cable (hand made), please change it to a stock one and try again.

按键在使用量产线的情况下仍然无法使用。

Key doesnt work even its using a stock cable.

请根据固件更新 **Firmware Update** 板块的说明更新最新的固件，如果无法进入刷机模式，请直接联系售后支持；

Please update the latest firmware according to 固件更新 **Firmware Update** and try again. If you cannot enter the flash mode, please contact the customer support directly.

常见问题

FAQ

部分按键不触发或者连击。

Some keys are not triggered or are always triggered.

请检查轴体是否有问题。

Please check your switches first.

有一整行或者一整列按键同时触发。

There is an entire row or column of keys that are triggered simultaneously.

请直接联系售后支持。

Please ask the customer support directly.