

Introduction

The type of locks that I will be covering in this will be Group 2 combination locks. These are the typical type of locks found on almost all safes. Some, such as the LaGard 3330, can give more trouble than the S&G 6700 series, which are simple and used as beginner locks and sadly, also the most common type of mechanical safe locks. If you are a beginner or don't even know anything whatsoever about this topic and you just want to learn this because it's cool or to impress a girl ;), then this book is definitely you. I know there are a couple other books/tutorials on this out there but I wanted to create my own. No matter how thorough the book, there will always be some missing piece of information and I'm hoping this fills in the gaps for others out there (and my girlfriend got interested in this so this book is dedicated to her <3). And I hope this will be able to address some of those questions and that this and all the different resources put together will be complete enough to get cracking! (Pun intended). If you have any information not in this that you would like to inform me of, feel free to contact me! I have an account on keypicking.com under the username of Daggers; just shoot me a message and I'll get back to you!

Group 2 mechanical combination locks are locks that are supposed to resist manipulation for 2 hours. That's the official rating. Yeah, right. Group 2M are slightly more manipulation resistant and feature things that make taking contact readings harder, false gates, etc. Group 1 is, again, supposed to resist manipulation for 20 hours. It's way better than group 2 and 2M but still not perfect. They feature things such as an extra step that needs to be done after you enter the combination to engage all the

parts to open it. And then there is the group 1R. Same thing as group 1 but has several more features that make it impervious to x-ray and ultrasound attacks. These locks can not be x-rayed to see the combination unlike the other groups. Group 1R features things like wheels made out of delrin (low density plastic that don't show up well on x-ray), spacers in between wheels with false gates, and other precautions that confuse the x-ray image.

I would also recommend you to spend the couple extra bucks to get a cutaway safe lock to view how it works as you manipulate. You don't need a cutaway safe lock but you do need a safe lock! I recommend starting with an S&G 6741. If it just says S&G 6700 then it's most likely a 6741. A 6730 is the same thing but requires more precision when dialing in the combination and so is slightly harder for a beginner, but is still just as good. Do NOT start with a LaGard 3330! It's in the same group of locks, but has some features that I will cover later which makes it harder to start with.

I just want to say that before you try to get too deep into this book, get a safe lock and mount it on a piece of wood. Just reading through without any physical lock to look and mess around with, it will be very difficult to understand all the different components. I'm not saying it's bad if you just read through this, but it greatly helps to be able to have the lock in your hands. This is a great hobby and I wish you the best of luck!

Some might argue that this knowledge should stay secret so that the criminals won't have access to it. But the criminals already know it. Knowledge on holes in security needs to be made well known so that all the good people know and fix it. Security through obscurity is no security.


Contents

Chapter 1.....	5
How combination changing works.....	13
Chapter 2.....	14
Graph #1.....	18
Hi-low testing.....	26
Graph #2.....	28
Rotational Conversion.....	32
Chapter 3.....	34
Chapter 4.....	36
Troubleshooting.....	39
Chapter 5.....	42
Acknowledgements.....	46
Sources.....	46
High/low test chart.....	47

Ch. 1: How safe locks work

(or in other words, fail)

Ok, I have really bad photoshop skills so you'll just have to bear with me here. This is what the back of a LaGard 3330 (a typical group 2 safe lock) looks like with the back cover removed:



This is a LaGard3330. I highly recommend you have an s&g 6741/6730. It will for the most part, look the same. Ilco, Rensch, Diebold, Mosler, these work too as long as you have a group 2 from them.


The part outlined in blue is called the **nose**. It rides along the **drive cam** which is circled in orange. There is a metal wire, at the end of the arrow, that you can see pushing the **nose** down onto the **drive cam**. This means it is a spring loaded fence type of lock. The thing the spring is on is called the lever or arm. Because the **nose** is being pushed down onto

the **drive cam** when the gap is under the **nose** that means it'll drop into the gap ever so slightly. That's where the two little red dots come into play. They are called the **contact points**. The **nose** hits those points every time it is coming out of the **contact area** which is the space between the two contact points as indicated by the green line. The part in the very middle of the **drive can** is called the spline key. It's outlined in black because it's such an easy color to see amid other dark colors..... nah, I just ran out of colors :P The shaft of the dial screws into the drive cam (you can see the silver shaft behind the spline key). It has a little notch for the spline key to fit into so that it will stay in place and not unscrew out.

Are you still following along? Okay good! Now, the brass circle behind the **drive cam** is one of the 3 wheels in the lock. The purple part cutout in the wheel is called a **gate**. These terms are very important for later so make sure you remember all these. Oh, and the part circled in teal is called the **bolt**. It locks the handle of the safe the lock is on. The lock doesn't actually lock the safe, it locks the handle which is turned to retract all the bolts along the door of the safe and allow it to be opened.

If you have a S&G 6700 series, you'll have this little brass arm thingy at the bottom below the bolt. Don't worry about that yet, I'll get to it. We will be learning more about what they all do later but for now, remember these parts and what they look like! Seriously, remember all these terms and commit it to your mind. Know them like you know apples are apples and bananas are bananas.

I'm going to take it all apart now and show how all the different components fit together to make this lock function! Study it carefully!



So I numbered them. #1 is a tension washer. It's slightly wavy so it acts like a spring and keeps all the wheels (#'s 2, 5, & 9) lightly pressed against each other so nothing wobbles and it all fits snugly together. #2 is wheel number 1. You can see the gate in the wheel. The position of the gate is what determines the combination. Wheel number 1 goes on first when being reassembled and will be the wheel closest to the dial. Wheel 3 is the wheel CLOSEST to the drive cam! This will be explained shortly. #3 is called a fly. Specifically, a movable fly. It fits directly on top of the first wheel as pictured and the fly has a slot on wheel 1 it fits into. #4 is a spacer. It spaces the wheels out from one another so they don't rub on each other.

#5 is the second wheel. I have it laying upside down in the picture and for a purpose. #6 is pointing to a stub sticking out from the bottom of the second wheel called the drive pin. It fits into a groove on the top of wheel 1 and when spun, hit the fly that is laying on top of wheel one. This causes wheel one to turn with wheel two. Wheel 1 has no drive pin since there is no wheel under it that it needs to spin. #7 does the same thing as #3 and goes on the top of wheel 2 (the other side of wheel two than what's shown in the picture). #8 is the same thing as #4. #9 is the 3rd wheel. It is the same in appearance as wheel number 2 including a drive pin (since it has to move wheel 2) except that it has a larger fly (#10). The reason it's bigger will be explained later. #11 is another spacer but thicker than #'s 4 and 8. #12 is a retainer. After all the other parts are on the shaft, it snaps on to lock them into place. #13 is the drive cam with an upside down view. It goes on after the retainer. What holds it on is the spindle (the shaft of the dial) which screws into it as explained earlier.

#14 is the spline key and it holds the spindle to the drive cam. #15 is a metal bar above and behind the nose and is called the fence. When the nose is in the contact area on the drive cam, the fence lowers onto the wheels. Refer to the next picture to kinda visualize how that works. If the drive cam isn't holding up the nose, then the fence falls down onto the

top of all the wheels. And I forgot to mark it but that plastic ring between and to the right of the 2nd and 3rd wheel is to keep the dial running smoothly and so there's no metal on metal interaction. It goes on the spindle.

So this is a pretty good picture on how the fence rests on the wheels:



When the nose is on the drive cam, the fence is higher. Other wise, you would be able to feel the gates as you turn the dial and they scrape underneath the fence. Here's a picture:



Notice how high the fence is now? In this picture, the combination has been entered and all the gates are aligned. But even if they weren't, the fence still wouldn't be touching them because the nose is resting on the drive cam. Now, when we turn the dial to the contact area/drop in area in this next picture:



The whole lever arm falls in! Low enough that the metal protrusion at the top doesn't block it from moving sideways. Keep turning and it retracts the bolt:



The lever arm moves under the metal protrusion from the top of the lock body. Now, You see the little metal spring below the bolt? It's called a re-locker. It has a little arm going under the bolt and the bolt has a cut in it for the arm. The arm goes up into the bolt so the bolt can't retract into the lock. The back cover pushes the arm down so the bolt is free to move. This is because instead of manipulation, some people drill the lock and punch off the back cover to see the combination. With the cover off, the bolt is blocked by the re-locker. S&G's have a little brass arm that goes down into a hole in the bolt instead of up from the bottom. The back cover pushes down one end of the arm and that raises the other end to allow free movement of the bolt.

Basically the most important paragraph here!!!

Ok, now it's time for you to learn how the wheels move. The dial is directly connected to the drive cam so amount that the dial moves, the same movement is done by the drive cam. If you spin the dial at least one whole rotation to the right, it will take one full left rotation of the drive cam (and dial) to start the 3rd wheel moving left. Keep going and it will take another full rotation left to move the second wheel and again for the 1st. The reason the first wheel to get picked up is called the 3rd is because it's the 3rd # in the combination. Think about it; spinning the dial 4 times left sets the first wheel and 1st # in the combo. Now, you reverse direction 2 whole rotations to the right to pick up the 2nd wheel and then keep going until you get to the second number in the combination. Reverse direction again to the left one rotation to pick up the 3rd wheel and then stop at the 3rd number. You can't set the 3rd wheel first because then, how are you going to set the 1st and 2nd wheel without messing up the 3rd? Combinations are usually dialed by spinning the dial left 4 times to 1st #, right 3 times to 2nd #, left 2 times to 3rd #, then you spin the dial to the right to the drop in area and retract the bolt. When I say left 4 times to the 1st #, that's saying pass the 1st # 3 times and stop on the fourth. When I say right 3 times, pass the 2nd # 2 times and stop on the 3rd. Because of how they work, it takes 2 rotation (two passes of the second number) to pick up the second wheel. To PICK it up, not set it on where it's supposed to be. Then you have to move the dial to the 2nd number for the third time and leave it there. That's why you stop the 3rd time.

How combination changing works

In the next photo you can see there are small serrations in the wheel.



The brass bit from the wheel locks into those. You can see a circular-ish shape hole by this. When the combo is change, all these holes line up and a special metal rod called a change key slips into there. On the back of the lock casing there is a hole in the bottom left for this. The change key is turned and the brass arm going into the serrations is lifted off and then a new combo is dialed. The brass (which includes the gate of the wheel) is in a different relative spot to the silver center of the wheel (which has the drive pin and fly) and the combo is now different. Not all wheels will look like this but if they use a change key, they will work on the same principle, the change key moves the arm off the wheel, and then back on to the new combo.

Ch. 2: Exploiting these failure points

You made it through learning how these locks work! Or maybe you didn't..... just go back and re-read, you'll get it soon enough. No one gets it on their first go anyways! You're probably wondering what failure points did I go over? Well, learning how something works is the same thing as learning all the ways that it can be defeated. You just have to recognize what it is and that's why you're still reading! Locks to practice on: In this I will be using the example of an s&g 6741. I recommend either the 6741 or 6730. The only difference is the 6741 has a dialing tolerance of +/- 1.25 and 6730 has +/- .5. This means with the 6741 if a number in the combination is 10, you can dial 8.75 or 11.25 and with the 6730 only 9.5 or 10.5 and the lock will still open.

Why and how it's possible

These locks seem pretty secure right? The only thing you can use to move or do anything with is the dial. It's not like a key lock where you can stick some lockpicks in and pop it open, what you see is what you get! Safe cracking works through the measurement of where the contact points are located. On my lock, it's 96 for the left contact point and 6 for the right. You can feel these points on your lock. They will always be in the same general area. They will move, but only to a maximum of an increment and a half or so.


Now, remember how when the contact area is under the nose the fence rests on the wheel pack? This is the key. Look at the drop in area on the drive cam; it's sloped. The further down the nose is, the less wiggle room

there is for it until it's all the way in there and fits snugly. The contact point on the sloped side is the right contact point and the other side is the left one. Imagine it as if you are staring at the front of the lock (not the back) and you can see through it to the contact points. Left and right. You have to turn the dial left to touch the right contact point. If you turn it right, the nose drops down but you can't feel exactly where the contact point is. So you feel the right contact point only by hitting it from the left side of it. Opposite for the left contact point. And when I say hit, I mean to just lightly feel it. If you put too much force, the nose will ride up on it and go past.

Now you know how to find the contact points! Next thing to do is to know what this information can do for you. When the nose is deeper in the drop in area, there's less side to side play. This means the contact points will be closer together. But how does the nose go deeper in without all the gates being lined up?? Look at this next picture very closely; you've seen it before:




If you look at where the fence is on the wheels, you can just barely make out that it's only touching ONE wheel. The second one. The third one is slightly below and the first one is even more so lower than the 3rd. Now, imagine if the gate on wheel two was there under the fence. The fence would drop ever so slightly onto the next largest wheel, the 3rd one and the nose would drop further into the drop in area. That means there's less wiggle room. The contact points will be closer together by about a quarter of an increment. That's not a lot, but that's what we measure when we do manipulation. We pick up all the wheels, generally with a left rotation, and put them at 0. Then we spin the dial with right rotation to the contact area and measure the contact points while making sure not to pass 0 or else the wheel positions will be disturbed. We then turn left until we reach 0 again put all the wheels at 2.5 and measure the contact points again. Wash, rinse, and repeat at 5, 7.5, 10, and so on until you get to 97.5. That's 40 positions around the dial. We go 2.5 increments because these locks don't open on just that one combination, there is some error so 2.5 increments is sufficient. So basically since one wheel is bigger than the rest, we are graphing just the biggest wheel, not all of them. This flaw is unavoidable. The imperfections of machines make this happen. The third wheel usually is the wheel that the fence rests on. This is not just because of wheel size, but because the spring pushing the lever down is only pushing on the lever, on the side closest to the thirds wheel. It unbalances it and the side of the fence where the nose is, is pushed down further than the back of it. **ONTO THE GRAPHING!** Here's a graph paper you can use. I would recommend just recreating it and then scanning it and printing out copies. You want it to be full 8.5x11 page size.



Graph #1

So the first thing to do is to label your graph. Write Graph #1 AWL and then your lock model at the top. AWL means all wheels left. That's how we're going to be starting. This is important so that you can come back and know where you left off. Safe cracking doesn't have to be all at once, you can stop any time and come back later. In the 2nd to the top boxes on the left side of the paper you put the right contact point. You want the closest whole number. Let's say you have a contact point of 6 1 4 or 5 3 4, then put 6. If it's 6 1 2 you can put 6 or 7, doesn't matter. Then in the box above it, put 7. The box below, 5. Do the same with the left contact point and the bottom 3 boxes. It should look like this:



Now, pick up all the wheels with left rotation (spin left at least 3 or 4 times. You can feel the wheels being picked up) and park all wheels on 0. That means stop on 0, or put all the wheels there. Parking is the same thing as leaving a wheel on that number. When you dial a combination to open a safe lock, you are parking the 1st wheel on the 1st # and the 2nd wheel on the 2nd #.


The way you graph the number where the contact point is, is simple. The way the graph is divided, the horizontal lines stand for 1/4 of an increment. You want to be able to consistently read the dial and see if it's on 6 1/4, 6 3/8, 6 1/2, 6 5/8, etc. Going by 8ths is the best. An eighth is in between each horizontal line. So if the right contact point is 6 1/4 for all wheels on 0, you would go down from 0 (on top of the paper) to one line above the 6. Put a dot there. Same procedure for the left contact point.

Remember when I said that the contact points have to be felt from the inside out? If 0 is in between the two contact points for you, turn right to feel the left contact point (this is for all wheels left. Because if you have all wheels right, turning right even more would mess them up). Lightly move the dial until you encounter resistance. You should be moving the dial with enough force to move it, but light enough that the contact point stops the dial and your hand keeps moving on the surface of the dial but doesn't move the dial itself. It takes practice. Being able to take accurate contact readings is KEY TO EVERYTHING! Graph the number it stopped on. To read the right contact point, spin right rotation to the other side of 0 (because going the short way and spinning left will mess up the wheels on 0) and go slightly past the right contact point. Lightly turn left and read the right point. Then graph it.

If 0 is to the left of both contact points, just spin right and read both

contact points that way, making sure not to pass 0 and mess up the wheel positions. If 0 is to the right of both contact points, spin left and do the same thing.

After you've graphed the two contact points for 0, spin the dial left and pick up all the wheels again at 0. Turn to 2.5 and repeat the same procedure. It should look something like this:



This has two points on 6 and two points on 96.5. You want to repeat this process all the way around at every 2.5 increments. If you have a contact point on 5 1 4 or somewhere close to a number you're testing, you have to be careful not to disturb it when you take contact reading. Let's say you have 5 1 4 and 14 3 4 and your contact points. AWL to 5, right rotation just BARELY pass 5 1 4, try not to go completely

to 5. It's not too bad if you do though, just don't go past it! Spinning right, the wheels will pick up not quite where you left them with left rotation. The wheels will pick up a bit under 5 so you have some extra room to move between where the wheels are and the contact point.

Now, lightly feel the right contact point. You can spin the dial back and re-feel as many times as you want, just be careful not to disturb the wheels at 5. You can feel where the wheels are and where they pick up so you can get a sense of how far you can go before you disturb them. Now, when you test 15, put all wheels left rotation to 15 and turn the dial a couple increments right, past 14 3 4. When taking the contact point reading here, just make sure to do so lightly and not have the nose ride up on the drive cam. Turn too far and the wheels at 15 will be messed up. So graph the whole wheel pack and you'll get something like:

AWL graph #1

70 50 30 10 0 50 70 90 110 130 150 170 190 210 230 250 270 290 310 330 350 370 390 410 430 450 470 490 510 530 550 570 590 610 630 650 670 690 710 730 750 770 790 810 830 850 870 890 910 930 950 970 990 1010 1030 1050 1070 1090 1110 1130 1150 1170 1190 1210 1230 1250 1270 1290 1310 1330 1350 1370 1390 1410 1430 1450 1470 1490 1510 1530 1550 1570 1590 1610 1630 1650 1670 1690 1710 1730 1750 1770 1790 1810 1830 1850 1870 1890 1910 1930 1950 1970 1990 2010 2030 2050 2070 2090 2110 2130 2150 2170 2190 2210 2230 2250 2270 2290 2310 2330 2350 2370 2390 2410 2430 2450 2470 2490 2510 2530 2550 2570 2590 2610 2630 2650 2670 2690 2710 2730 2750 2770 2790 2810 2830 2850 2870 2890 2910 2930 2950 2970 2990 3010 3030 3050 3070 3090 3110 3130 3150 3170 3190 3210 3230 3250 3270 3290 3310 3330 3350 3370 3390 3410 3430 3450 3470 3490 3510 3530 3550 3570 3590 3610 3630 3650 3670 3690 3710 3730 3750 3770 3790 3810 3830 3850 3870 3890 3910 3930 3950 3970 3990 4010 4030 4050 4070 4090 4110 4130 4150 4170 4190 4210 4230 4250 4270 4290 4310 4330 4350 4370 4390 4410 4430 4450 4470 4490 4510 4530 4550 4570 4590 4610 4630 4650 4670 4690 4710 4730 4750 4770 4790 4810 4830 4850 4870 4890 4910 4930 4950 4970 4990 5010 5030 5050 5070 5090 5110 5130 5150 5170 5190 5210 5230 5250 5270 5290 5310 5330 5350 5370 5390 5410 5430 5450 5470 5490 5510 5530 5550 5570 5590 5610 5630 5650 5670 5690 5710 5730 5750 5770 5790 5810 5830 5850 5870 5890 5910 5930 5950 5970 5990 6010 6030 6050 6070 6090 6110 6130 6150 6170 6190 6210 6230 6250 6270 6290 6310 6330 6350 6370 6390 6410 6430 6450 6470 6490 6510 6530 6550 6570 6590 6610 6630 6650 6670 6690 6710 6730 6750 6770 6790 6810 6830 6850 6870 6890 6910 6930 6950 6970 6990 7010 7030 7050 7070 7090 7110 7130 7150 7170 7190 7210 7230 7250 7270 7290 7310 7330 7350 7370 7390 7410 7430 7450 7470 7490 7510 7530 7550 7570 7590 7610 7630 7650 7670 7690 7710 7730 7750 7770 7790 7810 7830 7850 7870 7890 7910 7930 7950 7970 7990 8010 8030 8050 8070 8090 8110 8130 8150 8170 8190 8210 8230 8250 8270 8290 8310 8330 8350 8370 8390 8410 8430 8450 8470 8490 8510 8530 8550 8570 8590 8610 8630 8650 8670 8690 8710 8730 8750 8770 8790 8810 8830 8850 8870 8890 8910 8930 8950 8970 8990 9010 9030 9050 9070 9090 9110 9130 9150 9170 9190 9210 9230 9250 9270 9290 9310 9330 9350 9370 9390 9410 9430 9450 9470 9490 9510 9530 9550 9570 9590 9610 9630 9650 9670 9690 9710 9730 9750 9770 9790 9810 9830 9850 9870 9890 9910 9930 9950 9970 9990 10010 10030 10050 10070 10090 10110 10130 10150 10170 10190 10210 10230 10250 10270 10290 10310 10330 10350 10370 10390 10410 10430 10450 10470 10490 10510 10530 10550 10570 10590 10610 10630 10650 10670 10690 10710 10730 10750 10770 10790 10810 10830 10850 10870 10890 10910 10930 10950 10970 10990 11010 11030 11050 11070 11090 11110 11130 11150 11170 11190 11210 11230 11250 11270 11290 11310 11330 11350 11370 11390 11410 11430 11450 11470 11490 11510 11530 11550 11570 11590 11610 11630 11650 11670 11690 11710 11730 11750 11770 11790 11810 11830 11850 11870 11890 11910 11930 11950 11970 11990 12010 12030 12050 12070 12090 12110 12130 12150 12170 12190 12210 12230 12250 12270 12290 12310 12330 12350 12370 12390 12410 12430 12450 12470 12490 12510 12530 12550 12570 12590 12610 12630 12650 12670 12690 12710 12730 12750 12770 12790 12810 12830 12850 12870 12890 12910 12930 12950 12970 12990 13010 13030 13050 13070 13090 13110 13130 13150 13170 13190 13210 13230 13250 13270 13290 13310 13330 13350 13370 13390 13410 13430 13450 13470 13490 13510 13530 13550 13570 13590 13610 13630 13650 13670 13690 13710 13730 13750 13770 13790 13810 13830 13850 13870 13890 13910 13930 13950 13970 13990 14010 14030 14050 14070 14090 14110 14130 14150 14170 14190 14210 14230 14250 14270 14290 14310 14330 14350 14370 14390 14410 14430 14450 14470 14490 14510 14530 14550 14570 14590 14610 14630 14650 14670 14690 14710 14730 14750 14770 14790 14810 14830 14850 14870 14890 14910 14930 14950 14970 14990 15010 15030 15050 15070 15090 15110 15130 15150 15170 15190 15210 15230 15250 15270 15290 15310 15330 15350 15370 15390 15410 15430 15450 15470 15490 15510 15530 15550 15570 15590 15610 15630 15650 15670 15690 15710 15730 15750 15770 15790 15810 15830 15850 15870 15890 15910 15930 15950 15970 15990 16010 16030 16050 16070 16090 16110 16130 16150 16170 16190 16210 16230 16250 16270 16290 16310 16330 16350 16370 16390 16410 16430 16450 16470 16490 16510 16530 16550 16570 16590 16610 16630 16650 16670 16690 16710 16730 16750 16770 16790 16810 16830 16850 16870 16890 16910 16930 16950 16970 16990 17010 17030 17050 17070 17090 17110 17130 17150 17170 17190 17210 17230 17250 17270 17290 17310 17330 17350 17370 17390 17410 17430 17450 17470 17490 17510 17530 17550 17570 17590 17610 17630 17650 17670 17690 17710 17730 17750 17770 17790 17810 17830 17850 17870 17890 17910 17930 17950 17970 17990 18010 18030 18050 18070 18090 18110 18130 18150 18170 18190 18210 18230 18250 18270 18290 18310 18330 18350 18370 18390 18410 18430 18450 18470 18490 18510 18530 18550 18570 18590 18610 18630 18650 18670 18690 18710 18730 18750 18770 18790 18810 18830 18850 18870 18890 18910 18930 18950 18970 18990 19010 19030 19050 19070 19090 19110 19130 19150 19170 19190 19210 19230 19250 19270 19290 19310 19330 19350 19370 19390 19410 19430 19450 19470 19490 19510 19530 19550 19570 19590 19610 19630 19650 19670 19690 19710 19730 19750 19770 19790 19810 19830 19850 19870 19890 19910 19930 19950 19970 19990 20010 20030 20050 20070 20090 20110 20130 20150 20170 20190 20210 20230 20250 20270 20290 20310 20330 20350 20370 20390 20410 20430 20450 20470 20490 20510 20530 20550 20570 20590 20610 20630 20650 20670 20690 20710 20730 20750 20770 20790 20810 20830 20850 20870 20890 20910 20930 20950 20970 20990 21010 21030 21050 21070 21090 21110 21130 21150 21170 21190 21210 21230 21250 21270 21290 21310 21330 21350 21370 21390 21410 21430 21450 21470 21490 21510 21530 21550 21570 21590 21610 21630 21650 21670 21690 21710 21730 21750 21770 21790 21810 21830 21850 21870 21890 21910 21930 21950 21970 21990 22010 22030 22050 22070 22090 22110 22130 22150 22170 22190 22210 22230 22250 22270 22290 22310 22330 22350 22370 22390 22410 22430 22450 22470 22490 22510 22530 22550 22570 22590 22610 22630 22650 22670 22690 22710 22730 22750 22770 22790 22810 22830 22850 22870 22890 22910 22930 22950 22970 22990 23010 23030 23050 23070 23090 23110 23130 23150 23170 23190 23210 23230 23250 23270 23290 23310 23330 23350 23370 23390 23410 23430 23450 23470 23490 23510 23530 23550 23570 23590 23610 23630 23650 23670 23690 23710 23730 23750 23770 23790 23810 23830 23850 23870 23890 23910 23930 23950 23970 23990 24010 24030 24050 24070 24090 24110 24130 24150 24170 24190 24210 24230 24250 24270 24290 24310 24330 24350 24370 24390 24410 24430 24450 24470 24490 24510 24530 24550 24570 24590 24610 24630 24650 24670 24690 24710 24730 24750 24770 24790 24810 24830 24850 24870 24890 24910 24930 24950 24970 24990 25010 25030 25050 25070 25090 25110 25130 25150 25170 25190 25210 25230 25250 25270 25290 25310 25330 25350 25370 25390 25410 25430 25450 25470 25490 25510 25530 25550 25570 25590 25610 25630 25650 25670 25690 25710 25730 25750 25770 25790 25810 25830 25850 25870 25890 25910 25930 25950 25970 25990 26010 26030 26050 26070 26090 26110 26130 26150 26170 26190 26210 26230 26250 26270 26290 26310 26330 26350 26370 26390 26410 26430 26450 26470 26490 26510 26530 26550 26570 26590 26610 26630 26650 26670 26690 26710 26730 26750 26770 26790 26810 26830 26850 26870 26890 26910 26930 26950 26970 26990 27010 27030 27050 27070 27090 27110 27130 27150 27170 27190 27210 27230 27250 27270 27290 27310 27330 27350 27370 27390 27410 27430 27450 27470 27490 27510 27530 27550 27570 27590 27610 27630 27650 27670 27690 27710 27730 27750 27770 27790 27810 27830 27850 27870 27890 27910 27930 27950 27970 27990 28010 28030 28050 28070 28090 28110 28130 28150 28170 28190 28210 28230 28250 28270 28290 28310 28330 28350 28370 28390 28410 28430 28450 28470 28490 28510 28530 28550 28570 28590 28610 28630 28650 28670 28690 28710 28730 28750 28770 28790 28810 28830 28850 28870 28890 28910 28930 28950 28970 28990 29010 29030 29050 29070 29090 29110 29130 29150 29170 29190 29210 29230 29250 29270 29290 29310 29330 29350 29370 29390 29410 29430 29450 29470 29490 29510 29530 29550 29570 29590 29610 29630 29650 29670 29690 29710 29730 29750 29770 29790 29810 29830 29850 29870 29890 29910 29930 29950 29970 29990 30010 30030 30050 30070 30090 30110 30130 30150 30170 30190 30210 30230 30250 30270 30290 30310 30330 30350 30370 30390 30410 30430 30450 30470 30490 30510 30530 30550 30570 30590 30610 30630 30650 30670 30690 30710 30730 30750 30770 30790 30810 30830 30850 30870 30890 30910 30930 30950 30970 30990 31010 31030 31050 31070 31090 31110 31130 31150 31170 31190 31210 31230 31250 31270 31290 31310 31330 31350 31370 31390 31410 31430 31450 31470 31490 31510 31530 31550 31570 31590 31610 31630 31650 31670 31690 31710 31730 31750 31770 31790 31810 31830 31850 31870 31890 31910 31930 31950 31970 31990 32010 32030 32050 32070 32090 32110 32130 32150 32170 32190 32210 32230 32250 32270 32290 32310 32330 32350 32370 32390 32410 32430 32450 32470 32490 32510 32530 32550 32570 32590 32610 32630 32650 32670 32690 32710 32730 32750 32770 32790 32810 32830 32850 32870 32890 32910 32930 32950 32970 32990 33010 33030 33050 33070 33090 33110 33130 33150 33170 33190 33210 33230 33250 33270 33290 33310 33330 33350 33370 33390 33410 33430 33450 33470 33490 33510 33530 33550 33570 33590 33610 33630 33650 33670 33690 33710 33730 33750 33770 33790 33810 33830 33850 33870 33890 33910 33930 33950 33970 33990 34010 34030 34050 34070 34090 34110 34130 34150 34170 34190 34210 34230 34250 34270 34290 34310 34330 34350 34370 34390 34410 34430 34450 34470 34490 34510 34530 34550 34570 34590 34610 34630 34650 34670 34690 34710 34730 34750 34770 34790 34810 34830 34850 34870 34890 34910 34930 34950 34970 34990 35010 35030 35050 35070 35090 35110 35130 35150 35170 35190 35210 35230 35250 35270 35290 35310 35330 35350 35370 35390 35410 35430 35450 35470 35490 35510 35530 35550 35570 35590 35610 35630 35650 35670 35690 35710 35730 35750 35770 35790 35810 35830 35850 35870 35890 35910 35930 35950 35970 35990 36010 36030 36050 36070 36090 36110 36130 36150 36170 36190 36210 36230 36250 36270 36290 36310 36330 36350 36370 36390 36410 36430 36450 36470 36490 36510 36530 36550 36570 36590 36610 36630 36650 36670 36690 36710 36730 36750 36770 36790 36810 36830 36850 36870 36890 36910 36930 36950 36970 36990 37010 37030 37050 37070 37090 37110 37130 37150 37170 37190 37210 37230 37250 37270 37290 37310 37330 37350 37370 37390 37410 37430 37450 37470 37490 37510 37530 37550 37570 37590 37610 37630 37650 37670 37690 37710 37730 37750 37770 37790 37810 37830 37850 37870 37890 37910 37930 37950 37970 37990 38010 38030 38050 38070 38090 38110 38130 38150 38170 38190 38210 38230 38250 38270 38290 38310 38330 38350 38370 38390 38410 38430 38450 38470 38490 38510 38530 38550 38570 38590 38610 38630 38650 38670 38690 38710 38730 38750 38770 38790 38810 38830 38850 38870 38890 38910 38930 38950 38970 38990 39010 39030 39050 39070 39090 39110 39130 39150 39170 39190 39210 39230 39250 39270 39290 39310 39330 39350 39370 39390 39410 39430 39450 39470 39490 39510 39530 39550 39570 39590 39610 39630 39650 39670 39690 39710 39730 39750 39770 39790 39810 39830 39850 39870 39890 39910 39930 39950 39970 39990 40010 40030 40050 40070 40090 40110 40130 40150 40170 40190 40210 40230 40250 40270 40290 40310 40330 40350 40370 40390 40410 40430 40450 40470 40490 40510 40530 40550 40570 40590 40610 40630 40650 40670 40690 40710 40730 40750 40770 40790 40810 40830 40850 40870 40890 40910 40930 40950 40970 40990 41010 41030 41050 41070 41090 41110 41130 41150 41170 41190 41210 41230 41250 41270 41290 41310 41330 41350 41370 41390 41410 41430 41450 41470 41490 41510 41530 41550 41570 41590 41610 41630 41650 41670 41690 41710 41730 41750 41770 41790 41810 41830 41850 41870 41890 41910 41930 41950 41970 41990 42010 42030 42050 42070 42090 42110 42130 42150 42170 42190 42210 42230 42250 42270 42290 42310 42330 42350 42370 42390 42410 42430 42450 42470 42490 42510 42530 42550 42570 42590 42610 42630 42650 42670 42690 42710 42730 42750 42770 42790 42810 42830 42850 42870 4

This graph is how you find the gates. So you'd understand how it's kind of important. Taking the correct contact point readings means an accurate graph! So make sure when you take contact point readings, it always consistent! It's best to use a light touch and make sure that the point you take is right where the nose touches the drive cam. But if you use the SAME EXACT amount of force each time (even if the nose does ride up on the drive cam a little) then you should still be fine. Not everyone will have the exact same points because everyone feels with differing amounts of force, but relatively, the graphs should show the same thing.


Now for you to know what a gate will look like on your graph. When the fence is resting on the wheel pack and the gate of the largest wheel is under it, it will be lower right? Yup. And then when it's moved off, it will be higher right? Yup again! The gate on the wheels are shaped like a U so the points on the paper should resemble that. It will drop and them go back up. Now think hard and you'll remember the right side of the drop in area is sloped. This will give a greater change in contact point than the other side. The left contact point reading will be less dramatic but will help confirm a gate on that number. So a typical gate will look like a drop for a couple numbers and then back up again on the right contact point and then up for a couple numbers and then back down again for the left contact point.

But this isn't the only way a gate looks like. A gate can drop but not go back up in a number or two. Let's say it makes a drop that is 4 increments wide. The whole thing would be too wide to be a gate so the gate would be right after the drop. Another way a gate can indicate is not by a drop at all, but by a small rise on either side. i.e ..^..^..

It's very important for you to know that when gate indicates, the indications will be at least $\frac{1}{4}$ of an increment on the right contact point. On better manufactured locks, it can indicate only $\frac{1}{8}$ of an increment

but on any lock you'll be starting with, you want to look for $\frac{1}{4}$ of an increment difference.

So it dips down for a couple numbers and then back up (with the right contact point). With the left, it'll go up and then back down. Think about it, when the two contact points get closer, the left one increases in number). Where in this graph do you see a dip in the contact point and a corroboratory rise in the left contact point? Si! It drops at around 35 for the RCP (right contact point) and up at 37.5 for the LCP. It can sometimes be in the same spot but it can also be a little off like it is here. Remember, the gate will only drop for about 2 increments. Now you want to do something called amplification. Remember how we went every 2.5 increments? Go every 1 increment from 31-39 and graph that in a different color. You'll get something like this:



This is to find the center of the gate. Going every 2.5 increments isn't precise but it lets us find the gate. Now we need to know the exact number it's on. So for the RCP's it's 32-35. Find the middle of that. It's 33.5. Now do the same for the LCP's. It's 35.25. Then find the middle of these two numbers; it's 34.375. Congratulations!!! That's one of the numbers! You don't really have to dial in 34.375, you can dial 34.5 or 34 1 4. Never go off by more than 1 4 increment! Now to find out which number in the combination it is :P Is this seeming like a long process yet? It should, but with practice you can get your time to 5-10min!

High low testing

The way you can determine which wheel the number belongs to is something called high low testing. Recall that the nose drops lower when the gate is under the fence. The contact area will be narrower. Now, when the wrong number is entered, the contact area will be wider. So we want to put the number we found on two of the wheels and throw the other wheel off. And do this with each wheel. So that in two of the tests, the gate will be under the fence and in the other it won't. So in one of those tests, we should have a contact area that is significantly wider since the gate will not be under the fence for one of the tests. We start with the first wheel being thrown off by 10 increments under. This is a low test. It doesn't have to be 10, it should be at least 10 though. This is just so it has more isolation.

For example: We find 34.375 (we'll make it easy and say 34.5)

Low testing:

R24.5 L34.5 L34.5 (Right 4 times to 24.5 and left 3 times to 34.5)

L34.5 R24.5 L34.5 (This puts only the 2nd wheel on 24.5)

L34.5 L34.5 R24.5 (Left 4 times to 34.5 and right twice to 24.5)

Each of these times you want to measure both contact points and write them down. Then find the space in between them. That's the size of the contact area. Now, this is where a thorough understanding of how safes work come into play. So let's say these 3 test show this:

LCP: 97 RCP: 6 Contact area 9

LCP: 97 RCP: 6 1/4 Contact area 9 1/8

LCP: 96 3/4 RCP: 6 1/4 Contact area 9 2/4

The most likely wheel to have 34.5 as a the combination is wheel 3. But we need to do High testing as well (it's not required if the indications from low testing is good enough. It just helps support it):

High test:

R44.5 L34.5 L34.5 (Right 4 times to 44.5 and left 3 times o 34.5)

L34.5 **R44.5 L34.5** (This is putting only 2nd wheel on 44.5)

L34.5 L34.5 **R44.5** (Left 4 times to 34.5 and right 2 times to 44.5)

and say we get:

LCP: 97 RCP: 6 Contact area 9

LCP: 97 RCP: 6 Contact area 9

LCP: 96 7/8 RCP: 6 1/8 Contact area **9 1/4**

Now both test show wheel 3 to indicate. So we know so far the combination is ?-?-34.5. This is why an understanding of how wheel pick up is needed. You need to know how to put each wheel at a specific number and know which wheel is at what number. IT IS CRUCIAL!!!

I included a little chart that helps you with this in the very back of the book for you to use. Even though you may not ever use high low testing since I describe a better alternative (in my opinion!) to it later, it's there if you want it :)

VERY IMPORTANT NOTE! Notice how we found 34.5 with AWL rotation. In all the high low tests every time we put a wheel on 34.5 is is with LEFT rotation. This is important. Parking with right rotation will put the wheel slightly off. The width of the fly and drive pin on each wheel makes it so that when you approach each wheel from the opposite direction, it will pick up in a slightly different spot than how you left it. Compensating for this will be covered later under "Rotational Conversion".

Graph #2

So start graph number two like you did number one with all the titles and all. But since you have wheel 3 going left you will have the other two wheels going right. It would be titled with LOCK TYPE Graph #2 1&2 AR / 3 @ L34.5. This means you are graphing wheels 1&2 with right rotation and wheel 3 is parked at 34.5 with left rotation when you take contact readings. AR means around right.

To graph this you pick up all wheels with right rotation and stop at 0. Then you turn left and pick up wheel 3 from 0 and stop at 34.5. Then you graph your contact points. Next turn right and pick up the wheel from 34.5 and the other 2 wheels at 0 and turn to 97.5. The 1st and second wheel will pick up at the same time so no need to do an extra rotation. You'll get better at this as you go. Then repeat the whole process, turning left to pick up wheel 3, park it at 34.5 and read contact points. Just be careful when you pass by 34.5 and you try to read 32.5. You're going to mess up the wheels so you'll have to reset the first wheel. You can just start at 32.5 instead of 0 to avoid this problem. That is what I recommend. So the whole thing should look like:

516 6700 brief / 3 @ L 34.5 graph #2

70 50 45 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100


67

57 0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100

96

95

Now, there's not an indication like there was in the last graph. There could be, but here there's not because I'm illustrating a principle to you. Things don't always work as perfectly as they did in the first graph I showed you. Since you are graphing the wheels with RIGHT rotation, you read the graph from right to left. The first graph was AWL so you read it left to right. Gate signatures can vary and can also be directional, as in only read as a gate from one direction. A down and up signature is the most common type you'll get. The next one is where it drops and doesn't rise back up within a reading or two. It can rise back up, but not immediately after. That's the case in this graph. We see after 70, it drops and takes a while to come back up. That is a gate signature. The whole thing is way too wide to be a gate so the gate is going to be right under 70. Amplify your findings and you should have this:



Since gates are usually about 3 increments wide I would choose 67.5 as the gate center not 68. Now do high low test again and find which wheel is indicating. Since we already know 34.5 is the 3rd wheel we only need to do high low tests for 2 wheels not all 3.

Pay attention to the rotation direction. It's different than the first high-low tests we did because this number was found with right rotation. So every time we go to 67.5, it needs to be right rotation.

Low test:

L57.5 R67.5 R67.5 RCP: 6 LCP: 96.5 Contact area: 9 $\frac{1}{2}$
R67.5 L57.5 R67.5 RCP: 6 $\frac{1}{4}$ LCP: 96.5 Contact area: 9 $\frac{3}{4}$

L57.5 R67.5 R67.5 RCP: 6 $\frac{1}{4}$ LCP: 96 $\frac{3}{4}$ Contact area: 9 $\frac{1}{2}$
R67.5 L57.5 R67.5 RCP: 6 $\frac{1}{2}$ LCP: 96 $\frac{1}{2}$ Contact area: 9 $\frac{1}{2}$

Let's say wheel two indicates like in the example, so now you know the combo is ?-67.5-34.5. Now, just dial in 0-67.5-34.5, 2.5-67.5-34.5, 5-67.5-34.5 and so on until it opens. You can graph this until it opens just in case the lock does not open you have something extra to refer to but usually it's not needed to graph on the final run. If you read Oldfast's chronicles on keypicking.com you know he goes by every 2 increments. This is because it is possible to miss a number every 2.5 increments if it's a lucky s&g 6730. Personally I graph with 2.5 because I know my 6730, even though it has +/- .5 dialing tolerance, it's not that precise and will work with 2.5. With experience, you'll be able to get your own way of doing it.

Let's say in your first graph, the 2nd wheel indicated first and not the 3rd. You would graph the second graph by going all wheels LEFT to 0, right 3 times to 34.5 (actually, not 34.5 but that will be explained later in Rotational Conversion), left twice to 0. Repeat with 97.5 instead of 0.

Basically, you're dialing in a combination each time because the first wheel has to be set, the second wheel has to be set in a different place than the 1st, and then the 3rd wheel has to be set different than the 2nd. If the 3rd wheel reads first, the first two wheels are parked in the same place together so there's no extra dialing for the second wheel.

If the 1st wheel reads first, then it's easy! The 2nd and 3rd wheel can be graphed without disturbing the 3rd wheel at all! If you start at 32.5, you won't pass 34.5 and mess up the first wheel there. This doesn't happen often though. The third wheel is the wheel that indicates most of the time.

Rotational Conversion

Now if you graph with AWR and the 1st or 3rd wheel indicates or you graph AWL and the second wheel indicates first, then you need to make sure you dial to the right number. If the combo is 30-90-60, it's going to be dialed L-R-L traditionally. If you dial it in R-L-R, and then left to drop in area and right to retract bolt, it won't even drop in. The gates will be just barely off from underneath the fence. That's because with each wheel, the width of the fly and drive pins add up and push each wheel off more. The 3rd wheel will be the least affected because there's only the drive pin of the drive cam. The 1st wheel has to deal with the drive cam, fly on the 2nd and 3rd wheel, and the drive pins on those wheels as well.

To fix this, first pick up all wheels and take them to any number. I like 50 because it's far from the contact points and I won't confuse the wheels picking up from the contact points. You can go right or left. In this example I picked up all wheels right. Now start turning left and right before you get to 50, slow down and feel for where the 3rd wheel will pick up. It might be 50 or it might be a bit off. Act like you're feeling for a contact point, be light and gentle. Let's say it picked up at 50.5. So the

first wheel is .5 off. Now go around again and feel for the second wheel being picked up. Let's say that's 51.5. So the 2nd wheel is 1.5 off. Now do the same for the 3rd and let's say it picks up at 52.5. So the 3rd wheel is 2.5 off. I like to write them down like this: .5-1.5-2.5 just so I know which wheel is off by what amount. So for the combination of 30-90-60 L-R-L converting to R-L-R, we start by dialing 30 with right rotation. But we go PAST by .5 to 29.5. This puts the gate centered under the fence. For 90, we go left to 90 and PAST by 1.5 to 91.5. Same thing with the 3rd wheel. Go right rotation PAST 60 by 2.5 to 57.5. Then left until you feel the nose drop in to the drive cam and turn right to retract the bolt!

Ch. 3: Alternatives

There are different ways to graph and different ways to tell which wheel is indicating rather than using the hi-low method.

Wheel isolation

Hi/low tests are annoying and complicated but the good news is that you don't have to do them! Since wheel 3 indicates most of the time, you can just park wheels 1&2 in the "forbidden zone" (the contact area. It's called that because you're not supposed to set the 3rd number to a number inside it) and then just move wheel 3 through the area you think there's a gate in. If the contact points indicate a gate, then you know it's wheel 3 because nothing else is moving! If nothing indicates, you can do the same for wheels 1&2 separately.

Alternative if 2nd wheel reads 1st

If the second wheel reads first, basically what you are doing is entering a new combination every time you test a number for the 2nd graph. 0-34.5-0, 2.5-34.5-0, etc. The first wheel has to be moved so you end up taking so much time! An easier way is to just put the 1st and 2nd wheel on the gate for the 2nd wheel and just move wheel 3 around. In the first place, wheel 3 usually reads first, if not, the wheel 3 is most likely going to read 2nd. This is way faster and has a high chance of you finding the second gate so I highly recommend you do this. This is what I do when the 2nd wheel reads first in a lock.

Alternative to AWL

The first obvious answer would be AWR, all wheels right. Yup, you can do that too if the lock isn't indicating any gates with AWL. It's just that 2 numbers in the combo are set with left rotation and the 3rd wheel usually indicates first; and the 3rd wheel is set with left rotation. When you set a wheel at let's say, 50, with left rotation, it will be in a different spot than if you set it at 50 with right rotation. I'll explain how to compensate for this later. You can also graph just one wheel such as the 3rd wheel so that you don't have to do hi-low or isolate wheels to find which wheel is indicating because it's the only wheel moving. But again, this is only faster if the 3rd wheel indicates first.

Make it all go faster

If you want to get fast at manipulation, you have to take some shortcuts. Don't graph. It takes WAY too much time! And only take right contact points, the right ones are enough of an indication by themselves because of the slope of the drive cam. Just go AWL and look for a suitable drop, amplify, replace your hi/low tests with wheel isolation (this will be covered later), then move on to the next wheel. Keep going like this. Or if you're ok with some risk, just run the 3rd wheel around with the first two wheels right in the middle of the contact area until you find a gate and then amplify. That way, you don't have to do hi/low testing; you know it's on wheel 3! Repeat for wheel 2. You can get 5-10min manipulations this way!

Ch. 4: Tips and tricks

So the main purpose I wrote all this was to help people with no knowledge of safe cracking. When I started out I had many problems I had that I wasn't sure about and this section is to address those issues for others that might have those problems. If the lock doesn't open:

- **High-Low tests:** Make sure you are getting the high/low tests right. Put the right wheels on the right numbers and in the [correct rotation](#). Remember: Wheel 1 is the first number in the combination so it is the wheel that's closest to the dial and gets picked up [last](#). Wheel 3 is the last number and gets picked up [first](#). Don't forget that or to use correct rotation.
- **Dial accurately:** Dial within 1/8 of an increment of where you are trying to park a wheel. It's best if you get EXACTLY on that number. If your contact point feels really faint, here's a technique a guy that goes by the name Datagram taught me. Get close to the contact point and then turn the dial by [lightly](#) running your thumb along the dial with just enough friction to turn the dial. When it hits the contact point, it should stop exactly on it. Make sure you DO NOT increase the force otherwise the nose will ride up on the drive cam and you'll get a false reading. This takes practice. Try having the back of the lock open as you do this and look at it/have someone else look for you/or record it so you know just how much force to put on the dial with your thumb. If you have too light of force, you'll randomly stop and think the contact point is there.
- **Read correctly:** Make sure you are [consistent](#) with your readings. This is a big thing. If the increments on the dial are really wide and it's hard to pinpoint exactly where the dial is, tape a needle to the index mark you dial to and a piece of tape tapered to a point on each contact point. This helps greatly with readings since you need to be consistent down to the

1/8 increment. What you see to be 3/8 could be what I see to be 2/4 or vice versa. That doesn't matter as long as you are consistent with all your readings. Another problem is you have to make sure that you are viewing the dial from the same angle! Looking at it from different angles can give you varied readings. You can also tape paper on. This little setup was done in 30 sec and it works well enough to tell that in the picture it's on 8 3/8 not 8 1/2 or 8 1/4.



- **Feel consistently:** Like I said before: It's best to use a light touch and make sure that the point you take is right where the nose touches the drive cam. As long you use the SAME EXACT amount of force each time though (even if the nose does ride up on the drive cam a little) then you should still be fine. Not everyone will have the exact same points on their graphs because everyone feels with differing amounts of force, but relatively, the graphs should show the same thing. Graph the first graph with the same combination several times without looking at previous

graphs until you get the same graph every time! That way, you'll improve on your touch. It'll take time but it's worth it!

- **Taking contact points exercise:** If you're having trouble feeling accurately for contact points, there are exercises you can do to improve your touch. If you take the back cover off and put the dial where you think the contact point is, you can look and see if you're riding up on the drive cam or not. A smart phone or a mirror helps with this. Another way would be to have someone else look and see when you touch the contact point and when you think you do. Sometimes if you use too light of a touch, you'll stop before you even hit the drive cam.


- **Dial efficiently:** In order to save time when manipulating, you have to know how to dial in test combinations without extra rotations. Let's say the contact area is 85-95 and you found the second number in the combination to be 30 and the third to be 50. You dial 0-30-50. For the next test at 2.5-30-50, you rotate left to pick up 0, then when you pass 30, it picks up. When you pass 50, that picks up. So you only have to do one rotation to pick up all the wheels. But if the combination was ?-50-30 then after the first test of 0-50-30, you turn left from the contact area to 0 and pick up the first wheel, then continue to 50 and pick up the second wheel, and now you have to make a second rotation to make it to 30. So it takes a little more than 2 rotations. Carefully study how the wheels pick up with the back cover off and you'll understand pretty quickly. Also, try to make rotations without having to change your grip as much. Try to do it all in one movement. That saves more time than you would think!

Troubleshooting

-**If you can't find any gates:** There may be times when you graph but can't find any indications of a gate at all. A reason might be because the lock you are working on has a dialing tolerance of +/- .5 such as the S&G 6730. With these locks, a gate could appear as normal with a 2 increment drop, only a 1 increment drop, or with no indication at all. Now, in the latter two cases, you want to re-graph with 2 increment readings instead of 2.5. This will cause the gate to appear as normal.

-**Two contact points on one contact point:** Sometimes when taking contact readings, you might come across a situation where the contact point will feel really soft and then you turn a bit more and it's more solid. Sort of like two contact point on one. This can be really confusing but what going on here is that there is a bump on the drive cam. Here's a picture to illustrate what is going on:





The first picture shows a normal right contact point. The second picture is one with a bump. What you're feeling is the bump and then the slope again. The arrows point to the two different parts that you can feel. When this happens you can take either point but you need to make sure you take the same one every time. Some problems might arise if you take the second but much more noticeable one. When a gate is present under the fence, the bump won't matter because the nose will be low enough it won't be scraping by it. Because of this, I take the first reading every time. It just saves on some uncertainty.

-**High/low testing isn't working:** If your high/low tests are inconclusive and don't show enough change to accurately indicate which wheel is indicating, make sure you're doing it right; that all rotations are correct. If you found a gate with left rotation, it ALWAYS has to be set with left rotation. If that's not the problem, then I would recommend switching to wheel isolation. I would recommend that anyways as it is less complicated and generally faster. Once you find the gate center, park wheels 1 and 2 in the middle of the contact area and move wheel 3 to a couple increments before the gate and then to the center. If there is a

significant drop, then the gate belongs to wheel 3! If not, do the same for wheels 2 and 1. Only 1 wheel should be changing positions, the other two should always be in the same spot in the contact area so the gate can only belong to the wheel that is moving. If none indicate this way, you probably don't have a gate. Look for another indication or try graphing with AWR or AWL depending on what you started with.

-**If all else fails:** You want to make sure you aren't following these instruction blindly. You want to think and adapt it. Make sure you always know which wheel is moving and where it is. You have to be able to put the right wheel, with the right rotation, to the number that you want to put it on. One of the biggest mistakes is wrong rotation, or picking up the wrong wheel. That is why knowing how the wheels interact with each other and move is the most important thing. You have to accurately visualize the wheel pack in your mind.

Chapter 5: LaGard 3330, Mosler, and Diebold

As explained, the LaGard has a masking effect or wheel shadowing, whatever you want to call it. This means the graphs will look like it has multiple hills/a giant hill or mountain in it. The reason behind this anomaly is that the wheels are more oval in shape. If you go back and take a look at the LaGard wheel shape, you'll see that little arm on it. The one used to change the combination. It puts pressure on the silver wheel center in one direction only. So that pressure transfers to the other side of the wheel and slightly deforms the wheel into an oval shape. An S&G wheel has two arms and thus cancels each other out quite well.

The first thing to do is to just try to manipulate your 3330 normally. If that doesn't work then move onto these techniques. Because of how the wheels are oval, it makes predicting the general location of where the gate will be easier. The location of the gate and the location of the combo changing arm will always be in the same place in respect to each other. And with the way that the arm deforms the wheel, the gate appears ~90 degrees away from the top of the oval. That's $\frac{1}{4}$ turn or 25 increments. So, make a graph first with AWL or AWR and find the highest point. The gate for that wheel will be about 25 increments away, either direction. Of course, you still have to find out which wheel that would be. I credit this method to Altashot from keypicking.com. Thanks Altashot!

These next tips help you with finding out which wheel is causing a hill on your graph.

If you couldn't get your LaGard open with the above method, try one of the ones below that matches your situation. Or if you want to learn how

to know which wheel is causing a hill on your graph.

For graphs with one big major hill in it:

First thing, make a first graph and find the lowest point on the graph. I'm assuming you did AWL or

AWR. This means that low point, is a low point for ALL wheels. No wheel has a high point there or else it would not be low. Do something similar to a high-low test now. Put two wheels on that low point and one at the highest point. Do it for each wheel and find contact area. The widest contact area will belong to the wheel that has the big hill. Now put that wheel on the lowest area and graph the other two wheels. Keep doing this to find the highs and lows of each wheel and try to "unmask" the other wheels.

For graphs with multiple, distinct, hills:

Do the same thing as previous but for each hill. Tag each hill to a wheel so you know which wheels to park in which spot to reveal the gates on the other wheels. Put wheels 1&2 on their lowest point and isolate wheel 3 and graph just that wheel. If that doesn't work, try with just wheel 1 or just wheel 2. I prefer to try wheel 3, then 2, then 1. 1 is last because it takes longest to graph that one when isolating it.

Another way!

Take readings every 10 increments and then amplify the lowest point starting from the previously graphed point. Find out which wheel is indicating there with the above methods. Let's say wheel 3 had that point. Graph a second graph with the same 10 increment method while wheel 3 on its low spot. Find another low spot on the graph and the wheel it belongs to. Basically, you're acting like that low point is a number in the combination even though it might not be. Do a third graph with the other two wheels on their low spots. If it doesn't open, put the final wheel on its low spot. You should now have low spots for all the

wheels. Put wheels 1&2 on their low points and graph just wheel 3. They should allow wheel 3 to be graphed. Do this for wheels 1&2 if wheel 3 doesn't show up. Just keep finding lower and lower points and eventually one of them will be an actual gate.

Mosler and Diebold

If you happen to have a group 2 Mosler or Diebold, things will have to be done a bit differently. For Moslers, the drive cam is closest to the dial so the wheels pick up from front to back instead of back to front as in a normal scenario. Just make sure you can account for this and that you always know which wheel is moving and where it is.

Some Diebolds, such as the 177's, have a differently shaped drive cam and nose. The nose is U shaped and so is the drop in area on the drive cam. Some might actually be slightly tilted so that the left contact point is the one that will indicate more of a change. So either take both contact points or be careful that you're taking the correct contact point. When taking only the left contact point, everything else is the same, just make sure to look for a rise on the left contact point instead of a drop on the right.

Acknowledgements

Thanks to everyone at keypicking.com! Especially Oldfast for large portions of information as well as getting me started in this hobby! And to my girlfriend Dayana for the motivation to write this :)

The way I first got started into this hobby was when I was browsing through keypicking.com and I saw a thread labeled “Oldfast safe chronicles”. I was intrigued and took a look. I always imagined safe cracking to need tools or such a crazy amount of skill. Oldfast lays things out in such a simple yet alluring way that I couldn't help but be captivated. Whenever I would hit a roadblock reading other writings on manipulation, either his chronicles or he himself would usually be the way I was able to keep going.

The very first method described on defeating the LaGard 3330 is a method from Altashot. This is not my method. I want to credit him with this and thank him for it as it has greatly helped me and I hope it will greatly help you as well!

I also want to give a shout out and dedicate this book to my girlfriend. She has been such an encouragement that I don't think I would've finished this book without her. People say the best way to learn is to teach and I've found that to be true. Just by teaching her how to manipulate, has opened my eyes to the variety of problems different people might have when learning. Not everyone struggles with the same things and so I have to try and be as thorough as possible to help everyone. So if you find yourself struggling, try to teach a friend or family member how to do this and you'll realize you know more than you think! Thanks for reading this and good luck!

Sources

Safe Ventures. "News." *Safe Ventures*. N.p., n.d. Web. 01 Sep. 2013.
<<http://www.safeventures.com/news.php?id=16>>.

Altashot. "Altashot's Story." *Photobucket*. N.p., 27 Jan. 2014. Web. 01 Sep. 2013.
<<http://s1155.photobucket.com/user/Altashot/story/71817>>.

Oldfast. "Oldfast: Safe Chronicles." *Keypicking.com*. N.p., 13 Dec. 2012. Web. 01 Sep. 2013. <<http://keypicking.com/viewtopic.php?t=7432>>.

Blaze, Matt. *Safecracking for the Computer Scientist*. N.p.: n.p., 2004. *Safecracking for the Computer Scientist*. Matt Blaze, 21 Dec. 2004. Web. 1 Sept. 2013.
<<http://www.crypto.com/papers/safelocks.pdf>>.

Sieveking, Robert Gene. *Guide to Manipulation*. Streamwood, IL (698 Bonded Pkwy., Streamwood 60107): National Locksmith, 1988. Print.

Number being tested: _____ Rotation: R L

High test:

Wheel tested

Test combinations

1	_____		
2		_____	
3			_____

Wheel 1- LCP: RCP: Contact area:

Wheel 2- LCP: RCP: Contact area:

Wheel 3- LCP: RCP: Contact area:

Low test:

Wheel tested

Test combinations

1	_____		
2		_____	
3			_____

Wheel 1- LCP: RCP: Contact area:

Wheel 2- LCP: RCP: Contact area:

Wheel 3- LCP: RCP: Contact area:

Combination so far: _____ - _____ - _____

