USBSID-Configtool manual

Author: LouD - generated on 2026-11-08

Table of Contents

Disclaimer . . . 2
About . . . 2
Drivers . . . 2
- Linux Udev rules . . . 2
- Windows driver . . . 2

Screens . . . 3
- Welcome screen . . . 3
- v1.5 Sockets confirmation message . . . 4
- Sockets screen . . . 5
- Clock screen . . . 6
- LEDS screen . . . 7
- Features screen . . . 7
- SID tests screen . . . 9
- Debug screen . . . 9

Development . . . 10
License . . . 10
- Software License ~ GNUv2 . . . 10
- Configtool Software License ~ EPLv2 . . . 10
- USBSID-Pico v1.5 PCB Hardware License ~ CC BY-NC-ND 4.0 . . . 11
- USBSID-Pico v1.3 PCB Hardware License ~ CC BY-SA 4.0 . . . 11
- USBSID-Pico v1.0 PCB Hardware License ~ CC BY-SA 4.0 . . . 11
- USBSID-Volume-daughterboard v1.0 PCB Hardware License ~ CC BY-SA 4.0 . . . 11

Disclaimer

I do this stuff in my free time for my enjoyment. Since I like to share my joy in creating this with everyone I try my best to provide a working PCB and Firmware. I am in no way an electronics engineer and can give ***no guarantees*** that this stuff does not break or damage your hardware, computer, phone, or whatever you try to hook it up to. Be sure to take great care when inserting any real MOS SID chips into the board. While everything has been tested with real chips, this is in no way a guarantee that nothing could go wrong. Use of this board and firmware at your own risk! I am in no way responsible for your damaged hardware. That being said, have fun!

About

What is there to say, you can configure your board with this tool and it is self explanatory.
Prefer the command line? A CLI config tool (`cfg_usbsid`) is also available ~ see the `USBSID-Pico-firmware-manual` file for its usage.

Drivers


Linux Udev rules


In the examples/udev directory you can find the udev rules that are used on Linux.
This purely an example file that you can use and change to your own needs. Steps required for this to work

```
# Check if you are in the plugdev group with the groups command
groups
# If not, add yourself to the plugdev group, then log out and in
sudo usermod -aG plugdev $USER
# Copy the udev ules file to the correct directory
sudo cp 69-usbsid-permissions.rules /etc/udev/rules.d
# Now reload the udev rules
udevadm control --reload-rules && udevadm trigger
# Not working? Try reloading the service
sudo systemctl restart udev
```

Windows driver


Use Zadig to install the correct driver. Replace the driver for `USBSID-Pico Data` with WinUSB.






Screens

Welcome screen







v1.5 Sockets confirmation message



Sockets screen





Clock screen



LEDS screen



Features screen





USB RX ringbuffer: buffers up to 8 incoming USB packets and prevents cracks on write-heavy tunes. Default on. Listed under ADVANCED next to Preset auto detect, written with the other settings (SET_CONFIG item 17) and stored in the ini file as `rx_ring` in the `[Features]` section. The setting applies after saving the configuration and rebooting the board. Available on firmware

newer than v0.8.1.

SID tests screen



Debug screen



Development

More information about USBSID-Configtool is available on the github repo

License

Software License ~ GNUv2


All code written by me in this repository is licensed under the terms of the GNU General Public License as published by the Free Software Foundation, version 2. Any code in this repository that is not written by me automatically falls under the licensing conditions by the authors of said code as mentioned in the source code header. For for more information about this license please read the LICENSE document in the root of the USBSID-Pico repository.

Configtool Software License ~ EPLv2

This program and the accompanying materials are made available under the terms of the Eclipse Public License 2.0 which is available at eclipse.org.
SPDX-License-Identifier: EPL-2.0

USBSID-Pico v1.5 PCB Hardware License ~ CC BY-NC-ND 4.0

USBSID-Pico v1.5 PCB © 2026 by LouD is licensed under
Creative Commons Attribution-NonCommercial-NoDerivatives 4.0 International



USBSID-Pico v1.3 PCB Hardware License ~ CC BY-SA 4.0

USBSID-Pico v1.3 PCB © 2025-2026 by LouD is licensed under
Creative Commons Attribution-ShareAlike 4.0 International



USBSID-Pico v1.0 PCB Hardware License ~ CC BY-SA 4.0

USBSID-Pico v1.0 PCB © 2024-2026 by LouD is licensed under
Creative Commons Attribution-ShareAlike 4.0 International



USBSID-Volume-daughterboard v1.0 PCB Hardware License ~ CC BY-SA 4.0

Volume-daughterboard v1.0 PCB © 2026 by LouD is licensed under
Creative Commons Attribution-ShareAlike 4.0 International



Author: LouD - generated on 2026-11-08