

# USBSID-Pico PCB firmware manual

Author: LouD - generated on 2026-09-03

## Table of Contents

|                                                                           |    |
|---------------------------------------------------------------------------|----|
| Disclaimer.....                                                           | 3  |
| Firmware types.....                                                       | 3  |
| Firmware naming.....                                                      | 3  |
| Board revision.....                                                       | 3  |
| Firmware naming.....                                                      | 3  |
| Firmware naming per Pico type.....                                        | 4  |
| Naming examples for the rp2040 Pico1.....                                 | 4  |
| Naming examples for the rp2350 Pico2.....                                 | 4  |
| Firmwares with embedded USBSID-Player.....                                | 4  |
| Firmwares with Cynthcart embedded.....                                    | 4  |
| How to flash your Pico.....                                               | 5  |
| Firmware configuration.....                                               | 6  |
| USBSID-Configtool.....                                                    | 6  |
| Commandline configuration tool.....                                       | 6  |
| Python Configuration GUI downloads.....                                   | 6  |
| Linux / Windows downloads.....                                            | 7  |
| Windows downloads.....                                                    | 7  |
| Configuration web page (for Chrome/Edge based browsers using webusb)..... | 7  |
| Default configuration (depends on the board version).....                 | 8  |
| Board clock rate.....                                                     | 8  |
| Clock rate locked.....                                                    | 8  |
| Audio mode.....                                                           | 9  |
| Lock audio switch.....                                                    | 9  |
| SID Voltage & Configuration confirmation.....                             | 9  |
| Disable socket change detection.....                                      | 10 |
| Socket settings.....                                                      | 10 |
| Socket One/Two Enabled.....                                               | 10 |
| Socket One/Two Dualsid enabled.....                                       | 10 |
| Socket One/Two Chiptype.....                                              | 11 |
| Socket One/Two SID 1 type.....                                            | 11 |
| Socket One/Two SID 2 type.....                                            | 11 |
| Socket Two Act as One.....                                                | 11 |
| Flip Socket One and Socket Two.....                                       | 11 |
| Mix socket addresses (Quad SID only).....                                 | 11 |

|                                                                            |    |
|----------------------------------------------------------------------------|----|
| Preset silent auto detection .....                                         | 11 |
| LED Enabled .....                                                          | 12 |
| LED Idle breathe enabled .....                                             | 12 |
| RGBLED Enabled .....                                                       | 12 |
| RGBLED Idle breathe enabled .....                                          | 12 |
| RGBLED Brightness .....                                                    | 12 |
| RGBLED SID to use .....                                                    | 12 |
| FMOpl Enabled .....                                                        | 12 |
| FMOpl SID number .....                                                     | 13 |
| CDC Enabled .....                                                          | 13 |
| WebUSB Enabled .....                                                       | 13 |
| Asid Enabled .....                                                         | 13 |
| Midi Enabled .....                                                         | 13 |
| License .....                                                              | 13 |
| Software License ~ GNUv2 .....                                             | 13 |
| Configtool Software License ~ EPLv2 .....                                  | 13 |
| USBSID-Pico v1.5 PCB Hardware License ~ CC BY-NC-ND 4.0 .....              | 14 |
| USBSID-Pico v1.3 PCB Hardware License ~ CC BY-SA 4.0 .....                 | 14 |
| USBSID-Pico v1.0 PCB Hardware License ~ CC BY-SA 4.0 .....                 | 14 |
| USBSID-Volume-daughterboard v1.0 PCB Hardware License ~ CC BY-SA 4.0 ..... | 14 |

# Disclaimer

I do this stuff in my free time for my enjoyment. Since I like to share my joy in creating this with everyone I try my best to provide a working PCB and Firmware. I am in no way an electronics engineer and can give **no guarantees** that this stuff does not break or damage your hardware, computer, phone, or whatever you try to hook it up to. Be sure to take great care when inserting any real MOS SID chips into the board. While everything has been tested with real chips, this is in no way a guarantee that nothing could go wrong. Use of this board and firmware at your own risk! I am in no way responsible for your damaged hardware. That being said, have fun!

## Firmware types



Each PCB revision is the firmware designator, please check your PCB revision, this is under the MOS logo and next to **USBSID-Pico** on your PCB.

Firmware filenames contain the PCB revision number e.g. **usbsidpico-rgb-v1.X.uf2** is for PCB revision **v1.0** and for use with a black clone Pico containing an RGB LED.

## Firmware naming

Below are the filenames used for each Pico and board type, take great care in selecting the correct file for you Pico!

**WARNING!** Do **NOT** use the **RGB** firmware for any of the (non black) rp2040 or (non black) rp2350 Pico boards that do not contain an RGB LED, this can break your Pico!

## Board revision

The 1.X in each filename equals for the PCB revision as mentioned under firmware types. Don't worry if you flash a firmware for the incorrect PCB revision, this causes no harm.

## Firmware naming

**usbsidA-BC.uf2** examples: **usbsidpico-v1.0-rgb.uf2**, **usbsidpico2\_w-v1.3.uf2** or **usbsidpico2-v1.5-rgb\_sp**.

A: The pico board type e.g. **pico**, **pico2**, **pico\_2** or **pico2\_w**

B: The PCB version e.g. `v1.0`, `v1.3` or `v1.5`

C: A combination of optional features e.g. `-rgb`, `_sp` or `_sp_cc`

## Firmware naming per Pico type

Firmwares suitable for rp2040 Pico1 boards start with `usbsidpico-` Firmwares suitable for rp2040 Pico1\_w boards start with `usbsidpico_w-`

Firmwares suitable for rp2350 Pico2 boards start with `usbsidpico2-`

Firmwares suitable for rp2350 Pico2\_w boards start with `usbsidpico2_w-`

## Naming examples for the rp2040 Pico1

Firmware naming suited for the pico 1 always start with `usbsidpico-`

`usbsidpico-v1.X.uf2` for regular green rp2040 Pico boards.

`usbsidpico-rgb-v1.X.uf2` for black clone rp2040 Pico boards with RGB LED onboard.

`usbsidpico_w-v1.X.uf2` for regular green rp2040 PicoW boards.

**NOTE!** Due to the hardware limitations of the RP2040, highly demanding, cycle-exact SID tunes (dense per-cycle register writes, e.g. some digi/sample tunes) may not play at full speed on Pico1 or Pico1\_w boards. Use a Pico2 or Pico2\_w (rp2350) board for these tunes.

## Naming examples for the rp2350 Pico2

Firmware naming suited for the pico 2 always start with `usbsidpico2-`

`usbsidpico2-v1.X.uf2` for regular green rp2350 Pico2 boards.

`usbsidpico2-rgb-v1.X.uf2` for black clone rp2350 Pico2 boards with RGB LED onboard.

`usbsidpico2_w-v1.X.uf2` for regular green rp2350 Pico2W boards.

## Firmwares with embedded USBID-Player

Starting with firmware version v0.6.0-BETA firmwares ending with `sp` have an embedded emulator that can play PSID and RSID tunes and PSID64 PRG/P00 files.

For example `usbsidpico2-v1.0_sp.uf2`, `usbsidpico2-v1.3-rgb_sp.uf2` or `usbsidpico2-v1.5_sp.uf2`

This USBID-Player is still in active development and some tunes might not work or play at all. The embedded USBID-Player requires more than 256KB RAM and an overclocked CPU which makes this firmware only available for rp2350 Pico2 boards.

**WARNING!** Whenever the USBID-Player is used the Pico MCU is overclocked to 250MHz, regardless of Pico type. Passive cooling `_might/could` be needed.

See the `USBID-Player-manual` file for more information.

## Firmwares with Cynthcart embedded

Starting with firmware version v0.8.0 firmwares ending with `_cc` can start Cynthcart with CC commands.

For example `usbsidpico-v1.0_sp_cc.uf2`, `usbsidpico2-rgb-v1.3_sp_cc.uf2` or `usbsidpico2-v1.5_sp_cc.uf2`

**WARNING!** Cynthcart runs through the embedded USBID-Player, so the same 250MHz overclock

(regardless of Pico type) and possible need for passive cooling applies here too.

See the [USBSID-Pico-Cynthcart-manual](#) file for more information.

# How to flash your Pico

## NOTE:

When flashing a new firmware version, all previously configured settings will be reset to default. Use the commandline configtool to save your current settings to a [ini](#) file if you want to save them!

A Raspberry Pi Pico board is incredibly easy to flash, as it comes with a built in bootloader for flashing new firmwares in the [uf2](#) format.

In order to flash a new firmware to your USBSID-Pico you will need to put the Pico into bootloader mode.

This can be done in multiple ways:

With the cable already plugged into your computer and Pico and seated on the board (using buttons):

- Press and hold the [BOOTSEL](#) button on the Pico.
- Press and release the [RST](#) button on the USBSID-Pico board.
- Now release the [BOOTSEL](#) button.
- A new drive should appear on your computer called [RPI-RP2](#) or [RP2350](#) depending on your Pico type.
- Copy the correct [uf2](#) firmware file to this directory.
- After copying the Pico will reboot and your Pico is flashed.

With the cable not plugged in to your computer and Pico and also not seated on the board (using buttons):

- Plug in the USB cable to your Pico and not into your computer.
- While holding the [BOOTSEL](#) button on the Pico plugin the other end of the USB cable into your computer.
- Now release the [BOOTSEL](#) button.
- A new drive should appear on your computer called [RPI-RP2](#) or [RP2350](#) depending on your Pico type.
- Copy the correct [uf2](#) firmware file to this directory.
- After copying the Pico will reboot and your Pico is flashed.

With the cable already plugged into your computer and Pico and seated on the board (using software):

- With the GUI config tool
- Go to the [DEBUG](#) tab and click on [BOOTLOADER](#)
- A new drive should appear on your computer called [RPI-RP2](#) or [RP2350](#) depending on your Pico type.

- Copy the correct **uf2** firmware file to this directory.
- After copying the Pico will reboot and your Pico is flashed.

or

- Go to the config webpage ([usbsid.loudai.nl/index.html?player=webusb&debug=usbsidpico](https://usbsid.loudai.nl/index.html?player=webusb&debug=usbsidpico)):
- Connect to the board using **WebUSB (Hermit)** as emulator
- Click on **CONFIG** to open the configuration tab
- Scroll to the bottom of the page and click on **BOOTLOADER** in the box named **DEBUG**
- A new drive should appear on your computer called **RPI-RP2** or **RP2350** depending on your Pico type.
- Copy the correct **uf2** firmware file to this directory.
- After copying the Pico will reboot and your Pico is flashed.

or

- With the CLI config tool command in your **PATH** variable
- Type **cfg\_usbsid -boot** to send the reboot to bootloader command
- A new drive should appear on your computer called **RPI-RP2** or **RP2350** depending on your Pico type.
- Copy the correct **uf2** firmware file to this directory.
- After copying the Pico will reboot and your Pico is flashed.

## Firmware configuration

USBSID-Pico has an extensive set of configuration options that expands with each firmware release.

### USBSID-Configtool

You can configure your board by using the official USBSID-Configtool

The tool is available here [USBSID-Configtool](#) in the releases section

### Commandline configuration tool

You can configure your board with: - the commandline config-tool - the commandline config-tool with the Python Configuration GUI by ISL/Samar if you prefer a GUI.

### Python Configuration GUI downloads

[Download script](#)

Python3 → [Download](#)

TkInter → [Installation guide](#)

And either one of the Linux or Windows CLI downloads below

## Linux / Windows downloads

The latest version of the CLI config tool is available in a zip file called **tools.zip** from release v0.6.0-BETA and up

## Windows downloads

If the DLL's are missing from the zip file you can always download them from here:


[Download DLL 1](#)

[Download DLL 2](#)

## Configuration web page (for Chrome/Edge based browsers using webusb)

[USBSID web configuration tool](#) (requires a Chrome based browser).

If needed you can change your USBSID configuration after selecting WebUSB and clicking on **Open config**.



*The player is set up with borrowed code from Deepsid using Hermit's JsSID implementation.*

# Default configuration (depends on the board version)

The default configuration differs slightly between Pico1 (rp2040) and Pico2 (rp2350) boards.

An explanation for these settings can be found further on in this document.

Board clock rate: **1000000Hz (DEFAULT)** for rp2040, **985248Hz (PAL)** for rp2350

Clock rate locked: **False**

Audio mode: **Mono**

Preset silent auto detection: **False** (**True** for PCB revision v1.5+)

Socket One Enabled: **True**

Socket One Dualsid enabled: **False**

Socket One Chiptype: **Unknown**

Socket One SID 1 type: **Unknown**

Socket One SID 2 type: **N/A**

Socket Two Enabled: **True**

Socket Two Dualsid enabled: **False**

Socket Two Chiptype: **Unknown**

Socket Two SID 1 type: **Unknown**

Socket Two SID 2 type: **N/A**

Socket Two Act as One: **False**

Flip Socket One and Socket Two: **False**

Mix socket addresses (Quad SID): **False**

LED Enabled: **True**

LED Idle breathe enabled: **True**

RGBLED Enabled: **False** (**True** for RGB Pico's)

RGBLED Idle breathe enabled: **False** (**True** for RGB Pico's)

RGBLED Brightness: **0** (**127** for RGB Pico's)

RGBLED SID to use: **-1** (**1** for RGB Pico's)

CDC Enabled: **True**

WebUSB Enabled: **True**

Asid Enabled: **True**

Midi Enabled: **True**

FMOpl Enabled: **False**

FMOpl SID no: **0**

## Board clock rate

The Commodore64 has different clockrates depending on where you live, USBSID-Pico supports these different clock rates as configuration setting.

Supported SID players will automatically send a new clock rate request to the board to switch to.

Available options are:

**DEFAULT 1000000Hz, PAL 985248Hz, NTSC 1022727, DREAN 1023440, NTSC2 1022730**

## Clock rate locked

Some players start sending data directly after the clockrate is changed. While in most cases this is no issue, some SID clones need some time to start up. This causes issues when the clock rate is changed on the fly.



Also changing the clock rate multiple times after another can cause data corruption to the SID which causes garbled sound.

To overcome this it is possible to lock the clockrate to the current setting it is set to. This blocks the ability for on the fly change requests.

Available options are:

False, True

## Audio mode

*PCB revision v1.3 only*

Sets the audio mode for the headphone jack and audio out pins.

When set to **Mono** the audio of both SID sockets will be combined to mono.

When set to **Stereo** the audio of both SID sockets will be separated into left for **SID1** and right for **SID2**

Available options are:

Mono, Stereo

## Lock audio switch

*PCB revision v1.3 only*

Locks the audio switch into its current state (**Mono** or **Stereo**) and prevents it from being changed.

Available options are:

False, True

## SID Voltage & Configuration confirmation

*PCB revision v1.5 only*

The board boots with 5v and 9v enabled to automatically detect any changes in the socket / chip configuration, it does this by running a chip and SID detection.

When a change is detected the boards turns off the 9v and 5v and the onboard (RGB)LED starts flashing, making the board unusable until the configuration is validated and confirmed.

*Please verify the configuration with care before confirming, failure to do so might damage/kill your SID chips, and we don't want that!*

There are multiple ways to validate and confirm the configuration:


### GUI Configtool

On opening the configtool and connecting to the board there will be a text stating the configuration needs to be confirmed. Verify the config on the **SOCKETS** tab and when done click **CONFIRM**



### Web Configtool

On opening the config website and connecting to the board there will be a text stating the configuration needs to be confirmed. Verify the config on the **CONFIG** tab by clicking **RETRIEVE CONFIG** first and when done validating click **CONFIRM CONFIG**. Both buttons will glow when a click is needed



### CLI Configtool

First read the configuration with `cfg_usbsid -r`, the printed configuration will have a line that states the config needs confirmation. You can do this with `cfg_usbsid -ack`.

## Disable socket change detection


*PCB revision v1.5 only*

When you have a fixed socket setup, e.g. you do not plan on changing the chips anytime soon, it is possible to disable the change detection on boot. This will make the board start up with 5v and 9v and then - if 12v is required - switch to the required voltage setting during the boot process by switching the voltage back off, setting the correct hv voltage and then switching it back on.


When the socket detection is on, the board will *always* try to detect any changes in the configuration *before* the required voltage is applied.

By setting the `Disable socket detection on boot` option you can control the above behaviour:

### GUI Configtool



### Web Configtool



### CLI Configtool

Change the behaviour with `cfg_usbsid -sad N` where N can be 0 (disabled) or 1 (enabled)

## Socket settings

Each socket comes with its own set of configurable options.

### Socket One/Two Enabled

Enable or disable the use of this socket.

Available options are:

`False`, `True`

### Socket One/Two Dualsid enabled

Enable or disable dualsid for this socket.

This requires the `Chiptype` for this socket to be set to any clone chip (not `MOS`) and ofcourse a dual

SID supporting SID clone with support of connecting the A5 address line.

Available options are:

False, True

## Socket One/Two Chiptype

Set the type of SID chip for this socket.

Available options are:

MOS (real SID), Unknown, SKPico, ARMSID, ARM2SID, FPGASID, RedipSID, PDSID, BackSID, SIDEmu

## Socket One/Two SID 1 type

Available options are:

Unknown, N/A, 8580, 6581, FM0p1

## Socket One/Two SID 2 type

Available options are:

Unknown, N/A, 8580, 6581, FM0p1

## Socket Two Act as One

When enabled, this will disable other Socket Two settings and this socket will receive all writes from Socket One as it were mirrored.

Available options are:

False, True

## Flip Socket One and Socket Two

When enabled, Socket One and Socket Two are swapped so Socket One's physical position responds as Socket Two and vice versa.

Available options are:

False, True

## Mix socket addresses (Quad SID only)

When enabled, addresses for a 4-SID setup are mixed between sockets instead of being assigned sequentially per socket. Combine with **Flip** for the remaining address orderings.

Available options are:

False, True

## Preset silent auto detection

When enabled, the board silently re-runs chip/SID auto detection before applying a preset.

Default is **False** on PCB revision v1.0~v1.3 and **True** on PCB revision v1.5+.

Available options are:

False, True

## LED Enabled

Disable or enable the use of the onboard LED.

When enabled this automatically enables the LED as Vu meter for the voices of **SID1**.

Available options are:

**False**, **True**

## LED Idle breathe enabled

Disable or enable the idle breathing effect for the onboard LED.

Available options are:

**False**, **True**

## RGBLED Enabled

*Only for black Pico clones with onboard RGB LED*

Disable or enable the use of the onboard RGBLED.

When enabled this automatically enables the RGBLED as Vu meter.

Available options are:

**False**, **True**

## RGBLED Idle breathe enabled

*Only for black Pico clones with onboard RGB LED*

Disable or enable the idle breathing effect for the onboard RGBLED.

Available options are:

**False**, **True**

## RGBLED Brightness

*Only for black Pico clones with onboard RGB LED*

Set the maximum brightness of the onboard RGBLED.

Available range is:

**0** to **255**

## RGBLED SID to use

*Only for black Pico clones with onboard RGB LED*

Set the SID of which to use the voices for the Vu meter.

Available options are (depending on your SID configuration):

**-1** off, **0** off, **1** SID1, **2** SID2, **3** SID3, **4** SID4

## FMOp1 Enabled

Requires a SID clone with FMOp1 capabilities, the socket **Chip type** set to **Clone** and **SID type** set to **FMOp1** before activation!

Available options are:

False, True

## FMOp1 SID number

*This setting cannot be changed manually* This setting will automatically be set to the correct SID number when all requirements are met as described under **FMOp1 Enabled**

## CDC Enabled

*This config setting is intended for future use* Available options are:

False, True

## WebUSB Enabled

*This config setting is intended for future use* Available options are:

False, True

## Asid Enabled

Disable or enable ASID protocol handling (SysEx-based SID playback over MIDI).

Available options are:

False, True

## Midi Enabled

Disable or enable MIDI input handling (note/CC/voice control of the SID(s)).

Available options are:

False, True

# License

## Software License ~ GNUv2

All code written by me in this repository is licensed under the terms of the GNU General Public License as published by the Free Software Foundation, version 2. Any code in this repository that is not written by me automatically falls under the licensing conditions by the authors of said code as mentioned in the source code header. For more information about this license please read the LICENSE document in the root of the USBSID-Pico repository.

## Configtool Software License ~ EPLv2

This program and the accompanying materials are made available under the terms of the Eclipse Public License 2.0 which is available at [eclipse.org](https://www.eclipse.org/eclipse-legal/epl-2.0/).

SPDX-License-Identifier: EPL-2.0

## USBSID-Pico v1.5 PCB Hardware License ~ CC BY-NC-ND 4.0

USBSID-Pico v1.5 PCB © 2026 by [LouD](#) is licensed under  
[Creative Commons Attribution-NonCommercial-NoDerivatives 4.0 International](#)



## USBSID-Pico v1.3 PCB Hardware License ~ CC BY-SA 4.0

USBSID-Pico v1.3 PCB © 2025-2026 by [LouD](#) is licensed under  
[Creative Commons Attribution-ShareAlike 4.0 International](#)



## USBSID-Pico v1.0 PCB Hardware License ~ CC BY-SA 4.0

USBSID-Pico v1.0 PCB © 2024-2026 by [LouD](#) is licensed under  
[Creative Commons Attribution-ShareAlike 4.0 International](#)



## USBSID-Volume-daughterboard v1.0 PCB Hardware License ~ CC BY-SA 4.0

Volume-daughterboard v1.0 PCB © 2026 by [LouD](#) is licensed under  
[Creative Commons Attribution-ShareAlike 4.0 International](#)



Author: LouD - generated on 2026-09-03