

USBSID-Pico Cynthcart manual

Author: LouD - generated on 2026-09-11

Table of Contents

Disclaimer.....	2
Thank you.....	2
Firmwares with Cynthcart embedded.....	2
Usage.....	2
CC messages.....	2
Cynthcart control.....	2
License.....	3
Software License ~ GNUv2.....	3
Configtool Software License ~ EPLv2.....	3
USBSID-Pico v1.5 PCB Hardware License ~ CC BY-NC-ND 4.0.....	3
USBSID-Pico v1.3 PCB Hardware License ~ CC BY-SA 4.0.....	3
USBSID-Pico v1.0 PCB Hardware License ~ CC BY-SA 4.0.....	3
USBSID-Volume-daughterboard v1.0 PCB Hardware License ~ CC BY-SA 4.0.....	4

Disclaimer

I do this stuff in my free time for my enjoyment. Since I like to share my joy in creating this with everyone I try my best to provide a working PCB and Firmware. I am in no way an electronics engineer and can give **no guarantees** that this stuff does not break or damage your hardware, computer, phone, or whatever you try to hook it up to. Be sure to take great care when inserting any real MOS SID chips into the board. While everything has been tested with real chips, this is in no way a guarantee that nothing could go wrong. Use of this board and firmware at your own risk! I am in no way responsible for your damaged hardware. That being said, have fun!

Thank you

First off thanks go out to Paul Slocum for creating Cynthcart and Mario Ballano for creating emudore.

Firmwares with Cynthcart embedded

Starting with firmware version v0.8.0 firmwares ending with **em can run Cynthcart**.

For example **usbsidpico-v1.0_em.uf2** or **usbsidpico2-rgb-v1.3_em.uf2**

Cynthcart runs through the embedded USBID-Player, so all Cynthcart firmwares **_also** come with the onboard USBID-Player included. See the **USBID-Player-manual** file for more information.

WARNING! Because Cynthcart runs through the embedded USBID-Player, the Pico MCU is overclocked to 250MHz, regardless of Pico type (rp2040 or rp2350). Passive cooling *might/could* be needed.

Usage

To start the emulator and Cynthcart you will need an USB-midi connection to USBID=Pico.

CC messages

85 (0x55) ~ Enable Cynthcart

86 (0x56) ~ Disable Cynthcart

87 (0x57) ~ Reset Cynthcart (**not implemented yet**, currently a no-op)

Cynthcart control

For all other midi CC messages to control Cynthcart please refer to the Cynthcart manual.

Page two in github.com/PaulSlocum/cynthcart/blob/master/manual/cynthcart2.0.1.pdf [cynthcart2.0.1.pdf] or [cynthcart2.0.1_5x7.pdf](#)

On the right side of [cynthcartCommandChart1.pdf](#)

Or on the bottom of [cynthcartCommandChart2.pdf](#)

License

Software License ~ GNUv2

All code written by me in this repository is licensed under the terms of the GNU General Public License as published by the Free Software Foundation, version 2. Any code in this repository that is not written by me automatically falls under the licensing conditions by the authors of said code as mentioned in the source code header. For more information about this license please read the LICENSE document in the root of the USBSID-Pico repository.

Configtool Software License ~ EPLv2

This program and the accompanying materials are made available under the terms of the Eclipse Public License 2.0 which is available at eclipse.org.

SPDX-License-Identifier: EPL-2.0

USBSID-Pico v1.5 PCB Hardware License ~ CC BY-NC-ND 4.0

USBSID-Pico v1.5 PCB © 2026 by [LouD](#) is licensed under
[Creative Commons Attribution-NonCommercial-NoDerivatives 4.0 International](#)



USBSID-Pico v1.3 PCB Hardware License ~ CC BY-SA 4.0

USBSID-Pico v1.3 PCB © 2025-2026 by [LouD](#) is licensed under
[Creative Commons Attribution-ShareAlike 4.0 International](#)



USBSID-Pico v1.0 PCB Hardware License ~ CC BY-SA 4.0

USBSID-Pico v1.0 PCB © 2024-2026 by [LouD](#) is licensed under
[Creative Commons Attribution-ShareAlike 4.0 International](#)



USBSID-Volume-daughterboard v1.0 PCB Hardware License ~ CC BY-SA 4.0

Volume-daughterboard v1.0 PCB © 2026 by [LouD](#) is licensed under [Creative Commons Attribution-ShareAlike 4.0 International](#)



Author: LouD - generated on 2026-09-11