

REPLACEMENT PARTS GUIDE

524K-II 4WD Loader (PIN: 1BZ524KA_ _D001001-004924)



Required Parts

524K-II 4WD Loader (PIN: 1BZ524KA_ _D001001-004924)

Sequence	Description	Image	PartNumber	Quantity	Interval Hrs	Remarks
1	Hydraulic Oil Filter		AM39653	1	500	Hydraulic Reservoir Breather
2	Inline Fuel Filter		AT489745	1	500	
3	Engine Oil Filter		RE504836	1	500	
4	Severe-Duty Fuel Filter		AT433554	1	500	Fuel Filter with Heater
5	Fuel Filter Element		AT365870	1	500	Fuel Filter without Heater
6	Primary Fuel Filter		AT526913	1	500	
7	Final Fuel Filter		AT526918	1	500	
8	Hydraulic Oil Filter		AT367635	2	1000	Axle Oil Filter, Also Replace Once at Initial 250 Hour ¹
9	Primary Air Filter Element		AT300487	1	1000	
10	Secondary Air Filter Element		AT314583	1	1000	



Required Parts

524K-II 4WD Loader (PIN: 1BZ524KA_ _D001001-004924)

Sequence	Description	Image	PartNumber	Quantity	Interval Hrs	Remarks
11	Air Filter Ejector Valve		M89679	1	1000	
12	V-Ring Face Oil Plastic Seal		T277593	4	2000	Steering Cylinder Joint Seals, If Nevergrease equipped
13	Transmission Oil Filter		AT468647	1	2000	
14	Rocker Arm Cover Gasket		R524469	1	2000	Engine 6068HDW74, Engine Rocker Arm Cover
15	Cylinder Head Gasket		R524497	1	2000	Engine 6068HBZ06, Engine Rocker Arm Cover
16	Hydraulic System Return Filter Element		AT545968	1	4000	
17	Pulley		RE505881	1	4000	Engine 6068HDW74, Crankshaft Damper
18	Pulley		RE508578	1	4000	Engine 6068HBZ06, Crankshaft Damper
19	Torsional Damper		AT308993	1	5000	Driveline Damper



Required Parts

524K-II 4WD Loader (PIN: 1BZ524KA_ _D001001-004924)

Sequence	Description	Image	PartNumber	Quantity	Interval Hrs	Remarks
20	Cab Air Filter		AT191102	1	AR	
21	Cab Recirculation Air Filter		AT307501	1	AR	
22	V-Belt, Effective Length 1955 mm (76.2 inch)		T426743	1	AR	S.N. (-002956) 80 and 100 amp alternator (with a/c)
23	V-Belt for Alternator, Effective Length 1940 mm (76.4 inch)		T452270	1	AR	S.N. (002957-) 80 and 100 amp alternator (with a/c)

¹Perform initial service once after the first 250 hours of operation.



Oil & Capacities

524K-II 4WD Loader (PIN: 1BZ524KA_ _D001001-004924)

Sequence	Description	Qty or Capacity	Interval Hrs	Remarks
1	John Deere Plus-50™ II Engine Oil ⁶	19.0 L (5.0 gal)	500	
2	John Deere Hy-Gard™ Park Brake Oil ⁶	0.3 L (10.1 oz)	1000	
3	John Deere Hy-Gard™ Transmission Oil ⁶	21.5 L (5.6 gal)	2000	
4	John Deere Hy-Gard™ Axle Oil (each) ⁶	17.0 L (4.5 gal)	2000	Also Replace Once at Initial 250 Hour ¹
5	John Deere Hydrau™ Hydraulic System Oil ⁶	92.0 L (24.3 gal)	4000	
6	John Deere COOL-GARD™II Pre-Mix	22.5 L (5.9 gal)	6000	

¹Perform initial service once after the first 250 hours of operation.

²Plus-50 is a trademark of Deere & Company

³Hy-Gard is a trademark of Deere & Company

⁴Hydrau is a trademark of Deere & Company

⁵Cool-Gard is a trademark of Deere & Company

⁶For recommended oil viscosities based on operating temperatures, see operator manual section Maintenance—Machine. (Section 3-1.)



Fluid Analysis Test Kits

524K-II 4WD Loader (PIN: 1BZ524KA_ _D001001-004924)

Sequence	Description	Part Number	Qty or Capacity	Interval Hrs	Remarks
1	Universal Fluid Analysis Kit	AT346594	1	250	Engine Oil
2	Universal Fluid Analysis Kit	AT346594	1	500	Transmission Oil
3	Universal Fluid Analysis Kit	AT346594	2	500	Axle Oil
4	Universal Fluid Analysis Kit	AT346594	1	500	Park Brake
5	Universal Fluid Analysis Kit	AT346594	1	500	Hydraulic Oil
6	Diesel Fuel Test Kit, 8 Ounce	AT180344	1	500	Diesel Fuel
7	Regular Engine Coolant Kit	TY27787	1	500	Engine Coolant

Based on fluid analysis results, intervals may need to be adjusted for operating conditions. See an authorized John Deere dealer.



Service Instructions

524K-II 4WD Loader (PIN: 1BZ524KA_ _D001001-004924)

Sequence	Service Hrs	Instructions
1	10	Clean/replace air cleaner dust unloader valve
2	10	Check coolant level in surge tank
3	10	Check engine oil level
4	10	Check hydraulic system oil level
5	10	Check transmission oil level
6	10	Inspect/replace outer pin seals, if equipped
7	100	Lubricate loader linkage and cylinder pivots
8	250	Drain and refill front and rear axle oil (Replace only at Initial 250 Hour) ¹
9	250	Replace axle oil filters—if equipped (Replace only at Initial 250 Hour) ¹
10	250	Take engine oil sample
11	500	Lubricate driveline upper and lower sliding joints and lower U-joints ²
12	500	Check front and rear axle oil level
13	500	Lubricate front and rear axle shaft seals ²
14	500	Check battery water level and tighten terminals
15	500	Check air intake hoses and charge air cooler tube couplings
16	500	Check axle oil sample
17	500	Check transmission oil sample
18	500	Check hydraulic oil sample
19	500	Check diesel fuel sample
20	500	Check engine coolant sample
21	500	Replace in-line fuel strainer



Service Instructions

524K-II 4WD Loader (PIN: 1BZ524KA_ _D001001-004924)

Sequence	Service Hrs	Instructions
22	500	Replace severe duty fuel filter—if equipped
23	500	Drain and refill engine oil and replace filter ³
24	500	Replace primary fuel filter
25	500	Replace final fuel filter
26	500	Replace hydraulic reservoir breather filter
27	500	Check park brake oil level
28	500	Lubricate front and rear shaft seals on park brake
29	500	Check ride control accumulator—if equipped
30	1000	Replace air cleaner dust unloader valve
31	1000	Replace engine air cleaner elements
32	1000	Replace axle oil filters
33	1000	Check coolant condition
34	1000	Clean engine crankcase vent tube
35	1000	Lubricate frame hinge pivots ²
36	1000	Drain and refill park brake oil ⁴
37	2000	Drain and refill transmission oil and replace filter ⁵
38	2000	Drain and refill front and rear axle oil
39	2000	Clean front and rear axle oil recirculation screens—if equipped
40	2000	Check and adjust engine valve lash (clearance)
41	2000	Rerun transmission clutch calibration
42	2000	Replace outer pin seals, if equipped
43	4000	Clean hydraulic pump case drain in-line screen
44	4000	Replace crankshaft damper every 4000 hour or 5 year whichever earlier



Service Instructions

524K-II 4WD Loader (PIN: 1BZ524KA_ _D001001-004924)

Sequence	Service Hrs	Instructions
45	4000	Replace hydraulic system return filter
46	4000	Drain, flush, and refill hydraulic system oil
47	4000	Clean hydraulic system fill strainer
48	5000	Check driveline damper for cracks
49	6000	Drain and refill engine coolant
50	AR	Inspect tires and check pressure
51	AR	Check wheel bolt torque
52	AR	Inspect engine air cleaner elements
53	AR	Inspect air conditioner compressor and alternator belt
54	AR	Clean cooler cores
55	AR	Check rear camera and radar object detection (ROD) system—if equipped
56	AR	Drain water from severe duty fuel filter and water separator—if equipped
57	AR	Check windshield washer fluid level
58	AR	Drain water from primary fuel filter with water separator
59	AR	Drain water from final fuel filter with water separator
60	AR	Check and clean or replace cab fresh air filter
61	AR	Check and clean or replace cab recirculating air filter

¹Perform initial service once after the first 250 hours of operation.

²Grease daily for deep mud, water or snow operation.

³Reduce drain interval when sulfur content in fuel exceeds 6.2%. see operator's manual for reduced drain interval.

⁴Reduce drain interval to 500 hours for deep mud, water, or snow operation.

⁵Reduce service intervals to 1500 hours in severe applications, which run the torque converter at high loads for more than approximately 25% of the time. (Examples include basement digging, land clearing, etc.)

