PlankFiducials

Author: Luciano Ristori **Date:** November 2026

Overview

Python tools to analyse OGP CMM (ZONE3) measurements of fiducials on silicon sensor modules mounted on a populated plank.

Each module is measured at 4 fiducials, one near each corner (LL, LR, UR, UL). The default fiducials are the outermost ones (LL01, LR01, UR01, UL01), but any fiducial along the same row may be used instead when the default one is hidden, for example by encapsulant. The analysis recognises substitutes automatically.

The workflow has two steps:

1. `make_nominal_table.py` builds, once, the table of nominal positions of all fiducials and corner circles on a sensor, from a CMM measurement of one sensor.
2. `fiducial_fit.py` analyses each plank measurement using that table.

Requires Python 3 with numpy.

Installation

Clone the repository and link the two scripts into `~/bin` (which must be on the shell's search path), so they can be run from any directory:

```
git clone https://github.com/LucianoRistori/PlankFiducials.git ~/code/CMM/PlankFiducials
chmod +x ~/code/CMM/PlankFiducials/fiducial_fit.py ~/code/CMM/PlankFiducials/make_nominal_tabl
e.py
ln -s ~/code/CMM/PlankFiducials/fiducial_fit.py ~/bin/fiducial_fit
ln -s ~/code/CMM/PlankFiducials/make_nominal_table.py ~/bin/make_nominal_table
```

The links point to the files in the repository, so any change (or `git pull`) takes effect immediately; nothing needs to be reinstalled. Check with `which fiducial_fit`. If numpy is missing: `pip3 install numpy`.

Once installed, the commands below can be called without `python3` and without the `.py` extension, e.g. `fiducial_fit MEASUREMENT_FILE`.

make_nominal_table.py

```
python3 make_nominal_table.py RAW_SENSOR_FILE [OUTPUT_FILE] [--cut UM]
```

Input: a CMM measurement of all fiducials of one sensor (`Label, X, Y, Z` per line): the 4 corner circles (LLcircle, LRcircle, URcircle, ULcircle) and the fiducial rows LL01-LL16, LR01-LR18, UR01-UR18, UL01-UL16, in a sensor frame with LLcircle at the origin and LRcircle on the x axis.

What it does:

- Fits an exact 1.000 mm grid to the fiducials (the pattern is lithographic, so the grid is exact). Outliers (default cut 4 um) are fiducials of a slightly different shape; they are excluded from the fit.
- Idealises the circles to an exact rectangle (mean measured width and height).
- Centres the fiducial grid on the circle rectangle, with rows exactly parallel to x and y.
- Outliers keep their own measured offset from the grid, so the table describes what the CMM actually sees on them.
- Z = 0 for all points.

Output: `Label, X, Y, Z` per line (default name `PSFiducials_nominal.txt`).

---

fiducial_fit.py

```
fiducial_fit MEASUREMENT_FILE [--nominal FILE] [--maxrms UM]
```

Example, from any directory:

```
fiducial_fit Layer1TopFiducials_20261028163846.txt
```

Which nominal table is used

The nominal table is not given on the command line in normal use. The program looks for it in this order and uses the first one that applies:

1. `--nominal FILE` on the command line, if given (for an occasional different table).
2. The environment variable `PLANK_NOMINAL`, if it is set, e.g. in `~/.bash_profile`:

   ```
   export PLANK_NOMINAL=~/Dropbox/Documents/CMS/CMM_Work/Planks/PopulatedPlanks/PS_Fiducial
   s/PSFiducials_nominal.txt
   ```

3. The built-in default (constant `DEFAULT_NOMINAL` in `fiducial_fit.py`):
   `~/Dropbox/Documents/CMS/CMM_Work/Planks/PopulatedPlanks/PS_Fiducials/PSFiducials_nominal.txt`

The first line of every report states which table was used and where it came from (`--nominal`, `PLANK_NOMINAL` or `built-in default`). If the file does not exist, the program stops with an error saying which path it tried.

Input and options

The `.txt` extension of the measurement file may be omitted.

Input: a ZONE3 fiducial file with lines `Name,X,Y,Z`, names LL1, LR1, UR1, UL1, LL2, ... (corner + module number). Header text and non-fiducial lines (for example circles) are ignored. An optional point named `ORG` defines the origin of the global coordinate system.

What it does:

1. **Per module:** identifies which fiducial was actually measured in each corner (searching every position in the row), fits a 3D rigid transform from the nominal table to the 4 measured points, and computes the 3D positions of the 4 corner circles. A module is flagged when its XY fit RMS exceeds the cut (default 30 um); the z non-planarity of the 4 points is reported separately.
2. **Global "mean" system:** its axes are the mean orientation of the modules (X, Y, Z = average local x, y and normal of the modules, made exactly orthogonal); the origin is the `ORG` point if present, otherwise the centroid of all circles. All modules are used; flags are informational. See "The global reference system" below for the definition and the reasons.
3. **Results:** circle positions and module poses (centre, rotation about Z, tilts about X and Y) in the mean system.

Output: the report is printed and written to the current directory as `<measurement>_report.txt`. An existing report is never overwritten: a second analysis of the same file gives `<measurement>_report_2.txt`, then `_3`, and so on. The report header records the analysis date and time, the code version (git commit, with a warning if the code had uncommitted changes), the full paths of the nominal table, the measurement file and the report file itself, and the quality cut, so different reports of the same input can be compared.

`example_L1Bot.txt` is a sample 4-module measurement (bottom side) including template header lines.

The global reference system

What it is for

The results are meant to rank the mechanical quality of each plank. The idea is simple: on a perfectly built plank, measured without errors, the 4 corner circles of every module would form exactly the same rectangle, and the rectangles of different modules would differ only by a shift along X. Any deviation from that picture, after the X shifts, is a construction (or measurement) error, and figures of merit can be built from it.

For this to work, the global reference system must be chosen so that it does not absorb construction errors into its own definition.

Definition used

- **Orientation.** Each module has its own orientation, given by the 3D fit of its fiducials: its local x axis (along the fiducial rows), local y axis and normal. The global axes are the **mean orientation of the modules**: the rotation that is closest, in the least-squares sense, to all module rotations (the orthogonal part of their sum). In practice global X, Y and Z are the average local x, y and normal of the modules, made exactly perpendicular to each other.

- **Origin.** The `ORG` point if it is in the measurement file, otherwise the centroid of all circles of all modules. The origin only shifts all coordinates together and does not change any relative quantity.

The module centres play no part in defining the orientation.

Alternatives considered

1. **Axes from the module centres.** X along the best-fit line through the module centres, Z normal to the best-fit plane through all circles. (The first version of the program used the plane through all circles for Z.)
2. **Axes from external references on the plank,** for example the CMM alignment or dedicated reference points. This would require reference features that are not yet measured, and would mix the quality of the module placement with the quality of those references.

Why the module orientations

Consider a plank where every module is rotated by the same small angle about Z with respect to the line through the module centres: a "staircase".

- With the **module-based axes** (our choice), global X follows the modules. The modules come out unrotated, but their centres step in Y by about angle x pitch from one module to the next. After the X shifts the circle rectangles do **not** superimpose: the defect is visible.
- With **axes from the centres**, global X follows the line of centres. Every module comes out rotated by the same angle, and after the X shifts the rotated rectangles superimpose perfectly: the defect is **invisible**.

The same holds for a staircase in height (every module tilted by the same angle about Y, centres at the same height). This is why Z is also taken from the modules (their mean normal) and not from a plane fitted through all circles: such a plane follows the module centres and would hide the tilt.

In short, a reference system built from the module centres absorbs any error that is common to all modules; a system built from the mean module orientation turns it into residuals, which is what a figure of merit needs.

Things to keep in mind when reading the report

- The rotation and tilts of each module (rotZ, tiltX, tiltY) are measured with respect to the **average module**, so they average to about zero over the plank. A rotation or tilt common to all modules appears instead as a steady trend of the centre Y or Z with X.
- Module angles are measured over short distances (about 35 mm between the fiducials along x, about 98 mm along y). An angle error is multiplied by the distance from the centre of the plank, so measurement errors are amplified towards the ends of the plank, by a factor of order a few. Averaging over the modules reduces this.
- All modules, including flagged ones, enter the mean orientation. A badly measured module can therefore tilt the whole system; the report gives the RMS angle of the modules from the mean orientation as a check.
- Because each module gets its own X shift, errors in the spacing of the modules along the plank are not tested by this comparison. If the spacing matters, it needs a separate figure of merit (or fixed shifts equal to the design pitch).

Data locations

Nominal table, the raw sensor measurement it comes from, plank measurements and results are kept in Dropbox, not in this repository:

```
~/Dropbox/Documents/CMS/CMM_Work/Planks/PopulatedPlanks/
    PS_Fiducials/PSFiducials_20261102162326.txt   raw sensor measurement
    PS_Fiducials/PSFiducials_nominal.txt          nominal table
    results/                                      analysis results
```