Page 2

Expansion connectors, LCD interface, I2C IO-expansion, RS232 interface, uSD interface, Joystick and accelerometer.

Page 3

SPI-Ethernet interface and GPS interface

Default jumper settings are indicated in the schematic. However, always check jumper positions on actual boards since there is no guarantee that all jumpers are in default place.

UL = UnLoaded = normally not mounted component.

Rev 1.1

Switch ETH_CS and ETH_INT control for ENC28J60 (switched XP0.14 and XP0.15)

Rev 1.0

Original revision



(C) Embedded Artists AB

TITLE: Experiment Expansion Board v1.1

Document Number:

REV:

Date: 2009-04-22 22:52:43

Sheet: 1/3



