

Hydra32 (ESP32-Deauther) — Complete Hardware Guide

Firmware: Hydra32 / HydraESP (ESP32-Deauther) · **Upstream:** [SameerAISahab/ESP32-Deauther](#) (GPL-3.0) **Chip:** ESP32 (Xtensa LX6) on the **ESP32 DevKit V1** board · **Cyber Controller profile:** hydra32 (esptool backend, multi-file offsets, pinned + SHA-256-verified release) **This guide:** purchase → build → flash → integrate into Cyber Controller → use → troubleshoot.

1. Overview

Hydra32 (the project also calls itself **HydraESP**; the pinned release is tagged **Hydra32** and ships the app as `projecthydra-32.bin`) is a WiFi/Bluetooth security-research firmware for the classic dual-core **ESP32-WROOM-32**. It is an ESP32-Deauther variant that bundles WiFi reconnaissance and 802.11 deauthentication with a browser-based control panel served from on-device SPIFFS storage. Documented capabilities include **WiFi scanning**, **deauthentication** (up to 16 simultaneous targets), **WPA handshake capture** (`.pcap` / `.hccapx`), **PMKID capture**, **beacon spam**, **Ghost Mode** (probe-request SSID echo), **Evil Twin** (open clone + captive-portal password capture), **BLE spam** (Apple/Samsung/Google proximity advertisements), and a defensive **deauth detector**. An optional SSD1306 OLED shows live status. Cyber Controller's role is narrow and honest: it flashes the **pinned, SHA-256-verified** release images at the correct offsets and exposes the device on the **Devices** tab — it adds no attack capability of its own. (Feature names and version: §9.)

2. Legal & Safety

Authorized testing only. Deauthentication, beacon spam, Evil Twin, and BLE spam actively transmit on the 2.4 GHz band and are **illegal against networks, devices, or people you do not own or have explicit written permission to test** in most jurisdictions (US: CFAA + FCC rules against willful RF interference; the EU and many others have equivalent statutes). Deauthentication is jamming-by-protocol: it knocks real clients off real networks, so unauthorized use is not a grey area. Use Hydra32 **only** on your own lab gear or under a signed engagement scope. Even passive WiFi scanning/sniffing and the captive-portal credential capture in Evil Twin can be regulated where you live — check local law first. Cyber Controller surfaces the firmware's lawful-use notice and treats transmit features as dangerous; the tool does not remove your responsibility for what you transmit. Upstream states plainly: *"Use it only on networks and devices you own or have received explicit written authorisation to test."* (§9)

3. Hardware & Purchasing

Hydra32 targets **one board** in the Cyber Controller profile: the **ESP32 DevKit V1** (the DOIT/"NodeMCU-32" style 30-pin board built around the **ESP32-WROOM-32** module). Upstream notes other plain ESP32 modules (ESP32-WROOM-32, ESP32-WROVER) are *expected* to work, but **ESP32-S2 / S3 / C3 are not supported** — this is LX6-ESP32-only firmware. Buy the matching board:

Part	Why this one	Where to buy (search terms)
ESP32 DevKit V1 (ESP32-WROOM-32, 30-pin, 4 MB flash)	The profile's only board; cheap, serial-flash friendly, BOOT/EN buttons	AliExpress/Amazon: " ESP32 DevKit V1 " or " DOIT ESP32 DEVKIT V1 "; distributors: Mouser / DigiKey search "ESP32-DevKitC" / "ESP32-WROOM-32"
USB data cable (Micro-USB, <i>data</i> not charge-only)	DevKit V1 uses Micro-USB; charge-only cables show no COM port	Any electronics vendor: " micro USB data cable "
SSD1306 OLED 128×64 I²C (<i>optional</i>)	On-device live status/logs without the web UI	AliExpress/Amazon: " SSD1306 0.96 OLED I2C 128x64 "
Dupont jumper wires (<i>optional, for OLED</i>)	Wire the OLED to the I ² C pins	" dupont jumper wires female-female "

Board-buying notes - Verify 4 MB flash. The profile flashes a SPIFFS storage image at `0x190000` and assumes a 4 MB part (the upstream `partitions.csv` for the `devkit-v1` branch lays the storage partition there). A 2 MB clone will not fit the layout. If unsure, *verify*: check the WROOM-32 module marking or read flash size with `esptool flash_id`. - **USB-serial chip varies by clone.** Genuine/most DOIT DevKit V1 boards use the **Silicon Labs CP2102** (CP210x driver); cheaper clones use a **WCH CH340**. You need the matching driver (see §4). *Verify*: read the chip marking next to the USB port. - No invented part numbers or shop URLs here — search the terms above with your preferred vendor and confirm price/stock at purchase time (§9).

4. Building / Assembly

There is **nothing to solder** for the base setup — the DevKit V1 is a finished board; you only need a data cable. Assembly/setup work is drivers, the optional OLED, and (if you don't use the pinned release) building from source.

USB-serial driver (required to get a COM port) - CP2102 boards: install the **Silicon Labs CP210x VCP** driver. - **CH340 boards:** install the **WCH CH340** driver. - Without the right driver, no COM/tty port appears and flashing cannot start (§8).

Optional OLED wiring (SSD1306, I²C) - The DevKit V1's default hardware I²C pins are **GPIO21 = SDA** and **GPIO22 = SCL**, with **3V3** and **GND** for power. Wire OLED `VCC`→`3V3`, `GND`→`GND`, `SDA`→`GPIO21`, `SCL`→`GPIO22`. - *Verify*: confirm the exact SDA/SCL GPIOs (and the OLED I²C address, usually `0x3c`) against the Hydra32 source/README for your release before relying on them — upstream did not publish a fixed pinout table at the time of writing (§9).

Building from source (only if not using Cyber Controller's pinned release) - Hydra32 is an **ESP-IDF** project (CMake-based). Standard flow: install ESP-IDF, then `idf.py set-target esp32` → `idf.py build` → `idf.py -p <PORT> flash`. *Verify* the exact ESP-IDF version in the repo before building; IDF major versions are not always interchangeable (§9). - For normal use you do **not** build anything — Cyber Controller fetches the prebuilt, hash-pinned release.

5. Flashing & First Run (via Cyber Controller)

1. Connect the DevKit V1 by Micro-USB; open Cyber Controller → **Flash** tab.
2. **Port:** pick the board's COM/tty (click *Refresh* if missing → driver/cable issue, see §8).
3. **Firmware Profile:** Hydra32 (ESP32-Deauther) (profile id hydra32).
4. **Board: ESP32 DevKit V1** (esp32 chip; the profile's only board). Flash params are fixed by the profile: **4 MB**, flash mode **dio**, flash freq **80m**, default baud **921600**.
5. Click **Flash**. Cyber Controller resolves the pinned **Hydra32** release, **verifies each file's SHA-256**, and writes the multi-file image at the upstream offsets: - `bootloader.bin` → **0x1000** - `partition-table.bin` → **0x8000** - `projecthydra-32.bin` (app) → **0x10000** - `storage.bin` (SPIFFS web UI) → **0x190000** This is a **single-factory** layout — there is **no boot_app0** file (the profile sets `include_boot_app0`: false).
6. **First run:** after flashing, the ESP32 boots and starts its own management access point. From a phone or laptop, join the Hydra32 AP and browse to **http://192.168.4.1** to reach the web UI (tabs: **Scan, Attack, Detector, Settings, About**). The default AP credentials are reported as SSID **hydra** / password **notforfun** — *verify per release*, as defaults can change between versions (§9). With an OLED attached, status also appears on the screen.

Tip: if the board won't enter download mode automatically, hold **BOOT (IO0)** while the flash starts, or tap **EN** then start the flash. See §8.

6. Integrate into Cyber Controller

- **Profile:** hydra32 — backend **esptool**, chip **esp32**, board **ESP32 DevKit V1**. Image model is **multi-file-offsets** with a **pinned-release** resolver (release tag **Hydra32**). Every asset (`bootloader.bin`, `partition-table.bin`, `storage.bin`, and the `projecthydra-32.bin` app) is **SHA-256-pinned and verified at flash time, never vendored** — if a download's hash doesn't match, the flash aborts.
- **Control:** open the **Devices** tab → select the DevKit V1's port → set **Firmware = Hydra32 (ESP32-Deauther)** → **Connect**. The serial terminal is persistent and per-device colorized.
- **Primary UI is the web panel.** Unlike CLI-first firmwares, Hydra32 is driven through its browser UI at **192.168.4.1**; the Devices tab is for the serial console, boot/diagnostic output, and reconnects. Use whichever the firmware exposes for a given action.
- **Suicide / self-erase:** the profile sets `supports_suicide`: false — there is **no** firmware self-destruct for Hydra32. To wipe it, use **Erase Flash** in the Flash tab.
- **Backup first:** before overwriting an existing board, use **Backup** in the Flash tab to dump current flash.

7. Usage (end-to-end)

All steps below assume **authorized targets only** (§2). 1. **Power & connect:** plug the DevKit V1 into USB or a 5 V source; join its AP and open **http://192.168.4.1**. 2. **Scan:** **Scan** tab → list nearby APs (SSID, BSSID, signal). Pick your authorized target. 3. **Attack:** **Attack** tab → choose a mode: - **Deauth** — disconnect clients from the selected AP (up to 16 targets). - **Beacon spam** — flood fake beacons to test detection/visibility. - **Handshake / PMKID capture** — force re-auth and capture `.pcap` / `.hccapx`, or pull a PMKID without a connected client. - **Ghost Mode** — echo probe-request SSIDs. - **Evil Twin** — open clone of the AP with a captive portal that prompts for the password (captured credentials show in the UI/OLED). - **BLE spam** — broadcast Apple/Samsung/Google proximity ads. 4. **Timed operations:** set an attack duration so it auto-stops (Settings/Attack controls). 5. **Detector (defensive):** **Detector** tab → puts the radio in promiscuous monitor mode and alerts when **>10 deauth frames from one BSSID within 1 second** are seen; results show in a live log table. 6. **Settings/About:** channel and operational options live under

Settings; About shows version. 7. **Stop & disconnect**: stop the active attack in the web UI; in Cyber Controller, **Disconnect** to free the serial port.

8. Troubleshooting

- **No COM port**: install the correct USB-serial driver — **CP210x (Silicon Labs)** for CP2102 boards or **CH340 (WCH)** for clones; swap in a **data** USB cable (charge-only cables are the #1 cause); on Linux add your user to `dialout` and replug.
- **Flash fails / "Failed to connect"**: hold **BOOT (IO0)** while the flash starts (or tap **EN** then start); close any serial monitor holding the port; lower the flash baud in Settings (esptool can fall back to very slow rates to prove it isn't a baud problem).
- **SHA-256 / download mismatch**: the pinned release didn't verify — retry (transient download), confirm network access to GitHub releases, and don't substitute hand-downloaded bins; the profile intentionally refuses unverified files.
- **Web UI won't load at 192.168.4.1**: confirm you joined the Hydra32 AP (not your home WiFi); some phones auto-switch back to a known network with internet — disable "auto-switch"/"smart network switch." *Verify* the AP SSID/password for your release (§9).
- **Storage/UI assets missing or blank page**: `storage.bin` (SPIFFS) didn't write — re-flash; ensure the board is genuinely **4 MB** (a smaller flash can't hold the `0x190000` storage partition).
- **Boot-loops / brick: Erase Flash** then re-flash the pinned release; verify the WROOM-32 is real (`esptool flash_id` to confirm 4 MB).
- **OLED blank**: check `VCC/GND/SDA(GPIO21)/SCL(GPIO22)` wiring and the I²C address; *verify* the pins/address against your release's source (§9).
- **Wrong chip**: this firmware is **ESP32 (LX6) only** — an ESP32-S2/S3/C3 board will not run it.

9. Sources

- Upstream repo (README, features, releases): <https://github.com/SameerAISahab/ESP32-Deauther> (GPL-3.0).
- Releases / pinned Hydra32 tag, assets, and offsets: <https://github.com/SameerAISahab/ESP32-Deauther/releases> (`bootloader.bin@0x1000`, `partition-table.bin@0x8000`, `projecthydra-32.bin@0x10000`, `storage.bin@0x190000`; latest reported V1.1.3).
- Project site: <https://sameeralsahab.github.io/ESP32-Deauther/>.
- Cyber Controller profile: `src/config/profiles/hydra32.json` (board, chip, esptool offsets, SHA-256 pins, flash params, `supports_suicide: false`).
- Board specs (ESP32-WROOM-32, 4 MB, CP2102, Micro-USB, BOOT/EN): DOIT ESP32 DevKit V1 references (espboards.dev, Mischianti, Last Minute Engineers) and the Espressif ESP32-WROOM-32 datasheet.
- Drivers: Silicon Labs CP210x VCP; WCH CH340. Flashing/boot-mode troubleshooting: Espressif esptool docs; Random Nerd Tutorials ESP32 troubleshooting.
- **Verify at use time**: AP SSID/password defaults, OLED pinout/address, ESP-IDF build version, and current board prices/stock — these can change between firmware releases and vendors.