Quarterly Maintenance Manual

The coolant pump on unit B7 must be replaced every 4000 operating hours. Torque the housing bolts to 45 Nm in a star pattern.

Page two: emergency shutdown

Press the red mushroom switch, then isolate breaker CB-12 before opening the panel.