Assembly Instructions for Sensory Swing

Introduction

Thank you for choosing the Sensory Swing! This product is designed to provide a calming and enjoyable experience for both children and adults. Follow these assembly instructions carefully to ensure safe and correct setup.

Tools Needed

- Phillips screwdriver
- Adjustable wrench

Assembly Steps

Step 1: Unbox the Swing

- Carefully remove the swing and all components from the packaging.
- Ensure all parts are included by referencing the parts list below.

Parts List

- 1 x Sensory Swing
- 1 x Swing Suspension Strap
- 1 x Carabiner Clip
- 1 x Ceiling Hook
- 2 x Wall Anchors
- 2 x Screws
- 1 x Carry Bag
- Assembly Instructions (this document)

Step 2: Prepare the Installation Area

- Choose a suitable location for the swing. Ensure that there is enough clearance above and around the swing for safe swinging.
- Check that the ceiling is sturdy enough to support the swing.

Step 3: Install the Ceiling Hook

- Use the Phillips screwdriver to install the ceiling hook.
- If using wall anchors, drill holes in the ceiling and insert anchors as per the package instructions.
- Secure the ceiling hook into the anchor or directly into the ceiling.

Step 4: Attach the Suspension Strap

- Connect the suspension strap to the ceiling hook using the carabiner clip.
- Ensure that the carabiner is securely fastened.

Step 5: Hang the Sensory Swing

- Attach the sensory swing to the other end of the suspension strap.
- Adjust the height of the swing to your preference. Ensure it is securely fastened.

Step 6: Final Checks

- Double-check all connections and ensure the swing is stable and secure before use.
- Test the swing by gently applying weight to ensure it can support the intended user.

Safety Guidelines

- Always supervise children while they are using the swing.
- Ensure that the swing area is free from obstacles and hazards.
- Do not exceed the weight limit specified in the product guidelines.

Maintenance

- Regularly inspect the swing and suspension system for any wear and tear.

- Clean the swing fabric as needed according to the care instructions provided.

Customer Support

If you have any questions or need further assistance, please contact our customer support team at [insert contact information].