




Ender-3 3D Printer

Instructions for assembly

- This guide is for Ender-3 3D printer.
- Select the correct input voltage to match your local mains (230V or 115V).
- Because of software/hardware upgrades and model differences, new revisions may not be listed in this guide.
- Please plug the Power cord into a three-hole power jack.
- Detailed instructions for use are available on the TF card.
- This machine is equipped with a security protection mechanism. Do not manually move the nozzle and printing platform mechanism manually while booting up, otherwise the device will automatically power off for safety!



V.4.1

Model	Ender-3	Working Mode	Online or TF card offline
Molding Tech.	FDM	File Format	STL,OBJ,AMF
Printing Size	220*220*250mm	Slice Software	Cura, Repetier-Host, Simplify3D
Printing Speed	≤180mm/s, Normal 30–60mm/s	Power Supply	Input:AC115/230V 50/60HZ Output:DC 24V
Precision	±0.1mm	Total Power	270W
Slice Thickness	0.1mm–0.4mm	Filament	1.75mm PLA
Nozzle Diameter	Standard 0.4mm	Operating System	Windows XP/Vista/7/10 MAC, Linux
Nozzle Number	1	Language	English
Nozzle Temp.	≤250°C	Resume Print	YES
Bed Temp.	≤100°C	Filament Detector	NO



SHENZHEN CREALITY 3D TECHNOLOGY CO., LTD.

Add:18F,JinXiuHongDu Building, Meilong Blvd., Longhua Dist.,

Shenzhen, China 518131

Official Website: www.creality.com


Tel: +86 755-8523 4565

E-mail: info@creality.com


cs@creality.com





List 1





List 2





Step 1



Step 2



Step 3



Step 4

