PROCEDURA D'APPRENDIMENTO

HUMMER



Modalità **Stazionario**

1. Gonfiare tutti gli pneumatici alla pressione desiderata, attenendosi alla targhetta pressioni del costruttore del veicolo
2. Attivare tutti gli ID dei sensori presenti nell'automobile utilizzando lo strumento
3. Tirare il freno a mano
4. Portare lachiave di accensione in posizione ON/RUN (a motore spento)
5. Girare l'interruttore dei fari dalla posizione OFF a quella delle luci di stazionamento 4 volte in 4 secondi
6. Verranno prodotti 2 trilli dell'avvisatore acustico e l'indicatore di pressione bassa degli pneumatici inizierà a lampeggiare
7. Utilizzare lo strumento per attivare il sensore AS (Anteriore Sinistro)
8. Verrà emesso un suono dell'avvisatore acustico
9. Ripetere la procedura per gli pneumatici AD/PD/PS
10. Dopo che il sensore PS è stato acquisito, girare la chiave di accensione in posizione OFF
11. Rilasciare il freno a mano prima di mettersi in movimento

Nota: se non è possibile abilitare la modalità di apprendimento, vedere le informazioni di manuale di servizio

RELEARN PROCESS

HUMMER



Modality **Stationary**

1. Inflate all tires to desired pressure according to tire placard
2. Apply parking brake
3. Turn ignition to ON/RUN position (engine OFF)
4. Turn headlight switch from OFF to parking lamp 4 times within 4 seconds
5. A double horn chirp will sound and the low TIRE PRESSURE indicator will begin blinking
6. Use the tool to activate Left Front sensor
7. A single horn sounds
8. Repeat step for RF, RR and LR tires
9. After LR sensor has been learned, turn ignition to OFF
10. Release parking brake before driving

Note: if learn mode can't be enable, see the service manual information

Modality **Auto Relearn**

1. Inflate all tires to desired pressure according to tire placard

	2. Turn ignition ON 3. Press LOCK/UNLOCK on key fob until horn sounds 4. Use tool to activate Left Front sensor 5. A single horn sounds 6. Repeat step for Front Right, Rear Right, and Rear Left tires 7. Turn ignition OFF With DIC Button 1. Inflate all tires to desired pressure according to tire placard 2. Apply parking brake 3. Turn ignition ON (engine OFF) 4. Press MENU in the Driver Information Center (DIC) 5. Scroll to the tyre LEARN menu 6. Press \23 7. Horn sounds twice and tire LEARNING ACTIVE is displayed 8. Use the tool to activate Left Front sensor 9. A single horn sounds 10. Repeat step for Right Front, Right Rear, and Left Rear tires 11. Once the left rear sensor has been actiated, the horn will sound twice. 12. Turn the ignition OFF With Odometer Reset 1. Inflate all tires to desired pressure according to tire placard 2. Apply parking brake 3. Turn ignition ON (engine OFF) 4. Press the TRIP ODOMETER RESET STEM on instrument panel until press \23 TO RELEARN tire POSITIONS is displayed 5. Press \23 6. Horn sounds twice and tire LEARNING ACTIVE is displayed 7. Use the tool to activate Left Front sensor 8. Single horn sounds 9. Repeat step for Right Front, Right Rear, and Left Rear tires 10. Once the Left Rear sensor has been activated, the horn will sounds twice 11. Turn ignition to OFF