

**INDICACION Y MENSAJES
INDICATION AND MESSAGES**

INDICACION EN EL DISPLAY	INDICATION ON DISPLAY	DESCRIPCION	DESCRIPTION
ESPERAR	WAIT PLEASE	FASE DE ESPERA AL ENCENDER	WAITING PHASE WHEN SWITCH ON
RESET	RESET	MAQUINA ESPERA POR UN RESET	MACHINE IS WAITING FOR RESET
DATA OK ?	DATA OK ?	MAQ ESPERA CONFIRMACN DATO	MACHINE IS WAITING FOR DATA CONFIRM
MAQUINA OK	MACHINE OK	MAQUINA LISTA PARA EMPEZAR EL CICLO	MACHINE IS READY TO START CYCLE
VALOR ERRONEO L VALOR ERRONEO I VALOR ERRONEO S VALOR ERRONEO CR cr VALOR ERRONEO n VALOR ERRONEO < >	WRONG " L " SETTING WRONG " I " SETTING WRONG " S " SETTING WRONG " CR/cr " SETTING WRONG " n " SETTING WRONG " < > DEVICE " SETTING	VALORES QUE EXCEDEN LOS LIMITES DE LA MAQUINA HAN SIDO ENTRADOS PONER EL CURSOR ENCIMA DEL DATO ERRONEO Y VOLVER A ESCRIBIR	VALUES EXCEEDING THE LIMITS OF THE MACHINE HAVE BEEN INPUTED. PLACE THE CURSOR ON THE WRONG DATA AND WRITE IT AGAIN.
CICLO CARGA CICLO MANUAL CICLO AUTOMATICO CICLO PASO A PASO CICLO DE SOLO CORTE	LOADING CYCLE MANUAL AUTOMATIC STEP BY STEP CUT ONLY CYCLE	MUESTRA EL CICLO DE TRABAJO COLOCADO	SHOWS THE WORKING CYCLE SET.
BULTO LISTO	BUNDLE READY	HAY UN BULTO LISTO EN EL TRASPORTADOR, RECOJALO Y PRESIONE BOTON DE EXPULSION DE BULTO	THERE IS A BUNDLE READY ON CONVEYOR, TAKE IT AWAY AND PUSH BUNDLE EJECT BUTTON.
APILADOR LLENO	STACKER FULL	HAY 2 BULTOS LISTOS EN TRANSPORTADOR, RECOJERLOS Y PRESIONE BOTON DE EXPULSION DE BULTO	THERE ARE 2 BUNDLES READY ON CONVEYOR, TAKE THEM AWAY AND PUSH BUNDLE EJECT BUTTON.
PROGRAMA LOGRADO	PROGRAM ACHIEVED	CONTADOR TT TOTAL DE PIEZAS HA LOGRADO EL VALOR SET EL CICLO AUTOMATICO LTE ES DESHABILITADO PARA VOLVER A EMPEZAR EL CICLO AUTOMATICO RESET EL CONTADOR TT	COUNTER " TT " (PIECES TOTAL) HAS ACHIEVED THE VALUE SET. THE LTE AUTOMATIC CYCLE IS DISABLED. TO START AGAIN AUTOMATIC CYCLE RESET COUNTER " TT "
CAMBIO PERFIL	SHAPE HOLDER CHANGE	LA MAQUINA ESTA LISTA PARA EFECTUAR EL CICLO DE CAMBIO PORTAPERFIL	THE MACHINE IS READY TO CARRY OUT THE SHAPE-HOLDER REPLACEMENT CYCLE.
POSICIONADO	POSITIONED	EL PISADOR ESTA POSICIONADO CORRECTO PARA EFECTUAR EL CAMBIO DE PORTAPERFIL	PRESSER IS CORRECTLY POSITIONED TO CARRY OUT THE SHAPE-HOLDER REPLACEMENT.
NO TUBULAR 1 ... 2 ... 3 ... 4	NO TUBULAR 1 ... 2 ... 3 ... 4	FALTA DE UNA O MAS TELAS SENALADAS POR EL DIR 940	LACK OF ONE OR MORE FABRICS SIGNALLED BY DIR 940
NO AUTO REMOTO	REMOTE NO AUTO	EL CICLO AUTOMATICO ESTA DESHABILITADO DEBIDO AL DIR 940	THE LTE AUTOMATIC CYCLE IS DISABLED BECAUSE OF DIR 940.
LIMPIEZA MESA DE CORTE LIMPIEZA Y LUBRICACION GENERAL LUBRICACION TRANSPORTE BARRA CARRET CHEQUEAR TENSIONES CADENAS	CLEANING OF CUTTING TABLE GENERAL CLEANING AND LUBRIFICATION LUB.LINKAGE AND TROLLEY TRASPORT BAR CHECK ALL CHAIN TENSIONS	LOS MENSAJES DE MANTENIMIENTO SON MOSTRADOS PERIODICAMENTE Y SE QUEDAN POR UN TIEMPO FIJO	THE MAINTENANCE MESSAGES ARE PERIODICALLY DISPLAYED AND REMAIN FOR A FIXED TIME.

ALARMAS QUE INDICAN MALFUNCIONAMIENTO FAULT DESCRIPTIVE ALARMS		
SENALES EN EL DISPLAY INDICATION ON DISPLAY	CAUSA CAUSE	LOCALIZAR AVERIA (VEASE PAG 94) FAULT SEARCH (SEE PAGE 94)
TEJ FUERA DE POSICION TUBULAR OUT OF PLACE	INTERFERENCIA EN LA ZONA DE LA CADENA PRINCIPAL O FOTOCELULA PHI DEFECTUOSA O BIEN FALTA VOLTAJE 18V IA4 OFF INTERFACE WITHIN THE MAIN CHAIN AREA OF FAULTY PHOTOEYE PH1, OR LACK OF VOLTAGE +18V (IA4 OFF). *	ELIMINAR LA CAUSA DE LA INTERFERENCIA Y CONTROLAR LA FUNCIONALIDAD DE LA FOTOCELULA BLOQUEO CARRETA ELIMINATE THE CAUSE OF THE INTERFERENCE AND CHECK FUNCTIONALITY OF THE TROLLEY BARRAGE PHOTOEYE.
ALARMA PORTAPERFILS SHAPE HOLDER ALARM	IMANES PORTAPERFILES NO ALIMENTADOS CORRECTAMENT SHAPE HOLDER MAGNETS WITH INCORRECT SUPPLY *	CONTROLAR LA SALIDA 0-89-147 DEL TRANSFORMADOR TR2 Y IA20 CHECK OUTPUTS 0-89-147 OF TRANSFORMER TR2 E IA20
ALARMA DESPLZ EJE AXIS FAULT ALARM	DESPLAZAM CARRETA ADELANTE O ATRAS ALARMA RESECTABLE TROLLEY FAULT FORWARDS OR BACKWARDS RESECTABLE ALARM *	PSW4 FINAL CARRERA LADO ENTRADA SIEMPRE ON O DEFECTUOSO CONTROLAR LA CONEXION HACIA LA TARJETA BRB 2072 Y BRB 2044 PSW4 (LOADING SIDE TRAVEL END) ALWAYS ON OR FAULTY. CHECK CONNECTIONS TOWARDS CARDS BRB 2072 AND BRB 2044.
FRENO MOTOR PISADOR PRESSER MOTOR BRAKE	FRENO MOTOR PISADOR NO ALIMENTADO CORRECTAMENTE PRESSER MOTOR BRAKE WITH INCORRECT SUPPLY *	CONTROLAR IA21 LAS SALIDAS DEL TRANSFORMADOR TR3 Y LA TARJETA BRB 2048 CORRESPONDIENTE FUSIBLES Y CONEXIONES CHECK IA21, THE OUTPUTS OF TR3 TRANSFORMER, AND CARD BRB 2048 CORRISPONDENT (FUSES AND CONNECTIONS).
ALARMA GENERICA IA GENERIC ALARM IA	- FALTA DE VOLTAJE 18V O BIEN - UN INTERRUPTOR AUTOMATICO (IA5-6-7-8-9-10-18-19-20-21-22) OFF - O AVERIA EN GRUPO CTRL FRENOS - LA MAQUINA SE HA APAGADO Y VUELTO A ENCENDER SIN ESPERAR 10 SEG - LACK OF +18V VOLTAGE, OR - AN AUTOMATIC SWITCH (IA5-6-7-8-9-10-18-19-20-21-22) OFF, OR - BRAKES CONTROL GROUP FAULTY - SWITCHING OFF AND ON THE MACHINE WITHOUT WAITING 10 sec. *	VER F, LUEGO A SEE F, THEN A
ALARMA IA EXTERNA EXTERNAL IA ALARM	UN INTERRUPTOR AUTOMATICO IA31-32-33-34-35-36-37-38 OFF MOTOR RODILLOS Y ENSANCHADRS DIR AN AUTOMATIC SWITCH IA31-32-33-34-35-36-37-38 OFF (DIR ROLLERS AND SPREADER MOTOR). *	VER A SEE A
LAMPARA DE ALARMA DEFECTUOSA ALARM LAMP FAILURE	- LA MAQUINA SE HA ENCENDIDO Y RESET SIN ESPERAR AL MENOS 5 SEGUNDOS CON EL INTERRUPTOR DE LLAVE IC EN POSICION ON O BIEN - LA LAMPARA AMARILLA DE LA COLUMNA LUMINOSA DEFECTUOSA - THE MACHINE HAS BEEN SWITCHED ON AND RESET WITHOUT HOLDING THE KEY SWITCH " IC " IN " ON " POSITION FOR AT LEAST 5 SECONDS, OR - THE YELLOW LAMP ON THE LIGHTING COLUMN IS FAULTY. *	EFECTUAR CORRECTAMENTE EL ENCENDIDO DE LA MAQUINA SI PERMANECE SUSTITUIR LA LAMPARA AMARILLA DE LA COLUMNA LUMINOS SWITCH ON THE MACHINE EXACTLY, IF IT REMAINS REPLACE THE YELLOW LAMP OF THE LIGHTING COLUMN.

ALARMAS NUMERICAS DE MALFUNCIONAMIENTO O POR CONFIGURACNS DE SENSORES NO ACEPTABLES (PSW, MSW, Y PH)
MALFUNCTION NUMERIC ALARMS OR FOR UNACCEPTABLE SENSORS CONFIGURATIONS (PSW, MSW, AND PH)

INDICACION EN EL DISPLAY INDICATION ON DISPLAY	CAUSA	CAUSE	LOCALIZAR LA AVERIA (VER PAG 94) FAULT SEARCH (SEE PAGE 94)
ALARMA/ALARM # 001 (MAYUSCULO-CAPITAL LETTERS)	ENCODER CARRETA VERTICAL EC6 NO CONECTADO O DEFECTUOSO O FALTA DE MOV EN TIEMPO ESTABLECIDO DESPUES DE LA RELATIVA SENAL DE CONTROL	EC6 VERTICAL TROLLEY ENCODER FAULTY OR NOT CONNECTED, OR LACK OF A MOVEMENT WITHIN THE ESTABLISHED TIME, AFTER THE RELATIVE CONTROL SIGNAL. *	CONTROLAR LA FUNCIONALIDAD DEL ENCODER Y SUS CONEXIONES A LA TARJETA BRB 8000 CHECK FUNCTIONALITY OF THE ENCODER AND ITS CONNECTION TO BRB 8000 CARD.
ALARMA/ALARM # 001 (MINUSCULO-SMALL LETTERS)	CALIBRACION MOV VERTICAL CARRETA NO LLEVADA A CABO O NO CORRECTA O RAM DE LA BRB 8000 DEFECTUOSO	VERTICAL TROLLEY HEIGHT CALIBRATION NOT CARRIED OUT OR NOT OK, OR RAM OF BRB 8000 CARD FAULTY. * *	APAGADO Y ENCENDIDO LUEGO LLEVAR A CABO VERTIC MOV DE CARRETA CALIBRACION SWITCH OFF AND ON, THEN CARRY OUT THE VERTICAL TROLLEY HEIGHT CALIBRATION.
ALARMA/ALARM # 002	PSW1 - CARRETA ALTO = ON PSW3 - CARRETA BAJO = ON	PSW1 - TROLLEY UP = ON PSW3 - TROLLEY DOWN = ON *	VER B SEE B
ALARMA/ALARM # 003	SENAL INVERSION DEL ENCODER CARRETA VERTICAL EC6	SIGNAL INVERSION OF EC6 VERTICAL TROLLEY ENCODER *	CHEQUEAR LA FUNCIONALIDAD DEL ENCODER ED LA CONEXION A LA TARJETA BRB 8000 CHECK FUNCTIONALITY OF THE ENCODER AND ITS CONNECTION TO BRB 8000 CARD.
ALARMA/ALARM # 004	CICLO PRENSA INTERFERENTE CON CURSO DE CARRETA PSW7 - CARRETA FUERA DE PRENSA SIEMPRE OFF O DEFECT PSW9 - CARRETA SIN PISADOR SIEMPRE OFF O DEFECT O EN POSICION INCORRECTA	PRESSER CYCLE INTERFERING WITH TROLLEY TRAVEL PSW7 - TROLLEY OUT OF PRESSER ALWAYS OFF OR FAULTY PSW9 - PRESSER MEDIUM HEIGHT ALWAYS OFF OR FAULTY OR INCORRECTLY POSITIONED *	VER B SEE B
ALARMA/ALARM # 005	PSW10 - PISADOR BAJO SIEMPRE ON O DEFECTUOSO	PSW10 - PRESSER DOWN ALWAYS ON OR FAULTY *	VER B SEE B
ALARMA/ALARM # 006	PSW8 - PISADOR ALTO SIEMPRE ON, O BIEN PSW9 - PISADOR MEDIO SIEMPRE OFF OF DEFECTUO	PSW8 - PRESSER UP ALWAYS ON, OR PSW9 - PRESSER MEDIUM HEIGHT ALWAYS OFF OR FAULTY *	VER B SEE B
ALARMA/ALARM # 007	PSW6 - STOP CARRETA A LADO DESCARGA SIEMPRE ON O DEFECTUO	PSW6 - TROLLEY STOP AT UNLOADING SIDE ALWAYS OFF OR FAULTY *	VER B SEE B
ALARMA/ALARM # 008	PSW9 - PISADOR MEDIO SIEMPRE ON O DEFECTUOS PSW10 - PISADOR BAJO SIEMPRE ON O DEFECTUOSO PSW16 - PISADOR CASI MEDIA ALT SIEMPRE ON O DEFECT	PSW9 - PRESSER MEDIUM HEIGHT ALWAYS ON OR FAULTY PSW10 - PRESSER DOWN ALWAYS ON OR FAULTY PSW16 - PRESSER ALMOST AT MEDIUM HEIGHT ALWAYS ON OR FAULTY *	VER B SEE B
ALARMA/ALARM # 009	PSW10 - PISADOR BAJO SIEMPRE OFF	PSW10 - PRESSER DOWN ALWAYS OFF *	VER B SEE B
ALARMA/ALARM # 010	PSW8 - PISADOR ALTO SIEMPRE OFF O DEFECTUOS PSW9 - PISADOR MEDIO DEFECTUOSO	PSW8 - PRESSER UP ALWAYS OFF OR FAULTY PSW9 - PRESSER MEDIUM HEIGHT FAULTY *	VER B SEE B
ALARMA/ALARM # 011	PSW1 - CARRETA ALTO SIEMPRE ON O DEFECTUOS	PSW1 - TROLLEY UP ALWAYS ON OR FAULTY *	VER B SEE B
ALARMA/ALARM # 012	PSW12 - DESCARGA ABIERTA SIEMPRE OFF O DEFECTUOS PSW11 - DESCARGA CERRADA SIEMPRE OFF O DEFECTUOS	PSW12 - LAYING TABLE OPEN ALWAYS OFF OR FAULTY PSW11 - LAYING TABLE CLOSED ALWAYS OFF OR FAULTY *	VER B SEE B
ALARMA/ALARM # 013	ENCODER DESCARGA DEFECTUOSA O NO CONECTADA (BRB 3042) O FALTA DE MOVIM. ENTRE EL TIEMPO ESTABLECIDO DESPUES DE SENAL DE CONTROL RELATIVA	LAYING TABLE ENCODER FAULTY OR NOT CONNECTED (BRB 3042), OR LACK OF A MOVEMENT WITHIN THE ESTABLISHED TIME, AFTER THE RELATIVE CONTROL SIGNAL.	CHEQUEAR LA CONEXION DE LA TARJETA BRB 3042 Y LA CPU BRB 8000 CHECK THE CONNECTION BETWEEN BRB 3042 CARD AND BRB 8000 CPU CARD.
ALARMA/ALARM # 014	PSW13 - APILADOR ALTO Y PSW14 - APILADOR BAJO SIMULTANEAMENTE ON O PSW14 SIEMPRE ON	PSW13, STACKER UP, AND PSW14, STACKER DOWN, SIMULTANEOUSLY ON, OR PSW14 ALWAYS ON. *	VER B SEE B

INDICACION EN DISPLAY INDICATION ON DISPLAY	CAUSA	CAUSE	LOCALIZACION DE AVERIA (VER PAG 94) FAULT SEARCH (SEE PAGE 94)
ALARMA/ALARM # 015	MSW5 - STACK COMPACTO SIEMPRE OFF O SOBRECARGADO	MSW5 - COMPACT STACK ALWAYS OFF OR OVERLOAD *	VER B SEE B
ALARMA/ALARM # 016	PSW4 - CARRETA STOP AL LADO ALIMENT SIEMPRE ON O DEFECTUOSO	PSW4 - TROLLEY STOP AT FEEDING SIDE ALWAYS ON OR FAULTY *	VER B SEE B
ALARMA/ALARM # 017	PSW11 - DESCARGA CERRADA SIEMPRE ON O DEFECTUOSO O PSW12 - DESCARGA ABIERTA SIEMPRE ON O DEFECTUOS O AMBAS ON	PSW11 - LAYING TABLE CLOSED ALWAYS ON OR FAULTY, OR PSW12 - LAYING TABLE OPENED ALWAYS ON OR FAULTY * OR BOTH ALWAYS ON	VER B SEE B
ALARMA/ALARM # 019	PSW7 - CARRETA SIN PISADOR SIEMPRE ON O DEFECTUOSO	PSW7 - TROLLEY OUT OF PRESSER ALWAYS ON OR FAULTY *	SI APARECE FIN DE CURSO R : PSW7 SIEMPRE ON O DEFECTUOSO VER B DESPUES DE ESO CHEQUEAR ENCODER Y TARJETA BRB 2044 IF IT APPEARS AT R TRAVEL END: PSW7 ALWAYS ON OR FAULTY. SEE B AFTERWARDS CHECK ENCODER AND CARD BRB 2044
ALARMA/ALARM # 020	PSW5 - CARRETA DESPACIO AL LADO DESCARGA SIEMPRE ON O SIEMPRE OFF O DEFECTUOSO O POSICIONADO INCORRECTAMENTE	PSW5 - TROLLEY SLOW-DOWN AT UNLOADING SIDE ALWAYS ON, OR ALWAYS OFF, OR FAULTY OR INCORRECTLY PLACED *	SI APARECE EN RESET CON LENTAMIENTO CORRECTO : LEA 2010 IND O DEFECTUOSA - VER B IF APPEAR IN RESET WITH CORRECT SLOWING: LEA 2010 ADDRESS O FAULTY - SEE B
ALARMA/ALARM # 021	PSW7 - CARRETA SIN PISADOR SIEMPRE OFF O POSICIONADO INCORRECTAMENTE	PSW7 - TROLLEY OUT OF PRESSER ALWAYS OFF OR INCORRECTLY PLACED *	VER B SEE B
ALARMA/alarm # 034 (MINUSCOLO - SMALL LETTERS)	MEMORIA RAM DE LA CPU BRB 8000 NO INICIALIZADA	RAM MEMORY OF CPU CARD BRB 8000 NOT INITIALIZED. **	APARECE SOLO CUANDO MAQ ENCENDIDA Y DESAPARECE DESPUES DE RESET O DESPUES DE APAGAR Y ENCENDER IT APPEARS ONLY WHEN THE MACHINE IS SWITCHED ON AND DISAPPEARS AFTER RESET OR AFTER HAVING SWITCHED OFF AND ON THE MACHINE
ALARMA/alarm # 035 (MINUSCOLO - SMALL LETTERS)	FALTA DE ALAMBRE LINK N. 42 DA DIR 1-2 A DIR 3-4. LA MAQUINA SIGUE FUNCIONANDO NORMALMENTE, SOLO LOS AMPLIACIONES DE DIR 1-2 NO HACER EL MOVIMIENTO AUTOMATICO.	NO CONNECTION OF WIRE N.42 FROM DIR 1-2 TO DIR 3-4 THE MACHINE CAN OPERATE REGULARLY, ONLY THE SPREADERS OF DIR 1-2 WILL NOT MOVE AUTOMATICALLY. **	COMPRUEBE LA CONEXION DE CABLE N. 42 DA DIR 1-2 A DIR 3-4. CHECK CONNECTION OF WIRE N. 42 FROM DIR 1-2 TO DIR 3-4.
ALARMA/ALARM # 064	UNA O MAS SALIDAS DE LA TARJETA LEA 2020 IND. 3 CON NIVEL INCORRECTO. DEBE DE SER = 1 Y ES = 0 OUT0 (48) OUT2 (50) OUT4 (52) OUT6 (54) OUT1 (49) OUT3 (51) OUT5 (53) OUT7 (55)	ONE OR MORE OUTPUTS OF LEA 2020 ADDRESS 3 WITH WRONG LEVEL : IT SHOULD BE = 1 AND IS = 0 OUT0 (48) OUT2 (50) OUT4 (52) OUT6 (54) * OUT1 (49) OUT3 (51) OUT5 (53) OUT7 (55)	PROBABLE CORTOCIRCUITO EN SALIDA VER C PROBABLE SHORT CIRCUIT IN OUTPUT SEE C
ALARMA/ALARM # 072	UNA O MAS SALIDAS DE LA TARJETA LEA 2020 IND 3 CON NIVEL INCORRECTO. DEBE DE SER = 0 Y ES = 1. OUT0 (48) OUT2 (50) OUT4 (52) OUT6 (54) OUT1 (49) OUT3 (51) OUT5 (53) OUT7 (55)	ONE OR MORE OUTPUTS OF LEA 2020 ADDRESS 3 WITH WRONG LEVEL : IT SHOULD BE = 0 AND IS = 1 OUT0 (48) OUT2 (50) OUT4 (52) OUT6 (54) * OUT1 (49) OUT3 (51) OUT5 (53) OUT7 (55)	VER C SEE C
ALARMA/alarm # 083	CICLO BOMBA LUBRICACION INCORRECTO. NO BLOQUEA LA MAQUINA PERO PERMITE SOLO EL FUNCIONAMIENTO MANUAL LA LAMPARA ROJA DE LA COLUMNA LUMINOSA ESTA ENCENDIDA	LUBRICATION PUMP CYCLE INCORRECT (DOES NOT BLOCK THE MACHINE, BUT ALLOWS THE ONLY MANUAL OPERATION) THE RED LAMP OF THE LIGHTING COLUMN IS LIT UP. **	AIRE EN EL CIRCUITO DE LUBRICACION O MSW11 BOMBA LUBRICADORA O TARJETA LEA 2020 IND 4 DEFECTUOSA. ALARMA DESAPARECE SOLO DESPUES DE CICLO DE LUBRICACION CORRECTO Y COMPLETO. AIR IN THE LUBRICATION CIRCUIT OR MSW11, LUBRICATING PUMP OR CARD LEA 2020 ADDR.4 FAULTY. THE ALARM DISAPPEARS ONLY AFTER A CORRECT AND COMPLETE LUBRICATION CYCLE.

INDICACION EN EL DISPLAY INDICATION ON DISPLAY	CAUSA	CAUSE	LOCALIZACION DE AVERIA (VER PAG 94) FAULT SEARCH (SEE PAGE 94)
ALARMA/ALARM # 096	ONA O MAS SALIDAS DE LA TARJETA LEA 2020 IND 4 CON NIVEL INCORRECTO DEBERIA SER = 1 Y ES = 0 OUT8 (56) OUT10 (58) OUT12 (60) OUT14 (62) OUT9 (57) OUT11 (59) OUT13 (61) OUT15 (63)	ONE OR MORE OUTPUTS OF LEA 2020 ADDRESS 4 WITH WRONG LEVEL : IT SHOULD BE = 1 AND IS = 0 OUT8 (56) OUT10 (58) OUT12 (60) OUT14 (62) OUT9 (57) OUT11 (59) OUT13 (61) OUT15 (63) *	CORTOCIRCUITO PROBABLE EN SALIDA VER C PROBABLE SHORT CIRCUIT IN OUTPUT SEE C
ALARMA/ALARM # 099	APILADOR ARRIBA SENAL SALIDA ON OUT5 Y SIMULTANEA MENTE PH2 AREA APILADOR Y BARR FOTOCELULA ACTIVADA	STACKER UPWARDS OUTPUT SIGNAL ON (OUT5), AND SIMULTANEOUSLY PH2 ON, STACKER AREA BARRAGE PHOTOEYE. *	CHEQUEAR LA FUNCIONALIDAD DEL INVERTER CONTRL APILADOR Y DE LA FOTOCELULA BLOQUEO APILADOR PH2 CHECK THE FUNCTIONALITY OF STACKER CONTROL INVERTER AND THE STACKER BARRAGE PHOTOEYE PH2.
ALARMA/ALARM # 100	GRUPO DE MOV DE CORREA SERVOMTR MAS EJE TARJETA DE DIR 940 NO ESTA LISTO O DESHABILITADO	THE GROUP OF BELT MOVEMENT SERVODRIVER + AXIS CARD OF DIR 940 IS NOT READY OR DISABLED. *	ENCENDER Y APAGAR SWITCH CHEQUEAR STATUS DEL LED DEL GRUPO CORREA SERVOMTR MAS EJE TARJETA INDICADO EN EL MANUAL DE INSTRUCCION DIR 940 SI NO ES COMO INDICADO CHEQ CONEXIONES HACIA EL GRUPO Y EL INTERRUPTOR AUTOMATICO IA40. SWITCH OFF AND ON. CHECK THE STATUS OF THE LEDS OF THE GROUP BELT SERVODRIVER + AXIS CARD AS SHOWN IN THE DIR 940 INSTRUCTION MANUAL. IF IT IS NOT AS SHOWN CHECK THE CONNECTIONS TOWARDS THE GROUP AND THE AUTOMATIC SWITCH IA40.
ALARMA/ALARM # 104	UNA O MAS SALIDAS DE LA TARJETA LEA 2020 IND 4 CON NIVEL INCORRECTO DEBERIA DE SER = 0 Y ES = 1 OUT8 (56) OUT10 (58) OUT12 (60) OUT14 (62) OUT9 (57) OUT11 (59) OUT13 (61) OUT15 (63)	ONE OR MORE OUTPUTS OF LEA 2020 ADDRESS 4 WITH WRONG LEVEL : IT SHOULD BE = 0 AND IS = 1 OUT8 (56) OUT10 (58) OUT12 (60) OUT14 (62) OUT9 (57) OUT11 (59) OUT13 (61) OUT15 (63) *	VER C SEE C
ALARMA/ALARM # 110	UNA O MAS SALIDAS DE LA TARJETA LEA 2020 IND 5 CON NIVEL INCORRECTO DEBERIA DE SER = 1 Y ES = 0 OUT16 (152) OUT18 (154) OUT20 (156) OUT22 (158) OUT17 (153) OUT19 (155) OUT21 (157) OUT23 (159)	ONE OR MORE OUTPUTS OF LEA 2020 ADDRESS 5 WITH WRONG LEVEL : IT SHOULD BE = 1 AND IS = 0 OUT16 (152) OUT18 (154) OUT20 (156) OUT22 (158) OUT17 (153) OUT19 (155) OUT21 (157) OUT23 (159) *	PROBABLE CORTOCIRCUITO EN SALIDA VER C PROBABLE SHORT CIRCUIT IN OUTPUT SEE C
ALARMA/ALARM # 111	UNA O MAS SALIDAS DE LA TARJETA LEA 2020 IND 5 CON NIVEL INCORRECTO DEBERIA DE SER = 0 Y ES = 1 OUT16 (152) OUT18 (154) OUT20 (156) OUT22 (158) OUT17 (153) OUT19 (155) OUT21 (157) OUT23 (159)	ONE OR MORE OUTPUTS OF LEA 2020 ADDRESS 5 WITH WRONG LEVEL : IT SHOULD BE = 0 AND IS = 1 OUT16 (152) OUT18 (154) OUT20 (156) OUT22 (158) OUT17 (153) OUT19 (155) OUT21 (157) OUT23 (159) *	VER C SEE C
ALARMA/ALARM # 160	EJE CARRET TARJETA BRB 2044 O 2045 PROBLEMT DEFECTUOSO	TROLLEY AXIS CARD BRB 2044 OR BRB 2045 PROBABLY FAULTY. *	CHEQUEAR LA TARJETA BRB 2044 CARRETA Y BRB 2045 EL GRUPO INVERSOR Y EL CABLE CONECT RELEVAN DEL INVERSOR A LA BRB 2044 CHECK CARDS BRB 2044 TROLLEY AND BRB 2045, THE INVERTER GROUP AND THE RELEVANT CONNECTING CABLE FROM INVERTER TO BRB 2044.
ALARMA/ALARM # 161	ENCODER CARRETA HORIZONTAL EC5 DEFECTUOSO O CADENA DE TRANSMISION MUY SUELTA	HORIZONTAL TROLLEY ENCODER EC5 FAULTY OR THE TRANSMISSION CHAIN TOO LOOSE. *	CHEQUEAR LA CONEXION DEL MOTOR HORIZONTAL HACIA EL INVERSOR LA CONEXION DEL ENCODER Y LA TENSION DE LA CADENA DE TRANSMISION CHECK THE CONNECTION OF TROLLEY HORIZONTAL MOTOR TOWARDS THE INVERTER, THE CONNECTION OF ENCODER AND THE TENSION OF THE TRANSMISSION CHAIN.

INDICACION EN EL DISPLAY INDICATION ON DISPLAY	CAUSA	CAUSE	LOCALIZACION DE AVERIA (VER PAG 94) FAULT SEARCH (SEE PAGE 94)
ALARMA/ALARM # 163	FALTA DE MOV DEL MTR CARRETA HORIZONTAL O EL ENCODER EC5 ESTA DEFECTUOSO	NO MOVEMENT OF HORIZONTAL TROLLEY MOTOR OR ENCODER EC5 FAULTY.	APAGAR, ENCENDER Y RESETAR SI LA CARRETA NO SE MUEVE CHEQUEAR EL MOTOR Y EL CIRCUITO DE CONTROL (INVERTER ETC) SI LA CARRETA SE MUEVE IRREGULARMENTE CHEQUEAR EL ENCODER Y EL CIRCUITO DE CONTROL RELEVANTE SWITCH OFF, SWITCH ON AND RESET. IF THE TROLLEY DOESN'T MOVE CHECK THE MOTOR AND THE CONTROL CIRCUIT (INVERTER, ETC..) IF THE TROLLEY MOVES IRREGULARLY CHECK THE ENCODER AND THE RELEVANT CONTROL CIRCUIT.
ALARMA/ALARM # 164	TARJETA BRB 2044 EJE HORIZONTAL CARRETA DEFECTUOS O ROTA	BRB 2044 HORIZONTAL TROLLEY AXIS CARD FAULTY.	CHEQUEAR LA TARJETA BRB 2044 Y REEMPLAZARLA SI ES NECESARIO CHECK BRB 2044 CARD AND REPLACE IT IF NECESSARY.
ALARMA/ALARM # 170	ERRONEA COMUNICACION ENTRE BRB 8000 Y TARJETA BRB 2044 CARRETA EJE HORIZONTAL O TARJETA EJE BRB 2044 DEFECTUOSA	WRONG COMMUNICATION BETWEEN BRB 8000 CPU CARD AND BRB 2044 HORIZONTAL TROLLEY AXIS CARD, OR BRB 2044 AXIS CARD FAULTY.	CHEQUEAR LAS CONEXIONES CORRECTAS DE CABLES DE FIBRA OPTICA ENTRE TARJTS. VER E ENTONCES SUSTITUIR TARJ EJE BRB 2044 CHECK THE CORRECT CONNECTIONS OF THE OPTICAL FIBER CABLES BETWEEN CARDS. SEE E. THEN REPLACE BRB 2044 AXIS CARD.
ALARMA /alarm # 181	MEMORIA RAM DE LA BRB 8900 DEL DIR 940 3 - 4 DEFECTUOSA O NO INICIALIZAD	RAM MEMORY OF BRB 8900 CARD OF DIR 940 3-4 FAULTY OR NOT INITIALIZED	APAGAR Y ENCENDER SI PERMANECE SUSTITUIR BRB 8900 DIR 3-4. SWITCH OFF AND THEN ON, IF IT REMAINS REPLACE BRB 8900 DIR 3-4.
ALARMA/ALARM # 240	FALTA O INTERRUPCION DE UN MOVIMIENTO DURANTE EL CICLO MANUAL O AUTOMATICO O FALTA DE MOV POR PARTE DEL SENSOR CORRESPONDIENTE DE LA ENTRADA DE LA TARJETA LEA 2010 SIENDO EVIDENTE DESPUES 10 NO ACTIVAD DURANTE CICLO PASO A PASO	LACK OR INTERRUPTION OF A MOVEMENT DURING MANUAL OR OR AUTOMATIC CYCLE, OR LACK OF MOVEMENT ACQUISITION BY MEANS OF THE CORRESPONDING SENSOR OR THE CORRESPONDING INPUT CARD LEA 2010 (BECOMING EVIDENT AFTER 10") NON ACTIVATED DURING STEP BY STEP CYCLE.	NOTAR LA FASE DEL CICLO EN QUE SE PARO LA MAQUINA SI APARECE CON APILADOR BAJO CHEQUEAR PH2 DESPUES CHEQUEAR LA FUNCIONALIDAD DE PSW1-PSW3-PSW4-PSW5-PSW6-PSW11-PSW12-PSW14-PH3 VER B NOTE THE PHASE OF CYCLE WHERE MACHINE STOPPED. IF IT APPEARS WITH STACKER DOWN, CHECK PH2. AFTERWARDS CHECK FUNCTIONALITY OF: PSW1-PSW3- PSW4-PSW5-PSW6-PSW11-PSW12-PSW14-PH3. SEE B
ALARMA/ALARM # 241	FALTA DE CICLO PISADOR PSW8 PISADOR ALTO SIEMPRE OFF CON PISADOR ALTO Y PARADO	LACK OF PRESSER CYCLE: PSW8, PRESSER UP, ALWAYS OFF (WITH PRESSER UP AND IDLE).	VER B SEE B
ALARMA/ALARM # 242	PSW8 PISADOR ALTO SIEMPRE OFF O DEFECTUOSO O POSICIONADO INCORRECTAMENTE O VELOCIDAD DEL PISADOR NO CORRECTA	PSW8 PRESSER UP ALWAYS OFF OR FAULTY OR INCORRECTLY POSITIONED, OR PRESSER SPEED WRONG.	VER PAG 22 - 25 SEE PAGE 22-25
ALARMA/ALARM # 243	MEMORIA RAM DE BRB 8000 DEFECTUOSA	FAULTY RAM MEMORY OF BRB 8000 CARD	ENCENDER Y APAGAR SI PERMANECE SUSTITUIR BRB 8000. SWITCH OFF AND THEN ON, IF IT REMAINS REPLACE BRB 8000 CARD.
ALARMA/ALARM # 244	SEÑAL DE CONTROL INVERTOR ES OFF: IN34 (34) = 0 UN INVERTOR ESTA BLOQUEADO	INVERTER CONTROL SIGNAL IS OFF: IN34 (34) = 0 AN INVERTER IS BLOCKED.	APAGAR, ESPERAR POR 20 SEG Y ENCENDER Y CHEQUEAR EL STATUS DEL INVERTER EN DISPLAY RELATIVO SWITCH OFF, WAIT FOR 20 sec, THEN SWITCH ON AND CHECK THE STATUS OF THE INVERTERS ON THE RELEVANT DISPLAY.

 bierrebi italian cutting technologies	ALARMAS	*	BLOQUEA LA MAQUINA / BLOCKS THE MACHINE	240/4-05	94
	ALARMS	* *	NO BLOQUEA LA MAQUINA / DOES NOT BLOCK THE MACHINE		

INDICACION EN EL DISPLAY INDICATION ON DISPLAY	CAUSA	CAUSE	LOCALIZACION DE AVERIA (VER PAG 94) FAULT SEARCH (SEE PAGE 94)
ALARMA/ALARM # 247	MEMORIA RAM DE BRB 2057 DEFECTUOSA	FAULTY RAM MEMORY OF BRB 2057 CARD * *	APAGAR Y ENCENDER Y SE QUEDA SUSTITUIR BRB 2057 SWITCH OFF AND THEN ON, IF IT REMAINS REPLACE BRB 2057 CARD.
ALARMA/ALARM # 253	ALARMA FIBRA OPTIC: NO HAY COMUNICACION ENTRE BRB 8000 Y TARJETA EJE BRB 2044	OPTICAL FIBER ALARM: NO COMMUNICATION BETWEEN BRB 8000 CPU CARD AND BRB 2044 AXIS CARD. *	VER E SEE E
ALARMA/ALARM # 254	ALARMA FIBRA OPTICA: FALTA UN USADOR (TARJETA CPU) EN LINEA (CHEQUEAR EN LA MASCARA DIAGNOSTICO CUAL USADR TARJETA NO SE COMUNICA MAS)	OPTICAL FIBER ALARM: ONE USER (CPU CARD) MISSING IN LINE (CHECK IN THE DIAGNOSTIC MASK WHICH USER CARD DOES NOT COMMUNICATE ANY LONGER) *	VER E SEE E
ALARMA /alarm # 255	COMUNICACION ERRONEA ENTRE TARJETA CPU BRB 8900 DE DIR 940 3-4 Y TARJETA CONTROL CORREA EJE DEL GRUPO MOVIMIENTO CORREA DEL DIR 940	WRONG COMMUNICATION BETWEEN BRB 8900 CPU CARD OF DIR 940 3-4 AND BELT CONTROL AXIS CARD (OF BELT MOVEMENT GROUP OF DIR 940). * *	CHEQUEAR LA CONEXION ENTRE CONECTOR CN60 DE LA TARJETA CPU 8900 DIR 3-4 Y CONECTOR CN59 DE LA TARJETA BRB 3013 EN EL PANEL ELECTRICO DE CONTROL DE CORREA ENTONCES CHEQUEAR LA CONEXION ENTRE CN56 DE BRB 3013 Y TARJETA DE EJE CORREA CHECK THE CONNECTION BETWEEN CONNECTOR CN60 OF BRB 8900 CPU CARD DIR 3-4 AND CONNECTOR CN59 OF BRB 3013 CARD, IN THE ELECTRIC PANEL OF BELT CONTROL. THEN CHECK THE CONNECTION BETWEEN CONNECTOR CN56 OF BRB 3013 CARD AND BELT AXIS CARD.

 bierrebi italian cutting technologies	ALARMA	*	BLOQUEA LA MAQUINA / BLOCKS THE MACHINE	240/4-05	95
	ALARMS	* *	NO BLOQUEA LA MAQUINA / DOES NOT BLOCK THE MACHINE		