

Connecting wifi through bluetooth in rpi

in rpi:

```
sudo systemctl restart bluetooth
```

```
rfkill unblock bluetooth
```

```
bluetoothctl power on
```

```
bluetoothctl discoverable on
```

```
bluetoothctl pairable on
```

```
hciconfig (if it shows DOWN instead of UP)=> sudo hciconfig hci0 up
```

on rpi:

```
sudo rfcomm listen hci0 1
```

and then run this in laptop:

```
sudo rfcomm connect hci0 <PI_MAC_ADDRESS> 1
```

eg: sudo rfcomm connect hci0 D8:3A:DD:46:FC:C4 1

on rpi:

run the script bt_wifi_control.py. USE SUDO PYTHON3

on laptop:

```
echo -ne "WIFI_ON\n" > /dev/rfcomm0 for wifi on
```

```
echo -ne "WIFI_OFF\n" > /dev/rfcomm0 for wifi off
```