



Features


- ❖ Adopting dual-core ESP32UE 32bits high-speed processor,max main frequency is 240MHz.
- ❖ Pre-installed FluidNC firmware,
compatible with CNC3D COMMANDER,Candle,Bcnc,
GRBLPlotter software...
- ❖ Support six stepper drivers. X,Y,Z,A,B,C axis.
- ❖ Support Homing,software/hardware endstop,Z probe,macro...
- ❖ Support hotspot,Wifi to control.
- ❖ 12V 3pin laser signal output.
- ❖ Standard PWM and 0-10V analog voltage output.
- ❖ Support DC 24V
Auto-cut off power when voltage exceeding 30V.
Automatically select external power supply as the main control input
power,and prevent reverse power transmission,protect USB port.







Install CH340 Driver



arduinoIDE	2023/5/6 星期六 ...	文件夹	
ch340驱动	2023/5/6 星期六 ...	文件夹	
cp2102驱动	2023/5/6 星期六 ...	文件夹	
CH341SER.EXE	2022/10/23 星期...	应用程序	632 KB
Grbl_Esp32-6.rar	2023/5/6 星期六 ...	WinRAR 压缩文件	1,103 KB
grbl设置.rar	2022/11/3 星期...	WinRAR 压缩文件	114 KB
libraries.zip	2022/11/5 星期...	WinRAR ZIP 压缩...	61,212 KB
精雕5.5破解版.rar	2022/10/6 星期...	WinRAR 压缩文件	29,845 KB
精雕教程.txt	2023/5/6 星期六 ...	文本文档	1 KB
诺诚4.0.rar	2022/10/6 星期...	WinRAR 压缩文件	8,724 KB
上位机软件.rar	2022/11/2 星期...	WinRAR 压缩文件	110,909 KB







Software

CNC3d Commander










\$sta/ssid=Your wifi account


\$sta/password=Your wifi password

\$bye




```
Raw Datalog
Options | Clear Note: "<=> = sending to chip" and ">> = receiving from chip" Send: $bye Send Copy all to Clipboard
>> [MSG:INFO: feed_hold_pin gpio.36]
>> [MSG:INFO: Kinematic system: Cartesian]
>> [MSG:INFO: PWM Spindle Ena:gpio.12 Out:gpio.27 Dir:NO_PIN Freq:5000Hz Period:8191]
>> [MSG:INFO: Using spindle PWM]
>> [MSG:INFO: Flood coolant I2S0.24]
>> [MSG:INFO: Mist coolant gpio.4]
>> [MSG:INFO: Probe Pin: gpio.34:low]
>> [MSG:INFO: Connecting to STA SSID:haibin-kt]
>> [MSG:INFO: Connecting.]
>> [MSG:INFO: Connecting..]
>> [MSG:INFO: Connecting...]
```

Open browser and enter above IP address to access the control card.



Download config file and open.




```
board: 6 Pack
name: 6 Pack StepStick XYZABC
stepping:
  engine: I2S_STREAM
  idle_ms: 250
  pulse_us: 4
  dir_delay_us: 6
  disable_delay_us: 0
axes:
  shared_stepper_disable_pin: NO_PIN
  x:
    steps_per_mm: 800.000
    max_rate_mm_per_min: 5000.000
    acceleration_mm_per_sec2: 100.000
    max_travel_mm: 300.000
    soft_limits: false
    homing:
      cycle: 1
      positive_direction: false
      mpos_mm: 0.000
      feed_mm_per_min: 100.000
      seek_mm_per_min: 200.000
      settle_ms: 500
      seek_scaler: 1.100
      feed_scaler: 1.100
  motor0:
    limit_neg_pin: NO_PIN
```

Firmware Update

This board pre-installed FluidNC firmware, also uploaded yaml and index files.

Latest FluidNC: <https://github.com/bdring/FluidNC>

Open flash_download_tool_3.9.3_0 software.



Upload file

First line

[firmware.bin](#)

2th


[boot_app0.bin](#)

3th

[bootloader_qio_80m.bin](#)

4th

[Grbl_Esp32.ino.partitions.bin](#)




Select COM, then Erase previous files.




After successfully download,configure wifi as previous tell.

Also,need to upload Yaml and Index file when finish wifi configuration.




Unlock and upload config.yaml and index file.



名称	修改日期	类型	大小
config.yaml	2024/11/6/周三 9:29	YAML 文件	6 KB
index.html	2024/11/6/周三 9:29	WinRAR 压缩文件	114 KB

Go to ESP3D interface.



Re-start CNC3d commander,will see 6 axis.

Firmware flash complete.

More refer to

<http://wiki.fluidnc.com/en/config/overview>