User Guide

Using Lyra BitPerfect

Version 1.2

This guide explains the main controls and music-library operations in Lyra BitPerfect. For full technical documentation, download the Technical Report from lyrabitperfect.com.

1. Interface Overview

The main screen has a display at the top and playback controls below. Double-tap the display to cycle through three modes.

Display Mode	How to Activate	What You See
Spinning CD	Default display	Animated CD, track information and progress bar
VU Meter	First double-tap	Two analog needles showing real RMS level
Goniometer	Second double-tap	Stereo phase visualization (Lissajous figure)

2. The Three Audio States

The BITPERFECT control manages three distinct playback states. The LED identifies the active state.

LED	State	What Lyra Does
White / Pearl	Direct Playback	Standard Android audio path without Tone DSP
Green	Direct Mode	Direct high-fidelity path without Tone processing
Blue	BitPerfect USB	Bit-perfect output to a compatible external USB DAC

Press BITPERFECT to activate Direct Mode (green). With a compatible USB DAC connected, Lyra can switch to BitPerfect USB (blue). Press again to return to Direct Playback.

3. Tone Control

Activate the TONE switch to enable tonal shaping, then turn the knob between WARM and AIR. The display shows DIRECT at the center, WARM values on one side and AIR values on the other.

Setting	Range	Effect
WARM	−6 to 0	Gently reduces higher frequencies
DIRECT	0	Neutral Tone setting
AIR	0 to +6	Gently reduces lower frequencies

The Tone indicator is green when Tone is enabled and white when disabled. Tone and BitPerfect modes are mutually exclusive: enabling Tone deactivates BitPerfect; enabling BitPerfect deactivates Tone. Switching Tone off does not by itself activate BitPerfect. The DAC may remain connected as an audio output when Tone is in use.

4. Connecting a USB DAC

Connect a supported USB Audio Class 1 or 2 (UAC1/UAC2) DAC. When BitPerfect is enabled and the DAC is recognized as compatible, Lyra indicates USB BitPerfect with a blue LED and a deep-blue CD. Disconnecting the DAC returns the mode indication to Direct Mode where applicable.

Compatibility depends on the DAC and the Android device. Connecting a DAC does not guarantee bit-perfect operation in every hardware configuration. If Tone is enabled, BitPerfect USB is disabled, even though playback can continue through the connected DAC.

5. Music Library

Tap the library control to browse audio indexed by Android. The main sections are Music, Artists, Albums and Playlists. The Internal Storage tree shows locations containing indexed audio rather than every folder on the device. Android normally updates its multimedia catalog automatically as music is added or removed.

Browsing and playing music

In Music, navigate through folders and tap a track to play it. Use PLAY FOLDER to play the tracks in the chosen folder. Selecting music opens the player automatically. The library remembers the last location visited. Browsing the library does not interrupt the track already playing.

Selecting several songs from Music

Touch and hold the first song to enter selection mode, then tap other songs to add or remove them from the selection. Choose PLAY SELECTED to play the selection, or SAVE PLAYLIST to save it to a new or existing playlist. Creating a new playlist from an active selection saves those selected songs directly to the new list.

6. Creating and Adding to Playlists

Open Playlists, tap New playlist, enter a name and choose CREATE. Lyra opens that playlist. Tap ADD SONGS to enter the song-selection mode: the playlist name remains visible so you know where the chosen tracks will be saved.

Navigate through your music folders and tap songs to select them. In this ADD SONGS mode, a normal tap selects rather than starts playback. You may select songs from more than one folder. Choose ADD SELECTED to include the selected tracks in the playlist; use CANCEL to leave without adding them.

You can open the playlist and use ADD SONGS again at any time. Playlist names must be distinct; creating a new one does not silently overwrite another.

Opening and playing a playlist

Tap a playlist name to inspect its songs, or use the Play icon beside its name to play the whole list directly. Within an open playlist, tap a song once to play that song immediately.

7. Managing and Deleting Playlist Entries

To select songs already inside a playlist, touch and hold the first song. This activates selection mode; subsequent taps select or deselect additional songs. A normal tap before entering selection mode starts playback, so the long press is important.

Action	Result
PLAY SELECTED	Play only the songs currently selected in the playlist.
DELETE	Remove the selected songs from this playlist, after confirmation.
ADD SONGS	Browse and add new songs to the existing playlist.
Delete playlist	From the Playlists overview, touch and hold the playlist name, choose Delete playlist and confirm.

Deleting entries never deletes the original music files. DELETE within a playlist removes only the selected references. If every track is removed, the playlist itself stays available, with zero songs, ready to be filled again using ADD SONGS.

Deleting the playlist from the Playlists overview removes the list and its entries, but still does not delete any audio files from the phone. To delete an actual music file, use Android’s file manager outside Lyra.

8. Progress Bar and Session Recovery

Drag the gold marker on the progress bar to seek to a specific place in the track; release it to confirm. Touch and hold Previous or Next for fast rewind or fast forward.

When Lyra is closed and opened again, it restores the last playback queue, selected track and saved position, where available. The position indicator returns to the saved point while playback remains paused until you press Play.

9. Trial Period and License

Item	Details
Trial period	21 days from first launch; full access to features
On expiry	License screen appears; tap the wax seal to purchase
Price	EUR 10.99 — one-time payment; no subscription or advertising
After purchase	Lifetime access without recurring license fees

“An interface that does not look like an app, but a €5,000 physical object.”

lyrabitperfect.com — support@lyrabitperfect.com