

**Classifier LSKS..., LSKS...CS, LSKS...CS-Z,
LSKS...D, LSKS...ZD**

Flap Positioning

Working Instructions

Table of Contents:

	Sheet
1. Assembling the flaps	1
2. Alignment of flap adjustment	1
Alignment of flaps in the initial adjustment	1
Alignment of scales	1
Adjusting the flaps during operation	2

1. Assembling the flaps

The flap unit which comprising the flap carrier cpl. and the flap itself is normally installed in the classifier in a preassembled condition.

The upper axle is inserted into the drilled holes from the underside of the frame or classifier upper housing. It is retained with the aid of two nuts and a steel washer.

The installation of the flap is to be made according to the drawing "Flap Positioning cpl.". Care is thereby to be taken for the correct (clockwise or anti-clockwise) tangential arrangement and vertical alignment.

2. Alignment of flap adjustment

Alignment of flaps in the initial adjustment

In the case of large, accessible rotors this can be carried out from inside the rotor after removing a few of the blades. For smaller, non-accessible rotors the flaps should be aligned before installing the rotor.

The alignment is accomplished with the help of a simple gauge made of steel plate (see assembly "Auxiliaries: Flap Positioning cpl."). The previously installed flaps are turned so that they contact the gauge, as shown in the drawing. To retain each upper flap axle the bottom nut is tightened until the flap is pulled firmly against the frame (or classifier upper housing). When this nut can no longer be tightened, the counter nut can be locked against it.

Alignment of scales

To align the scale the pointer (see assembly "Auxiliaries: Flap Positioning cpl.") must first be mounted on the square of the respective axle and fixed using the wing nut. The scale is then positioned as shown in the drawing. The scale is aligned so that the pointer shows the initial adjustment 0° and then tack welded or glued in place.

**Classifier LSKS..., LSKS...CS, LSKS...CS-Z,
LSKS...D, LSKS...ZD**

Based on the zero position the scale has a positive and negative side. Adjustments in the positive direction increase the width of the classification gap but decrease the gap between the flaps themselves.

Adjustments in the negative direction reduce the classification gap width but increase the gap between the flaps themselves.

Should, in an exceptional case, the initial operational angle be at variance to the initial adjustment, this is to be amended immediately after aligning the scale.

Adjusting the flaps during operation

Each time before the flaps are adjusted, the respective flap angle is to be checked by inserting the pointer.

Both nuts are to be released a few millimetres to aid adjustment. After that the pointer and the ring spanner (assembly "Auxiliaries: Flap Positioning cpl.") are to set on the square of the axle.

If the axle cannot be turned (e.g. caking in the axle bores), loosen by knocking with the ring spanner a few times.

After setting to the required angle for flap operation, the nuts are tightened again and the axle is clamped in the new position.

Flap positioning can be carried out whilst the classifier is shut down or during operation. During shutdown it is recommended that all flaps are loosened in the first place and that adjustment and re-clamping is then carried out. During operation all work must be carried out sequentially on each flap.