

LOESCHE-Roller Grinding Mill**Safety****Table of Contents:**

	Sheet
1. Explanation of Symbols	1
1.1 "Safety at Work" Symbol	1
1.2 "Attention" Symbol	1
2. Notes on Safety at Work	2

1. Explanation of Symbols**1.1 "Safety at Work" Symbol**

In these Operating Instructions (BA) this symbol is assigned to all notes on safety at work in case of non-compliance with which apparent danger will result. Make sure to pay attention to these notes and be particularly careful in these cases. All notes on safety at work should also be brought to the attention of other users. Apart from the guidelines in these BA it will be necessary to observe all safety and accident prevention regulations as applicable in general.

1.2 "Attention" Symbol**Attention !**

This "Attention!" symbol will be found in those paras herein to which particular attention should be paid to ensure compliance with guidelines, regulations, notes, and the appropriate sequence of operations and thus to prevent damage or destruction of machines and/or other plant components.

2. Notes on Safety at Work

Particular attention shall be paid to the following notes as to safety at work:

- LOESCHE roller grinding mills are built according to the state of the art and offer operational reliability and safety. Roller grinding mills may create hazardous conditions, however, when improperly operated by unskilled persons or used for any other than the intended purpose.
- Roller grinding mills shall not be used for any other than the specified application. Any such other use constitutes a reason for non-conformity. The manufacturer will not assume any liability for damages arising therefrom. The full responsibility shall be vested in the user.
- The user shall ensure that the roller grinding mill will be operated only in good working order.
- Cleanliness and tidiness within the working area at the roller grinding mill shall be ensured by appropriate instructions and inspections by the user.
- Unauthorised modifications and changes having influence on the safety of roller grinding mill shall not be permissible.
- No modes of operation or manipulations shall be allowed which could affect mill safety.
- It shall be the operator's responsibility to immediately report any changes affecting the safety of roller grinding mill.
- The LOESCHE roller grinding mill shall not be operated unless it is ensured that all guards and other safety devices provided by manufacturer are properly fitted and serviceable.
- All safety rules and accident prevention regulations as applicable locally shall be observed for operation of the roller grinding mill.
- Use as prescribed also includes compliance with the instructions given by the manufacturer in regard to assembly and erection, dismantling and re-installation, commissioning and startup, operation and maintenance (inspection, maintenance and repair) of the roller grinding mill.
- The user shall ensure that operation, maintenance and repair of the roller grinding mill will be effected by authorized, trained and experienced personnel only. Such staff shall be duly instructed as to the hazards that may be encountered with the mill.

- Any person engaged in assembly and erection, dismantling and re-installation, commissioning and startup as well as operation and maintenance shall have read and fully understood the complete operating instructions and in particular the "Safety" portion thereof. The user is recommended to obtain a confirmation to this effect in writing.
- The responsibilities for assembly and erection, dismantling and re-installation, commissioning and startup as well as operation and maintenance need to be clearly defined and adhered to, in order to avoid any unclear competences under the aspect of safety.
- When performing any work relating to assembly and erection, dismantling and re-installation, commissioning and startup as well as operation and maintenance attention shall be paid to the shutdown procedures outlined in the operating instructions. Any such work may be commenced only when the equipment is in cold condition.
- Doors and flaps or gates shall only be opened after shutdown of roller grinding mill and cooling to room temperature.
- Prior to commencement of any work on the roller grinding mill the ancillary facilities thereof shall be protected against accidental starting.
- Lifting equipment and its attachments must be inspected before use. The operator is responsible for ensuring that no excessive loads are to be carried.

A regular inspection of lifting equipment is to be carried out and documented, according to the prevailing regulation.
- The capacity of lifting appliances to be installed must be higher than the weight of the heaviest part of roller grinding mill.
- Welding on or inside the machine shall not be permissible unless all applicable safety regulations will be observed.
- The machines shall be cleaned regularly. Any dust deposits forming as a result of lack of tightness or the like shall be eliminated immediately.
- Prior to startup after repairs, it should be checked that all cleaning and inspection doors are properly closed.
- All statutory accident prevention regulations valid in the designated country shall be observed when performing any maintenance work and inspections.