



Precautions For The Use Of Joint Modules



Avatar Intelligent Equipment Co., Ltd.

Mobile/Whatsapp:0086 18037112823

Fax: 0086-371-63685191 **Tel:** 0086-371-55919261

Email: emma@avatarroboticparts.com

Web: www.atarrobot.com

Add: No.Kinso Road, Zhengzhou, Henan Province, China

- Confirmation of goods.

- Please check the modules and attachments according to the packing list as soon as you receive the modules.

- Safe operation.

- Do not plug or remove the line with power on, and ensure complete discharge before removing the capacitor.

- Equipment in place.

- Make sure the mechanical strength of the installation location is sufficient to support the weight of the integrated joints, and ensure that the installation is stable.

- Screw fixing.

- Screw fixing of motor and structural parts must be done with thread glue and torque wrench, and strictly follow the torque reference value in the motor manual.

- Wiring specification.

- Strictly follow the pin definition for wiring, avoid judging according to the color of the cable, and ensure that the resistance is matched.

- Power supply.

- Make sure the power supply voltage matches the rated voltage of the integrated joint. When users connect the external lithium battery, if the rated voltage is 48V, and connect the integrated motor when the battery is fully charged, the power supply voltage may exceed 60V at the moment of startup, which may affect the work of the motor or even damage it. Preventive measures are to install electrolytic capacitors for voltage smoothing or connect the voltage regulator module in series to the motor terminal to stabilize the supply voltage.

- Battery power supply system.

- For battery power supply system, the battery can be used to absorb the reverse current to avoid the voltage exceeding the rated value.

- Power supply system.

- In the switching power supply system, the integrated motor may generate power generation effect when accelerating too fast or doing work by gravity load, resulting in higher bus voltage, which may trigger over-voltage error report. To prevent this, it is recommended to take measures such as connecting large-capacity electrolytic capacitors in parallel or adding braking resistors to reduce the voltage impact.

- Avoid electric shock and injury.

- When the motor is energized and in operation or when there are structural parts, it is strictly prohibited to touch the motor end directly with hands to prevent accidental electric shock or injury by structural parts.

- Motor disassembly.

- It is forbidden to disassemble the motor privately. Only in special circumstances, after consultation and under professional guidance can be disassembled. Private disassembly will not be eligible for warranty service.

- Transportation after disassembly.

- If problems occur after disassembling the motor under guidance, make sure all the original screws are fixed intact before sending it back to prevent damage caused by bumps during transportation, such as reducer screws, rear cover screws, etc.