



CURISYM 400

قوة الأداء ... راحة القيادة
POWER. COMFORT. CONTROL.



POWERFUL
ENGINE



ADVANCED
SAFETY



MODERN
DESIGN



MAXIMUM
COMFORT



SPECIFICATIONS

	Model	LZK40T1CN
	Length	2230 ± 20mm
	Width	820 ± 10mm
	Height	1360 ± 20mm
	Wheel base	1552 ± 20mm
	Seat height	785 ± 5mm
	Net Weight	222 ± 6kg
	Max allowable weight	372 ± 6kg (front: 135 ± 4kg rear: 237 ± 4kg)
	Type	4- stroke engine
	Fuel Required	Unlead gasoline
	Compression ratio	10.5 ± 0.2:1
	Maximum HP	25.0kw/6750rpm
	Maximum torque	37.0Nm/5000 rpm
	Starting methods	electrical starter
	Front shock absorber	Periscope type
	Rear shock absorber	Straight barrel damping type
	Clutch	Auto Centrifugal type
	Transmission	C.V.T.
	Front tire	120/70 R15 M/C 56S
	Rear tire	160/60 R14 M/C 65H
	Wheel	Aluminum

	Tire pressure	Front: STD 2.3 kgf/cm ² Rear: STD 2.5kgf/cm ²
	Front brake	Disk type (Ø 288 mm)
	Rear brake	Disk type (Ø 275 mm)
	License light	12V 5W
	Headlight deep/main beam	12V 67.5W 47.5W (LED)
	Position lamps	12V 12W (LED)
	Taillight/stoplight	12V 2.1W 12W (LED)
	Front Turn signal light	12V 2.4W*2 (LED)
	Rear Turn signal light	12V 2.2W*2 (LED)
	Engine oil capacity	2.0L (1.9 L for change/ 1.8L for no change filter)
	Transmission oil capacity	350c.c (330c.c for change)
	Fuel tank capacity	14.5 ⁰ ₋₁ L
	Fuse	5A+10A*3+15A*4+20A
	Fuel consumption for front shock absorber	340ml
	Spark plug	CPR8EA-9
	Battery capacity	YTZ12S(MF) 12V 11AH
	Air cleaner	Paper type



CURISYM 400

قوة الأداء ... راحة القيادة
POWER. COMFORT. CONTROL.



POWERFUL
ENGINE



ADVANCED
SAFETY



MODERN
DESIGN



MAXIMUM
COMFORT



PERIODICAL MAINTENANCE SCHEDULE

Item	Check Items	Maintenance kilometer	300KM	Every 1000KM	Every 3000KM	Every 6000KM	Every 12000KM	Remarks
		Maintenance Interval	NEW	1 Month	3 Months	6 Months	1 Year	
1	Air cleaner element (Remark)		I	C	.	R(paper)	R(sponge)	
2	Air cleaner		I		C			
3	Oil filter (Screen)		C			C		
4	Oil filter (Paper)		R	Replacement for every 3000KM				
5	Fuel pump filter		I	Replacement for every 10000KM				
6	Engine oil(water cooling)		R	Inspection for every 1000KM ,Replacement for every 5000KM				
7	Engine oil(air cooling)		R	Inspection for every 1000KM ,Replacement for every 3000KM				
8	Tire, pressure		I	I				
9	Battery		I	I				
10	Cooling system			Inspection for 10000 km				
11	Coolant level			Inspection for 10000 km				
12	Coolant, water hoses and o-rings			Replacement for every 3 years				
13	Spark plug		I		I		R	
14	Steering bearing and handles		I		I			
15	Check transmission for leakage		I	I				
16	Check crankcase for leakage		I	I				
17	Transmission oil		R	Replacement for every 5000KM(5 Months)				
18	CVT system Drive belt/rollers)		I			I	R	
19	Fuel tank switch and lines		I	I	I			
20	Throttle valve operation and cable		I	I				
21	Engine bolts and nuts		I		I			
22	Cylinder head, cylinder, and piston							
23	Exhaust system/cleaning carbon					I		
24	Cam Chain/ignition time		I		I			
25	Valve clearance		I			I		
26	Shock absorbers		I			I		
27	Shock tension rod			Inspection for every 10000KM,Replacement for every 30000KM				
28	Front/rear suspension		I			I		
29	Main/side stands		I			I/L		
30	Crankcase Blow-by system(PCV)		I		I			
31	Clutch disk					I		
32	Brake mechanism/brake lining (pad)		I	I				
33	Bolts/nuts for each components		I	I				

☆ The above maintenance schedule is established by taking the monthly 1000 kilometers as a reference which ever comes first.

Code: I ~ Inspection, cleaning, and adjustment R ~ Replacement C ~ Cleaning (replaced if necessary) L ~ Lubrication