

CHECKWEIGHER DACS-GN OPERATION MANUAL



 WARNING

- Do not carry out installation, operation, service, or maintenance until thoroughly understanding the contents of this manual.
- Keep this manual available at all times for installation, operation, service, and maintenance.

ISHIDA CO., LTD.

IMPORTANT INFORMATION



WARNING

- **When performing installation, maintenance or inspection of the device, read this manual thoroughly. Be aware of the possible danger of the device and perform operation by following the instructions in this manual.**

1. It is impossible to predict and fully list in an instruction manual all the possible danger which may arise by using this device. When operating the device or performing operations in any way not specifically described in this manual, please contact the Ishida customer support. Safety countermeasures not specifically described in this manual or indicated on the machine itself should be carefully considered and implemented before installing the device or performing any operation, service, or maintenance procedures.
2. Ishida Co., Ltd. holds the copyright of this manual and the copyright law protects all information contained herein. Any disclosure to third parties or unauthorized copying of the information contained herein is not permitted without prior written approval from Ishida Co., Ltd.
3. Although this manual has been carefully edited, if there are any mistakes or if you have any questions, please check the machine type (model) and machine identification and contact your distributor or Ishida customer support.
The model and machine identification are indicated on the device plate attached to the device.
4. The information contained herein may be changed without prior notice.

 ISHIDA		44 SANNO-CHO, SHOGOIN, SAKYO-KU KYOTO, 606-8392 JAPAN	
MODEL _____			
PROJECT No. _____			
SERIAL No. _____			
MFG. DATE _____			
POWER SINGLE	AC	V	A
3-PHASE	AC	V	A
FREQUENCY			Hz
ISHIDA CO., LTD. MADE IN JAPAN			

Device Plate

WARRANTY CONDITIONS

1. Ishida Co., Ltd. only assumes responsibility for repairing or replacing components which are deemed to be defective due to improper materials or manufacturing.
The measures to be taken for defects with uncertain cause shall be decided by mutual consultation between both parties.
For detailed warranty information, refer to the warranty statement included with the device.
2. Ishida assumes no responsibility for direct or indirect damage or lost income caused by unforeseeable operational procedures in any improper way or unauthorized modification to the device.
3. The warranty period is stated in the warranty statement.

Note

The definition for each intended reader described in the table below is as follows:

• Operator:	Personnel who perform basic operations during daily production with the production line (i.e., Operator level operations). Do not perform any work in this manual that is targeted to any personnel other than Operators.
• System administrator:	Personnel who, in addition to the operator level operations, perform registration for weighing and adjustment operations (i.e., Site Engineer level operations). Do not perform any work in this manual that is targeted to Ishida service engineers.
• Ishida Service engineer:	Personnel with specialized knowledge about the device who perform maintenance or inspection of the device, and tuning when installing the device. (i.e. Installation level operations). Unless otherwise noted, there is no limitation in performing any operation described in this manual.

OBJECTIVES AND ORGANIZATION OF THIS MANUAL

This manual is designed to provide users with information on operation, maintenance and inspection procedures of the ISHIDA checkweigher.

The following information is contained in this manual.

1. SAFETY PRECAUTIONS

Be sure to read and understand all information related to safety contained in this manual before attempting to operate, inspect or service this machine.

This information is included to instruct persons who own, install, operate, service or inspect this machine on the warning symbols, precautions which must be observed, the meanings of safety labels attached to the machine as well as sanitary precautions.

2. INTRODUCTION

This chapter describes special terminology used in this manual, machine specifications, configuration, and operation outlines.

3. INSTALLATION

This chapter describes the correct methods of installing the machine.

4. OPERATION PANEL

This chapter describes the components and functions of the operation panel unit (RCU).

5. PRODUCTION

This chapter describes the normal operations and describe the procedures for emergency stop, preparation, operation, and shutdown.

6. OPERATION AND FUNCTION

This chapter describes the setting procedure for product data and functions for applied operations.

7. CLEANUP PROCEDURES

This chapter describes procedures for cleaning the machine.

8. MAINTENANCE AND INSPECTION

This chapter describes the maintenance and inspection procedures required to keep the weighing function in optimum condition.

9. TROUBLESHOOTING

This chapter describes possible causes of failures/troubles and remedial actions.

10. OPTIONS FOR CHECKWEIGHER

This chapter describes the function of the options for checkweigher.

11. APPENDIX

INDEX

TABLE OF CONTENTS

1 SAFETY PRECAUTIONS

1.1	Summary	1-1
1.2	Warning Indications-Types and Definitions.....	1-1
1.3	General Precautions.....	1-2
1.4	Special Precautions	1-6
1.5	Warning Labels.....	1-9
1.5.1	Warning Label Handling	1-9
1.5.2	Warning Label Location.....	1-9
1.6	Drive Power Shutdown and Indication.....	1-10

2 INTRODUCTION

2.1	Terminology	2-1
2.2	Main Components.....	2-2
2.3	Operation Outline	2-4

3 INSTALLATION

3.1	Installation Condition.....	3-1
3.2	Preparing Power Source	3-2
3.3	Installation Procedure	3-2
3.3.1	Preparations before Moving and Installing the Machine	3-2
3.3.2	Preparations after Moving and Installing the Machine.....	3-3

4 OPERATION PANEL

4.1	Operation Panel	4-1
4.2	Main Operations and Indications in this Manual.....	4-3
4.3	Data Input Procedure for Alpha-numerical Values	4-4

5 PRODUCTION

5.1 Emergency Stop and Restart	5-1
5.2 Outline of the Production	5-2
5.3 Pre-start inspection	5-3
5.3.1 Pre-start Checkup	5-3
5.3.2 Zero Adjustment	5-5
5.4 Pre-Production Procedure	5-6
5.5 Checkweigher Production	5-7
5.5.1 Preset Number Selection	5-7
5.5.2 Starting the Production	5-8
5.5.3 Inspection During Production	5-9
5.5.4 Stopping the Production	5-9
5.5.5 When Weight is Displayed Incorrectly	5-10
5.6 End Production	5-10
5.7 Overview of the Items Displayed in the Standby Menu	5-11
5.8 Display of the Standby Menu	5-13
5.9 Function Dialog Menu	5-15
5.10 Output	5-16
5.10.1 USB Data Output	5-17
5.10.2 Each Time Output	5-18
5.10.3 Clear All Totals, Clear Log	5-19
5.10.4 Printer Data Output	5-20
5.10.4.1 Output Destination (When Printer is Installed)	5-20
5.10.4.2 Output of the printer	5-21
5.10.5 Output Data Sample	5-21
5.10.6 Display Access Log	5-24

6 OPERATION AND FUNCTION

6.1 Overview of the Setting Item	6-1
6.2 Access Level Change	6-5
6.2.1 Switching to the Operator Level (Level 0)	6-5
6.2.2 Switching to the Site Engineer Level (Level 1)	6-6
6.2.3 Switching to Installation level (Level 2)	6-7
6.3 Test Production	6-8
6.3.1 Check Mode	6-8
6.3.1.1 Description of the Check Mode Screen	6-8
6.3.1.2 How to Start the Check Mode during Stoppage	6-9
6.3.1.3 How to Start the Check Mode during Operation	6-9
6.3.1.4 Flow of Check Mode	6-10
6.3.2 Test Mode	6-12

6.3.2.1	Description of Test Mode Screen	6-12
6.3.2.2	How to Start the Test Mode during Stoppage	6-13
6.3.2.3	How to Start the Test Mode during Operation	6-13
6.3.2.4	How to Exit the Test Mode	6-14
6.4	Preset Setting	6-14
6.4.1	Product Name	6-15
6.4.2	Capacity	6-16
6.4.3	Reference Weight	6-17
6.4.4	Upper Limit+	6-17
6.4.5	Lower Limit-	6-18
6.4.6	OK-Upper Limit+ or OK-Lower Limit-	6-18
6.4.6.1	OK-Upper Limit+	6-18
6.4.6.2	OK-Lower Limit-	6-19
6.4.7	Preset Tare	6-20
6.4.8	Product Length	6-20
6.4.9	Speed	6-21
6.4.10	Conv. Speed	6-22
6.4.11	Charge Mixing Weight Deviation±	6-22
6.4.12	Timing Setting	6-23
6.4.13	Product Code	6-24
6.4.14	Product Image	6-25
6.4.15	Conveyor Mode	6-26
6.4.16	Reject Setting	6-27
6.4.16.1	Reject Direction Setting	6-29
6.4.17	Output Signal Setting	6-29
6.4.17.1	Output Condition Setting	6-30
6.4.17.2	Output Timing Setting	6-33
6.4.18	N/G Stop Setting	6-35
6.4.18.1	Continuous N/G Count	6-35
6.4.18.2	Continuous N/G Stop	6-36
6.4.19	Over Weight Accept.	6-36
6.4.20	Dynamic Calibration	6-37
6.4.21	Filter Simulation	6-38
6.4.21.1	Acquisition of Weigh Waveforms	6-39
6.4.21.2	Operation of Filter Simulation Screen	6-39
6.4.22	Set. chg. during driving	6-41
6.4.23	Setting the Special X-bar Chart	6-42
6.4.23.1	X-bar Sample Count	6-42
6.4.23.2	X-bar Ref.	6-43
6.4.23.3	X-bar Upper Limit or X-bar Lower Limit	6-43
6.4.24	Setting of the Special Histogram	6-44
6.4.24.1	Histogram Base	6-45
6.4.24.2	Histogram Gap	6-45
6.4.25	Useful Preset Change	6-46
6.4.25.1	Preset Number Change on the Preset Screen	6-46
6.4.25.2	Preset Setting Change in the Standby Menu	6-47
6.4.25.3	Simple Preset Setting	6-47
6.5	Setup Menu	6-49
6.5.1	Write/Read Set Value	6-50
6.5.1.1	Write Preset Setting	6-50
6.5.1.2	Read Preset Setting	6-51

6.5.1.3 Preset Setting CSV Output/Input	6-52
6.5.2 Program Version Information	6-54
6.5.3 License	6-54
6.5.4 Statistics & Output Setting	6-55
6.5.4.1 Output Destination	6-55
6.5.4.2 Line Name	6-55
6.5.4.3 Total Automatic Change	6-56
6.5.4.4 Total Items	6-57
6.5.4.5 Total Auto Output	6-57
6.5.4.6 Batch Analysis	6-58
6.5.4.7 Batch Total Auto Output	6-60
6.5.4.8 Batch Total Time	6-60
6.5.4.9 Batch Total Count	6-61
6.5.4.10 Total Output Time	6-61
6.5.4.11 Always Metal M Output	6-62
6.5.4.12 Each Time Output	6-63
6.5.4.13 Each Time Output Contents	6-63
6.5.4.14 Clear Batch Totals, Clear All Totals	6-64
6.5.4.15 X-bar chart	6-65
6.5.4.16 Histogram	6-65
6.5.5 Span Adjustment	6-66
6.5.6 Linear correction	6-67
6.5.7 System Configuration	6-69
6.5.7.1 Weight Display	6-70
6.5.7.2 Metal Detection	6-70
6.5.7.3 Printer	6-71
6.5.7.4 Reject Func. Select	6-71
6.5.7.5 Speed Display	6-72
6.5.7.6 Tare Subtraction	6-73
6.5.7.7 Dynamic Calibration	6-74
6.5.7.8 Reject. in Dynamic Cali	6-74
6.5.7.9 Preset Number Memorize	6-75
6.5.7.10 Set. chg. during driving	6-76
6.5.7.11 Weight Zone (Switching the 3 Zone/5 Zone)	6-77
6.5.7.11.1 Weight Zone Overview	6-77
6.5.7.11.2 Weight Zone settin procedure	6-77
6.5.7.12 Weight Log	6-78
6.5.7.13 Charge Mixing Weight Deviation	6-78
6.5.7.14 Input Signal Port Setting	6-79
6.5.7.15 Input Signal Setting	6-80
6.5.7.16 Test Mode	6-81
6.5.7.17 Startup Check	6-81
6.5.7.18 Standby Display Preference	6-82
6.5.8 Preset Copy	6-83
6.5.9 Date/Time setting	6-84
6.5.9.1 Date Setting	6-84
6.5.9.2 Time Setting	6-85
6.5.10 Level 1&2&3 Passcodes Setting	6-85
6.5.11 Weigh Unit Setting	6-87
6.5.12 Screen Capture	6-87
6.6 User Log In	6-89

6.6.1	Overview of the User Login Setting Item	6-90
6.6.2	Setting of User Log In	6-90
6.6.3	Log In.	6-91
6.6.3.1	Passcode Unlock	6-93
6.6.4	Log Out	6-94
6.6.5	Register ID.	6-94
6.6.6	Delete ID	6-95
6.6.7	Passcode Change	6-96
6.6.8	Auto Logged-Out Time	6-97
6.6.9	Passcode validity.	6-97
6.6.10	ID52 "maintenance engineer"	6-98
6.6.11	User List Output.	6-99

7 CLEANUP PROCEDURES

7.1	Washing and Sterilization	7-2
7.2	Washing and Sterilization Methods	7-3
7.2.1	Rinsing with Water Method	7-6
7.3	Removing and Attaching Each Parts	7-7
7.3.1	Infeed and Weigh Conveyor Unit.	7-7
7.3.2	Wind Cover (Option)	7-10

8 MAINTENANCE AND INSPECTION

8.1	Adjusting the Tension and Meandering of Infeed and Weigh Conveyor Belt	8-1
8.1.1	Adjusting the Tension	8-1
8.1.2	Adjusting the Meandering	8-2
8.2	Regular Inspection	8-3
8.3	Service Parts	8-3
8.4	Replacing Battery for Memory Backup.	8-4
8.5	Replacing Printer Paper.	8-4

9 TROUBLESHOOTING

9.1	Error Message Handling	9-1
9.2	Failure and Malfunction of DACS-GN	9-6

10 OPTIONS FOR CHECKWEIGHER

10.1	Rollover Prevention Board	10-1
------	-------------------------------------	------

10.2 Signal Tower Setting	10-2
10.2.1 Output Condition Setting (Signal Tower)	10-3
10.2.2 Output Timing Setting (Signal Tower)	10-5
10.3 Proper Weight Count	10-7
10.3.1 Total Count Zoom Display	10-8
10.3.1.1 Overview	10-8
10.3.1.2 Proper Count Clear	10-8
10.3.2 Basic Setting	10-10
10.3.2.1 Proper Count	10-10
10.3.2.2 Proper Reject Setting	10-11
10.3.2.3 Reject target time in proper weight switchover	10-12
10.3.3 Output Signal or Signal Tower Setting	10-13
10.4 FBC INDIRECT FEEDBACK CONTROL (TREND OUTPUT)	10-17
10.4.1 Overview of the auger filler feedback control	10-17
10.4.2 Status Display	10-18
10.4.3 Preset Parameters	10-20
10.4.3.1 FBC	10-20
10.4.3.2 FBC Target Weight	10-21
10.4.3.3 Sample Range +	10-21
10.4.3.4 Sample Range -	10-22
10.4.3.5 FBC Unused Range +	10-22
10.4.3.6 FBC Unused Range -	10-23
10.4.3.7 Sample Count	10-24
10.4.3.8 Sample Interval	10-24
10.4.4 System Configuration	10-25
10.5 FBC INDIRECT FEEDBACK CONTROL (PULSE OUTPUT)	10-26
10.5.1 Overview of the auger filler feedback control	10-26
10.5.2 Status Display	10-26
10.5.3 Preset Parameters	10-28
10.5.3.1 FBC	10-29
10.5.3.2 FBC Target Weight	10-30
10.5.3.3 Sample Range +	10-30
10.5.3.4 Sample Range -	10-31
10.5.3.5 FBC Unused Range +	10-31
10.5.3.6 FBC Unused Range -	10-32
10.5.3.7 Sample Count	10-33
10.5.3.8 Sample Interval	10-33
10.5.3.9 FB Rate	10-34
10.5.3.10 Control Pulse Frequency	10-35
10.5.4 System Configuration	10-35
10.6 FBC INDIRECT FEEDBACK CONTROL (CONTROL AMOUNT OUTPUT)	10-36
10.6.1 Overview of the auger filler feedback control	10-36
10.6.2 Status Display	10-37
10.6.3 Preset Parameters	10-39
10.6.3.1 FBC	10-39
10.6.3.2 FBC Target Weight	10-40

10.6.3.3 Sample Range +	10-41
10.6.3.4 Sample Range -	10-41
10.6.3.5 FBC Unused Range +	10-42
10.6.3.6 FBC Unused Range -	10-42
10.6.3.7 Sample Count	10-43
10.6.3.8 Sample Interval	10-44
10.6.4 System Configuration	10-44
10.7 FLOATING REF. WT. REVISION	10-45
10.7.1 Overview	10-45
10.7.2 Preset Parameters	10-47
10.7.2.1 Ref. Wt. Rev. Upper	10-47
10.7.2.2 Ref. Wt. Rev. Lower	10-48
10.7.2.3 Ref. Wt. Rev. Count	10-48
10.7.2.4 Ref. Wt. Rev. Alarm U.L.	10-49
10.7.2.5 Ref. Wt. Rev. Alarm L.L.	10-50
10.7.3 System Configuration	10-50
10.8 Weight Data Output	10-52

11 APPENDIX

11.1 Model Specifications	11-1
--	-------------

